## COPY

Copy pictures between the cards in the first and second slots.

- 1 Select COPY in the playback menu.
- 2 Highlight one of the following options.

Option	Description
SLOT1 → SLOT2	Copy pictures from the card in the first slot to the card in
	the second slot.
CLOTO > CLOT4	Copy pictures from the card in the second slot to the card
	in the first slot.

- 3 Press the selector right.
- 4 Highlight one of the following options and press MENU/OK.

Option	Description
	Copy selected pictures. Press the selector left or right to view pictures and press <b>MENU/OK</b> to copy the current pic-
	ture.
ALL FRAMES	Copy all pictures.

- Copying ends when the destination is full.
  - If you attempt to copy a file over 4 GB in size to a memory card with a capacity of 32 GB or less, copying will end and the file will not be copied.