PERIPHERAL LIGHT CORRECTION

Select **ON** to enable peripheral illumination correction during movie recording.

Options	
ON	OFF

- If **ON** is selected when a lens that does not transmit data to the camera is attached, peripheral illumination will be adjusted according to the option selected for **IMAGE QUALITY SETTING** > **IMAGE QUALITY SETTING** ADAPTER SETTING > PERIPHERAL ILLUMINATION CORRECTION in the shooting menu (\$\Pi\$ 147).
 - Select **OFF** if you notice banding in movies recorded using this option

☆ ☆ MOUNT ADAPTOR SETTING

This item is also found in the photo menus (11) 145). Changes to one apply to the other.