Filters

Take photos with filter effects.

1 Press the DRIVE/DELETE button and select FILTER in the drive-mode menu.



2 Choose a filter.

| Filter | Description |
|--------------------------|--|
| ₩ TOY CAMERA | Choose for a retro toy camera effect. |
| MINIATURE | The tops and bottoms of pictures are blurred for a diorama effect. |
| R POP COLOR | Create high-contrast images with saturated colors. |
| CA HIGH-KEY | Create bright, low-contrast images. |
| LOW-KEY | Create uniformly dark tones with few areas of emphasized highlights. |
| A DYNAMIC TONE | Dynamic tone expression is used for a fantasy effect. |
| ₷ SOFT FOCUS | Create a look that is evenly soft throughout the whole image. |
| A PARTIAL COLOR (RED) | Areas of the image that are the selected color are recorded in that color. All other areas of the image are recorded in black-and-white. |
| A PARTIAL COLOR (ORANGE) | |
| A PARTIAL COLOR (YELLOW) | |
| A PARTIAL COLOR (GREEN) | |
| A PARTIAL COLOR (BLUE) | |
| A PARTIAL COLOR (PURPLE) | |



Depending on the subject and camera settings, images may in some cases be grainy or vary in brightness or hue.