## **EVF COLOR ADJUSTMENT**

Adjust the color of the display in the electronic viewfinder.

1 Adjust colors using the selector.



2 Press MENU/OK.