
Removing Lens Caps

Remove lens caps as shown.






① Lens caps may differ from those shown.

Attaching Lens Hoods

When attached, lens hoods reduce glare and protect the front lens element.



Be sure to rotate the hood to the final position.