

CONNECTION SETTING

Adjust settings for connection to other devices.

To access connection settings, press MENU/OK, select the ☑ (SET UP) tab, and choose CONNECTION SETTING.





For more information on wireless connections, visit: http://fujifilm-dsc.com/wifi/

Bluetooth SETTINGS

Adjust Bluetooth settings.

•	
Option	Description
PAIRING	Pair the camera with a smartphone running the FUJIFILM Camera
REGISTRATION	Remote app.
SELECT PAIRING DESTINATION	Choose a connection from a list of devices with which the
	camera has been paired using PAIRING REGISTRATION .
	Select NO CONNECTION to exit without connecting.
DELETE PAIRING REG.	Delete pairing information for selected devices. Choose the de-
	vice in the device list. The selected device will also be removed
	from the devices listed in SELECT PAIRING DESTINATION .
Bluetooth ON/OFF	• ON: The camera automatically establishes a Bluetooth con-
	nection with paired devices when turned on.
	OFF: The camera does not connect via Bluetooth.
AUTO IMAGE TRANSFER	• ON: Mark photos for upload as they are taken. Mark JPEG
	photos for upload as they are taken.
	OFF: Photos are not marked for upload as they are taken.
SMARTPHONE SYNC. SETTING	Choose whether to synchronize the camera to the time and/or
	location provided by a paired smartphone.
	• LOCATION&TIME: Synchronize the time and location.
	• LOCATION: Synchronize the location.
	• TIME: Synchronize the time.
	OFF: Synchronization off.