FOCUS CHECK

Options are the same as those for still photography, but settings must be adjusted separately (11 161).

This item is also found in the photo menus (1991). Changes to one apply to the other.



Instant AF is disabled during movie recording. Use instant AF to focus before recording begins.

☆☆ DEPTH-OF-FIELD SCALE

This item is also found in the photo menus (\$\equiv 162\$). Changes to one apply to the other.

AF RANGE LIMITER

This item is also found in the photo menus (1991). Changes to one apply to the other.