4 Press MENU/OK when prompted.



5 Select WIRED LAN.



6 Select **CREATE NEW** to create a new communication setting profile.



- 7 Adjust IP ADDRESS SETTING.
 - Select AUTO to use an IP address assigned by the network.
 - Select MANUAL to choose the IP address manually as described in "Connecting Using an IP Address" (12) 265).
- 8 Select NEXT to proceed after adjusting IP address settings.





