Choosing a Connection Setting Profile

Follow the steps below to use pre-existing or user-created connection setting profiles.

1. Choose **SELECT CONNECTION SETTING** in the network/USB setting menu.

	NETWORK/USB SETTING	1 / 2
	CREATE/EDIT CONNECTION SETTING	
	SELECT CONNECTION SETTING 🏠🖥 STUDIO ▶	
	AIRPLANE MODE	
	Bluetooth/SMARTPHONE SETTING	
	instax PRINTER CONNECTION SETTING	
	Frame.io Camera to Cloud	
	FTP OPTIONAL SETTING	
	USB POWER SUPPLY/COMM SETTING	
	BACK EXIT	

2. Choose the desired connection setting profile.

SELECT CONNECTION SETTING	1 / 2
1: UNIVERSAL SETTING	
2: USB CARD READER	
3: USB TETHER SHOOTING AUTO	
4: USB TETHER SHOOTING FIXED	
5: USB RAW CONV./BACKUP RESTORE	
6: USB WEBCAM	
7: NISHIAZABU STUDIO ▶	
8: NOT CREATED	

AIRPLANE MODE

Select **ON** to disable the camera's wireless LAN and Bluetooth features.

Options	
ON	OFF