

## AF/MF SETTING (Still Photography)

Adjust focus settings for still photography.

To display AF/MF settings, press MENU/OK in the photo shooting display and select the M (AF/MF SETTING) tab.





The options available vary with the shooting mode selected.

## **FOCUS AREA**

Choose the focus area for autofocus, manual focus, and focus zoom ( 96).

## **FOCUS MODE**

Choose how the camera focuses (22).

## **AF MODE**

Choose how the camera focuses in modes FS and FC (1994).