

Maintenance

7.1 Maintenance schedule

Area	Inspection	Action	ОС	TI
Spraying valve	Function	Repair electrical control		S
		system		
Solenoid valve and	- Function	Repair electrical control	Р	S
cable end		system		
Flat-jet nozzle	Function	Repair electrical control	Р	S
		system		
		■ Replace		
	Spraying pattern	- Correct	Р	S
		 Replace nozzles 		
Pipework	• Leaks	Retighten pipe coupling	Ν	D
		Exchange seal		
Control cables • Function		Repair	N	D
		- Replace		

Operating condition (OC)		Time interval (TI)			
N	Normal operation (production)	s	every shift (8 hours)		
Р	Stop (maintenance, troubleshooting)	D	every day (24 hours)		

NOTICE

In the first three months after commissioning, the pipework must be inspected every two weeks. This allows leaks to be detected at an early stage.