

#### Maintenance

# 7 Maintenance

Target groups O, E, M, C



Definition of the target groups:

Operating Instructions General,
 Chapter Introduction/target groups.



Observe the following information:

- Operating Instructions General,
   Chapter Safety,
   Chapter Maintenance,
- Subsuppliers' Operating Instructions,
- Electrical Equipment Operating Instructions.

## 7.1 Maintenance schedule

Area	Inspection	Action	ОС	TI
General	<ul><li>Fastening</li></ul>	Fasten	Р	Υ
	- Damage	- Replace	Р	W
	(condition of barrel surface)	Repair		
	Function	Repair	N	S
	<ul> <li>Unusual noises</li> </ul>	Eliminate the cause	N	М
	• Wear	Replace	Р	ЗМ
		Repair		
	Contamination	- Clean	Р	М
Roller bearing as-	Function	- Replace	Р	6M
sembly		■ Repair		
	• Wear	Replace	Р	Υ
		Repair		
Swivel drive	Function	- Replace	Р	6M
		■ Repair		
	• Wear	Replace	Р	2Y
		Repair		



Snubber roll

### Maintenance

Area	Inspection	Action	ОС	TI
Pivoting arm bearing	- Function	■ Replace	Р	6M
assembly		- Repair		
	• Wear	■ Replace	Р	2Y
		■ Repair		
Fluid line,	<ul><li>Leaks</li></ul>	<ul> <li>Replace</li> </ul>	Р	3M
fluid connection		■ Repair		
	<ul> <li>Volumetric flow rate</li> </ul>	Set volumetric flow rate	Ν	М
Cylinder	Function	- Replace	Ν	S
		■ Repair		
		<ul> <li>Set speed</li> </ul>		
	Bearing assembly	■ Fasten	Р	Υ
		■ Replace		
		■ Repair		
	Sealing	Replace	Р	3M
		Repair		

### Operating condition (OC)

N Normal operation (production)

P Stop (maintenance, troubleshooting)

### Time interval (TI)

S every shift (8 hours)

\*\*)W every week

\*\*)M every month

\*\*)Y every year

\*\*) Intervals combined with numbers signify for example:

3M= every three months