

7 Maintenance

Target groups O, E, M, C



Definition of the target groups:

Operating Instructions General,
 Chapter Introduction/target groups.



Observe the following information:

- Operating Instructions General,
 Chapter Safety,
 Chapter Maintenance,
- Subsuppliers' Operating Instructions,
- Operating Instructions Electrics.

7.1 Maintenance schedule

Area	Inspection	Action	ОС	TI
General	 Fastening 	Fasten	Р	Υ
	 Damage 	■ Replace	Р	М
	(condition)	 Repair 		
	Function	Repair	Ν	S
	 Unusual noises 	Eliminate the cause	Ν	М
	• Wear	- Replace	Р	М
		Repair		
	Contamination	- Clean	Р	M
Peeler knife	 Visual check 		R	D
	Wear	 Regrind by hand 		М
Cylinder	Function	- Replace	N	S
		- Repair		
		 Set speed 		
	 Bearing assembly 	■ Fasten	Р	Υ
		■ Replace		
		 Repair 		

AISHA-CCM Version: A - 2018-10-01 13



Pivoting table with coil peeler

Maintenance

Area	Inspection	Action	ОС	TI
	Sealing	 Replace 	Р	М
		 Repair 		
Fluid line,	- Leaks	- Replace	Р	М
fluid connection		 Repair 		
	Volumetric flow rate	Set volumetric flow rate	N	М
Guide clearance	 Tolerances 	 Readjust, replace 	R	В3
Table surface	Contamination	- Clean	R	D
-(transfer table, tilt-	 Damage 	 Grinding 		3M
ing table)				

Operating condition (OC)		
N	Normal operation (production)	
Р	Stop (maintenance, troubleshooting)	
R	Repair	

Time interval (TI)

S every shift (8 hours)

**)D every day (24 hours)

**)M every month

**)Y every year

B3 Check/top up every 6 months

**) Intervals + numbers mean, for example:

3M= every three months

NOTE

In the first three months after commissioning, the pipework must be inspected every two weeks. This allows leaks to be detected at an early stage.