Maintenance

7 Maintenance

Target groups O, E, M, C



Definition of the target groups:

Operating Instructions General,
 Chapter Introduction/target groups.



Observe the following information:

- Operating Instructions General,
 Chapter Safety,
 Chapter Maintenance,
- Subsuppliers' Operating Instructions,
- Electrical Equipment Operating Instructions.

7.1 Maintenance schedule

Area	Inspection	Action	ОС	TI
General	 Fastening 	■ Fasten	Р	Υ
	Damage	 Replace 	Р	М
	(condition)	Repair		
	Function	Repair	N	S
	 Unusual noises 	Eliminate the cause	N	М
	• Wear	Replace	Р	М
		Repair		
	Contamination	- Clean	Р	М
Fluid line,	• Leaks	Replace	Р	М
fluid connection		■ Repair		
	Volumetric flow rate	Set volumetric flow rate	N	М
Guide	Function	 Repair 	R	Υ
		 Replace 		
	Lubrication	Clean sliding surfaces	Р	М
	Sliding surfaces	Grease sliding surfaces		
Strippers	• Wear	Replace		М



Wedge adjustment system

Maintenance

Area	Inspection	Action	ОС	TI
		Repair		
	 Contamination 	- Clean	Р	М
Cylinder	Function	 Replace 	Ν	S
		■ Repair		
		 Set speed 		
	 Bearing assembly 	■ Fasten	Р	Υ
		 Replace 		
		 Repair 		
	- Seal	Replace	Р	М
		 Repair 		

Operating condition (OC)		Time interval (TI)			
N	Normal operation (production)	s	every shift (8 hours)		
Р	Stop (maintenance, troubleshooting)	М	every month		
		Υ	every year		

NOTICE

In the first three months after commissioning, the pipework must be inspected every two weeks. This allows leaks to be detected at an early stage.

AISHA-CCM Version: A - 2018-10-18 13