

```

/**
*****
* @file           : main.c
* @author          : Sagar More
* @brief           : Task Code
*
*****
*/

// IRQ_no % 32 = bit position from the register

#include <stdint.h>
#include <stdio.h>

#define UART3_IRQ_NUM 39

#define ISPER1 (*(uint32_t *)0xE000E204)
#define ISER1 (*(uint32_t *)0xE000E104)

int main(void)
{
    // 1. Manually pend the pending bit for the USART3 IRQ number in
    NVIC
    ISPER1 |= (0x01 << (UART3_IRQ_NUM % 32));

    // 2. Enable USART3 IRQ number in NVIC
    ISER1 |= (0x01 << (UART3_IRQ_NUM % 32));

    while(1){

    }

}

void USART3_IRQHandler(void){
    printf("in USART3 ISR\n");
}

```