

```

/**
*****
*****
* @file           : main.c
* @author          : Sagar More
* @brief           : Task Code
*
*****
*****
*/

// IRQ_no % 32 = bit position from the register
#include <stdint.h>
#include <stdio.h>

#define OTG_HS_IRQ_NUM 77

#define ISPR2 (*(uint32_t *)0xE000E208)
#define ISER2 (*(uint32_t *)0xE000E108)

int main(void)
{
    // 1. Set pending bit for OTG_HS IRQ in NVIC
    ISPR2 |= (1 << (OTG_HS_IRQ_NUM % 32));

    // 2. Enable OTG_HS IRQ in NVIC
    ISER2 |= (1 << (OTG_HS_IRQ_NUM % 32));

    while(1) {

    }
}

void OTG_HS_IRQHandler(void){
    printf("in OTG_HS ISR\n");
}

```