W tej witrynie są wykorzystywane pliki cookie, których Google używa do świadczenia swoich usług i analizowania ruchu. Twój adres IP i nazwa klienta użytkownika oraz dane dotyczące wydajności i bezpieczeństwa są udostępniane firmie Google, by zapewnić odpowiednią jakość usług, generować statystyki użytkowania oraz wykrywać nadużycia i na nie reagować.

DOWIEDZ SIĘ WIĘCEJ ROZUMIEM

20 June 2022

Is It OK to Use an External 50 Ohm Terminator with an Oscilloscope?

Recently, a reader posed the question in the Comment field on Dr. Eric Bogatin's blog post, How to Choose Between the Oscilloscope's 50 Ohm Input and 1 MOhm Input: "Is there any difference between using an external 50 Ohm terminator instead of the internal 50 Ohm termination on the oscilloscope--for example, using a RG58/RG174 cable?"

Eric answered:

"In principle, you can use the oscilloscope input set for 1 MOhm termination, then add an external 50 Ohm termination resistor on a BNC Tee connector, for example. This has the advantage that you can actually use any resistor for a load, or terminate signals with an RMS voltage larger than 5 V.

However, there are two problems with using this approach for high-speed signals with rise times shorter than 1 nsec, which require an oscilloscope with bandwidth larger than 1 GHz.

Problem #1 is that on high-speed oscilloscopes, there are actually two amplifiers. One uses the 1 MOhm input resistor and the other uses the 50 Ohm resistor. When you change terminations, you are also changing amplifiers. The 1 MOhm amplifier will only go up to 1 GHz bandwidth, whereas the 50 Ohm amplifier will go up to the full bandwidth of the oscilloscope.

Problem #2 is that when you use a BNC tee (or any external adapter), you are adding a stub to the signal. You will see the impact of the stub at frequencies greater than 1 GHz.

But, if you are measuring < 1 GHz signals on an oscilloscope with ≤ 1 GHz bandwidth, using an external 50 Ohm termination is perfectly fine."

For more on this topic, see Eric's webinar: "

What Every Oscilloscope User Needs To know About Transmission Lines."

On 6/20/2022

Labels: 1 megaohm input, 50 ohm input, Eric Bogatin, termination models

No comments:

Post a Comment

Newer Post Home Older Post

Visit

Teledyne LeCroy

Search This Blog

Search



Top Posts

More Basics of Three-Phase AC Sinusoidal Voltages

How to Choose Between the Oscilloscope's 50 Ohm Input and 1 MOhm Input

Is Your Testbench Mixed-Signal Ready?

An Under-the-Hood View of PCIe 3.0 Link Training (Part I)

What Is Differential Manchester Encoding?

Blog Archive

≥023 (9)

2022 (41)

November (4)

≫ctober (2)

▶ eptember (2)

Mugust (5)

▶uly (3)

yune (4)

Get Ready for PCIe 6.0 Base Tx Testing--Compliance...

Is It OK to Use an External 50 Ohm Terminator with...

Oscilloscope Basics: Cal Out and Aux Out

What Happens When You Connect a USB-C Cable

May (4)

April (4)

March (4)

February (4)

anuary (5)

W tej witrynie są wykorzystywane pliki cookie, których Google używa do świadczenia swoich usług i analizowania ruchu. Twój adres IP i nazwa klienta użytkownika oraz dane dotyczące wydajności i bezpieczeństwa są udostępniane firmie Google, by zapewnić odpowiednią jakość usług, generować statystyki użytkowania oraz wykrywać nadużycia i na nie reagować.

DOWIEDZ SIĘ WIĘCEJ ROZUMIEM

≥016 (21) ≥015 (35) ≥014 (34) ≥013 (30)

© 2013-2022 Teledyne LeCroy, Inc., except where noted. Reproduction prohibited except by written permission.