M2 – Instruction Set Architecture

Module Outline

- Addressing modes. Instruction classes.
- MIPS-I ISA.
- Translating and starting a program.
- High level languages, Assembly languages and object code.
- Subroutine and subroutine call. Use of stack for handling subroutine call and return.

Subroutine Calls

Subroutines in MIPS

- Subroutine Call – **jal *subname***
  - Saves return address in R31 ($ra) and jumps to subroutine entry label subname

Subroutines in MIPS

- Subroutine Call – **jal *subname***
  - Saves return address in R31 ($ra) and jumps to subroutine entry label subname
- Subroutine Return – **jr $31**
  - Loads PC with return address in $31

Subroutines in MIPS



Subroutines in MIPS



Subroutines in MIPS



Subroutines in MIPS



Subroutines in MIPS



Subroutines in MIPS



Subroutines in MIPS



Subroutines in MIPS



Registers Usage Convention

Name	Register number	Usage	Preserved on call?
$zero	0	The constant value 0	n.a.
$v0–$v1	2–3	Values for results and expression evaluation	no
$a0–$a3	4–7	Arguments	no
$t0–$t7	8–15	Temporaries	no
$s0–$s7	16–23	Saved	yes
$t8–$t9	24–25	More temporaries	no
$gp	28	Global pointer	yes
$sp	29	Stack pointer	yes
$fp	30	Frame pointer	yes
$ra	31	Return address	yes

Subroutines – Parameter Passing

```
# main program
....
....
add R4, R0, R16
add R5, R0, R17
jal func1
....
....
....
```

```
0x200  func1:
       ....
       ....
0x240  jr $ra
```

Subroutines – Parameter Passing

```
# main program
....
....
add $a0, $zero, $s0
add $a1, $zero, $s1
jal accArray
print $v0
....
....
....
```

```
accArray:
add $v0, $zero, $zero
loop:
beq $a0, $zero, done
lw $t0, 0($a1)
add $v0, $v0, $t0
addiu $a1, $a1, 4
addi $a0, $a0, -1
j loop
done:
jr $ra
```

Subroutines – Parameter Passing

- Caller saves parameters in $a0 - $a3

Subroutines – Parameter Passing

- Caller saves parameters in $a0 - $a3
- Callee stores results in $v0, $v1.

Subroutines – Parameter Passing

- Caller saves parameters in $a0 - $a3
- Callee stores results in $v0, $v1.
- How does the caller pass more than 4 parameters to the callee?

Subroutines – Parameter Passing

- Caller saves parameters in $a0 - $a3
- Callee stores results in $v0, $v1.
- How does the caller pass more than 4 parameters to the callee?
- Program stack

Subroutines – Parameter Passing

- Caller saves parameters in $a0 - $a3
- Callee stores results in $v0, $v1.
- How does the caller pass more than 4 parameters to the callee?
- Program stack



The MIPS Stack





R29 = $sp **0x7FFF FFF4**

The MIPS Stack





- Push the value in $t0 on the stack

The MIPS Stack



- Push the value in $t0 on the stack

$sp (R29) 0x7FFF FFF0

The MIPS Stack



- Push the value in $t0 on the stack

Push

```
addi $sp, $sp, -4
sw $t0, 0($sp)
```

$sp (R29) **0x7FFF FFF0**

The MIPS Stack



- Pop into $t1

$sp (R29) 0x7FFF FFF4

The MIPS Stack



- Pop into $t1

Pop

```
lw $t1, 0($sp)
addi $sp, $sp, +4
```

$sp (R29) 0x7FFF FFF4

Subroutines – Parameter Passing

```
# main program
# 6 parameters to func1
....
....
...
jal func1
....
....
....
```



Subroutines – Parameter Passing

```
# main program
# 6 parameters to func1
....
....
# 4 args are in $a0 - $a3
...
# push 2 on stack
...
...
jal func1
....
....
....
```



Subroutines – Parameter Passing

```
# main program
# 6 parameters to func1
....
....
# 4 args are in $a0 - $a3
...
# push 2 on stack
addi $sp, $sp, -8
sw $t0, 0($sp)
sw $t1, -4($sp)
jal func1
....
....
....
```



Subroutines – Parameter Passing

```
# main program
# 6 parameters to func1
....
....
# 4 args are in $a0 - $a3
...
# push 2 on stack
addi $sp, $sp, -8
sw $t0, 0($sp)
sw $t1, -4($sp)
jal func1
....
....
....
```



Subroutines – Parameter Passing

```
# main program
# 6 parameters to func1
....
....
# 4 args are in $a0 - $a3
...
# push 2 on stack
addi $sp, $sp, -8
sw $t0, 0($sp)
sw $t1, -4($sp)
jal func1
....
....
....
```

```
func1:
....
lw $t4, 0($sp)
lw $t5, -4($sp)
....
....
```



Nested Subroutines



Nested Subroutines



Stores return address in $ra

Nested Subroutines



Nested Subroutines



Nested Subroutines

- func1 overwrites return address in $ra (R31)
- Store the current return address in the program stack

Nested Subroutines

func1:

….

….

….



Nested Subroutines

```
func1:
....
....
....
```



Nested Subroutines

```
func1:
addi $sp, $sp, -4
sw $ra, 0($sp)
....
....
....
```



Nested Subroutines

```
func1:
addi $sp, $sp, -4
sw $ra, 0($sp)
....
....
....
```

What does the stack look like after func1 passes contents of register $t2 as a parameter to func2 and calls func2? Show the code changes in func1 and func2.



Nested Subroutines

```
func1:
addi $sp, $sp, -4
sw $ra, 0($sp)
....
addi $sp, $sp, -4
sw $t2, 0($sp)
jal func2
....
....
```

```
func2:
addi $sp, $sp, -4
sw $ra, 0($sp)
....
```



Stack Frame

- Stack Frame: Private space for a subroutine allocated on entry and deallocated on exit
- Identified by a Frame Pointer ($fp (R30))



Stack Frame


Stack Frame
$fp
Return Addr
Old FP
Saved Registers
Local Variables
Parameters passed to func2
$sp
$fp
$sp
func1 Frame
func2 Frame

Stack Frame


Stack Frame
$fp
Return Addr
Old FP
Saved Registers
Local Variables
Parameters passed to func2
$sp
In case this function calls another

Stack Frame



In case callee calls another

In case callee modifies

$s0	16	saved temporary (preserved across call)
$s1	17	saved temporary (preserved across call)
$s2	18	saved temporary (preserved across call)
$s3	19	saved temporary (preserved across call)
$s4	20	saved temporary (preserved across call)
$s5	21	saved temporary (preserved across call)
$s6	22	saved temporary (preserved across call)
$s7	23	saved temporary (preserved across call)

Stack Frame


Stack Frame
$fp
Return Addr
Old FP
Saved Registers
Local Variables
Parameters passed to func2
$sp
In case callee calls another
In case callee modifies
Local variables in callee

Stack Frame


Stack Frame
$fp
Return Addr
Old FP
Saved Registers
Local Variables
Parameters passed to func2
$sp
In case callee calls another
In case callee modifies
Local variables in callee
Passes args to another func

Stack Frame


Stack Frame
$fp
Return Addr
Old FP
Saved Registers
Local Variables
Parameters passed to func2
$sp
...
$fp
$ra
$fp
$s0
$s1
func1_X
func1_Y
$sp
...

Frame Pointer

- After entry into a subroutine:



Frame Pointer

- After entry into a subroutine:
  - Save return address



Frame Pointer

- After entry into a subroutine:
  - Save return address
  - Save frame pointer of the caller function



Frame Pointer

- After entry into a subroutine:
  - Save return address
  - Save frame pointer of the caller function
  - Point the frame pointer to the first location of stack frame of the current subroutine



Frame Pointer

- After entry into a subroutine:
  - **Save return address**



Frame Pointer

- After entry into a subroutine:
  - **Save return address**

```
addi $sp, $sp, -4
sw $ra, 0($sp)
```



Frame Pointer

- After entry into a subroutine:
  - Save return address
  - **Save frame pointer of the caller function**



Frame Pointer

- After entry into a subroutine:
  - Save return address
  - **Save frame pointer of the caller function**

```
addi $sp, $sp, -4
sw $fp, 0($sp)
```



Frame Pointer

- After entry into a subroutine:
  - Save return address
  - Save frame pointer of the caller function
  - **Point the frame pointer to the first location of stack frame of the current subroutine**



Frame Pointer

- After entry into a subroutine:
  - Save return address
  - Save frame pointer of the caller function
  - **Point the frame pointer to the first location of stack frame of the current subroutine**

```
addi $fp, $sp, 4
```



Frame Pointer

```
func1:
addi $sp, $sp, -8
sw $ra, 4($sp)
sw $fp, 0($sp)
addi $fp, $sp, 4
....
....
....
```



Frame Pointer

```
func1:
addi $sp, $sp, -8
sw $ra, 4($sp)
sw $fp, 0($sp)
addi $fp, $sp, 4
....
....
....
```

Parameters can be accessed in the callee function: 4($fp), 8($fp)



Stack Frame

- **Save change registers**



Stack Frame

- **Save change registers**

```
addi $sp, $sp, -8
sw $s0, 4($sp)
sw $s1, 0($sp)
```



Stack Frame

```
func1:
addi $sp, $sp, -8
sw $ra, 4($sp)
sw $fp, 0($sp)
addi $fp, $sp, 4
addi $sp, $sp, -8
sw $s0, 4($sp)
sw $s1, 0($sp)

# func1 code
```



Stack Frame


State of stack before callee returns
...
$t1
$t0
$fp
$ra
$fp
$s0
$sp
$s1
...


State of stack caller expects
...
$fp
$t0
$sp
$t1
...

Stack Frame – Callee Epilogue

- Before return from callee subroutine:
  - Restore saved regs
  - Restore frame pointer of the caller function
  - Restore return address
  - Return



Stack Frame – Callee Epilogue

- Before return from callee subroutine:
  - Restore saved regs
  - Restore frame pointer of the caller function
  - Restore return address
  - Return

```
....
lw $s1, 0($sp)
lw $s0, 4($sp)
lw $fp, 8($sp)
lw $ra, 12($sp)
addi $sp, $sp, 16
jr $ra
```



Stack Frame – Callee Epilogue

- Before return from callee subroutine:
  - Restore saved regs
  - Restore frame pointer of the caller function
  - Restore return address
  - Return

```
....
lw $s1, 0($sp)
lw $s0, 4($sp)
lw $fp, 8($sp)
lw $ra, 12($sp)
addi $sp, $sp, 16
jr $ra
```



Stack Frame

```
func1:
addi $sp, $sp, -8
sw $ra, 4($sp)
sw $fp, 0($sp)
addi $fp, $sp, 4
addi $sp, $sp, -8
sw $s0, 4($sp)
sw $s1, 0($sp)

# func1 code

lw $s1, 0($sp)
lw $s0, 4($sp)
lw $fp, 8($sp)
lw $ra, 12($sp)
addi $sp, $sp, 16
jr $ra
```



Module Outline

- Addressing modes. Instruction classes.
- MIPS-I ISA.
- Translating and starting a program.
- High level languages, Assembly languages and object code.
- Subroutine and subroutine call. Use of stack for handling subroutine call and return.

Backup

Linking Multiple Modules



The a.out executable

- What does the a.out file contain?
  - Program “code” (machine instructions)
  - Data values (values, size of arrays)
- Other information that is needed for
  - execution
  - debugging
    - Debugging: The stage in program development where mistakes (“bugs”) in the program are identified

Stack Frame – Recall



Saved Registers

- Registers 16 – 23 are saved across function calls

Name	Register number	Usage	Preserved on call?
$zero	0	The constant value 0	n.a.
$v0–$v1	2–3	Values for results and expression evaluation	no
$a0–$a3	4–7	Arguments	no
$t0–$t7	8–15	Temporaries	no
$s0–$s7	16–23	Saved	yes
$t8–$t9	24–25	More temporaries	no
$gp	28	Global pointer	yes
$sp	29	Stack pointer	yes
$fp	30	Frame pointer	yes
$ra	31	Return address	yes

Saved Registers

- Registers 16 – 23 are saved across function calls
- Save registers $s0 - $s7 if used by the callee
- Example: $s0, $s1 are saved

Stack Frame

- Local variables are allocated on the stack after the saved registers



Stack Frame


High address
$fp
$sp
$fp
Saved argument registers (if any)
Saved return address
Saved saved registers (if any)
Local arrays and structures (if any)
$sp
$fp
$sp
Low address
(a)
(b)
(c)