

7.2.3.13 a Service instruction iZi Flex Fix i-Size; replace crotch strap

BeSafe®

Project: B1401	Rev.: 01	Date: 2017-10-31	Pages: 1 of 6	Saved: 2017-10-31	Sign:
Done by: RDP	7.2.3.13 a Service instruction iZi Flex Fix i-Size; replace crotch strap				

Service to be done by RETAILER

When do you need this manual:

1.	When the BeSafe iZi Flex lap belt guider is broken and needs replacing.	
----	---	--

What do you need:

Service parts	Lap belt guider Item number: 5186xx	
Tools	Torx T20 Screwdriver	
	Flathead Screwdriver	
Remarks		

7.2.3.13 a Service instruction iZi Flex Fix i-Size; replace crotch strap

Project: B1401	Rev.: 01	Date: 2017-10-31	Pages: 2 of 6	Saved: 2017-10-31	Sign:
Done by: RDP	7.2.3.13 a Service instruction iZi Flex Fix i-Size; replace crotch strap				

No.	Action
A1	Start by removing the fabric and foam. Detach the elastic loops at the back. Then pull the fabric over the lap belt guider. 
A2	Remove the front plastic hook, starting from the side. Then remove the foam under the seat fabric. 
A3	Remove the seatbelt guiders, by removing the 2 Torx T20 screws. Now rotate the backrest backwards. 

7.2.3.13 a Service instruction iZi Flex Fix i-Size; replace crotch strap

Project: B1401	Rev.: 01	Date: 2017-10-31	Pages: 3 of 6	Saved: 2017-10-31	Sign:
Done by: RDP	7.2.3.13 a Service instruction iZi Flex Fix i-Size; replace crotch strap				

A4 Remove the 13 screws in the base. Start near the rotation point, end at the front.



A5 Lift the seat upper shell from the seat lower shell. Start by unclicking the seat edge cover.



A6 Take the seat upper shell and turn it around.



A7 Loosen the lap belt guide bracket with a flathead screwdriver. Rotate it 90 degrees and push it through the upper seat shell hole.



7.2.3.13 a Service instruction iZi Flex Fix i-Size; replace crotch strap

Project: B1401	Rev.: 01	Date: 2017-10-31	Pages: 4 of 6	Saved: 2017-10-31	Sign:
Done by: RDP	7.2.3.13 a Service instruction iZi Flex Fix i-Size; replace crotch strap				

A8	Turn the upper seat shell around. Now you can pull out the lap belt guider. You may use some force.  
A9	Throw away the old lap belt guider.
B1	Push in the new lap belt guider. Make sure the lap belt guider is mounted in the correct direction (circular sewing towards the front):  
B2	Turn around the seat shell upper and pull the lap belt through. Push the lap belt guider bracket into the recess with force.  
B3	Position the seat assembly and backrest assembly. Place the seat upper shell on the seat assembly.  

7.2.3.13 a Service instruction iZi Flex Fix i-Size; replace crotch strap

Project: B1401	Rev.: 01	Date: 2017-10-31	Pages: 5 of 6	Saved: 2017-10-31	Sign:
Done by: RDP	7.2.3.13 a Service instruction iZi Flex Fix i-Size; replace crotch strap				

- B4** Make sure the clicker near the seat edge cover is mounted correctly on both sides. Also position the seat upper shell correctly near the rotation point.



- B5** Start with remounting the 13 screws, from the back to the front.



- B6** Remount the seat belt guiders using 2 screws.



- B7** Remount the foam and fabrics. Start by mounting the foam over the lap belt guider. Than remount the seat fabric. Start by mounting the front seat fabric hook, from one side to the other.



7.2.3.13 a Service instruction iZi Flex Fix i-Size; replace crotch strap

Project: B1401	Rev.: 01	Date: 2017-10-31	Pages: 6 of 6	Saved: 2017-10-31	Sign:
Done by: RDP	7.2.3.13 a Service instruction iZi Flex Fix i-Size; replace crotch strap				

B8	Pull through the lap belt guider. Next remount the elastic straps towards the back. 
B9	Mount the fabric around the seat shell upper corners, from the back towards the front. 
B10	Test if the lap belt guider opens and closes correctly. The job is finished. 