

BeSafe Service instruction iZi Flex Fix i-Size

Replace crotch strap fabric (example)



Project: iZi Flex FIX i-Size	Rev.: 01	Date: 03/05/2018	Pages: 1 of 3	Saved: 09-11-2017	Sign:
Done by: HW	Repair manual iZi Flex FIX i-Size Repair of failing recline stops Rev1 2018 05 03.docx				

Repair manual iZi Flex FIX i-Size

Service to be done by:	Retailer
------------------------	-----------------

When do you need this manual:

When the backrest of the iZi Flex fell flat and the rotation stops have opened.



What do you need:

No spare parts or tools are needed for this repair.

BeSafe Service instruction iZi Flex Fix i-Size

Replace crotch strap fabric (example)



Project: iZi Flex FIX i-Size	Rev.: 01	Date: 03/05/2018	Pages: 2 of 3	Saved: 09-11-2017	Sign:
Done by: HW	Repair manual iZi Flex FIX i-Size Repair of failing recline stops Rev1 2018 05 03.docx				

No.	Action	Picture
1.	Place the iZi Flex seat on a protective surface and check that the backrest can rotate freely up and down.	
2.	Move the fabric flap forward, moving it away from behind the red hip-belt guiders.	
3.	Rotate the backrest towards an upright position. When the rotation stops hit the red hip-belt guiders, use force and continue to rotate until the seat back is in a vertical position. The rotation stops will snap outward and end up next to/under the red hip-belt guiders.	

BeSafe Service instruction iZi Flex Fix i-Size

Replace crotch strap fabric (example)

BeSafe®

Project: iZi Flex FIX i-Size	Rev.: 01	Date: 03/05/2018	Pages: 3 of 3	Saved: 09-11-2017	Sign:
Done by: HW	Repair manual iZi Flex FIX i-Size Repair of failing recline stops Rev1 2018 05 03.docx				

No.	Action	Picture
4.	Use some force to press the rotation stops inwards, to make them lock behind the red hip-belt guiders again. <i>If difficult, try to rotate the backrest slightly while pressing.</i>	
5.	Re-install the fabric like indicated. Install the top flap behind the backrest fabric and tuck in the side flaps behind the red lap-belt guiders.	
6.	Check: - that the backrest can rotate freely enough to allow for the reclined position - that the recline stop is working, preventing the seat's backrest from falling backwards 90°.	