

7.2.3.11.c Instruction manual ISOfix release

BeSafe®

Reduce the tension of the ISOfix connectors before releasing

Cap.:	Rev.: 01	Date: 2016-09-21	Pages.: 1 of 2	Name: 7.2.3.11.c Service instruction for easy ISOfix release 2016 09 13.docx
Done by: EvdV	Sign:	Saved:		

Manual when to help when the ISOfix base cannot be released from the ISOfix anchors in the car



Solution: Reduce the tension on the ISOfix connectors!

Wiggle base sideways + pull release handle



Alternative:

Slide the ISOfix connectors out



7.2.3.11.c Instruction manual ISOfix release



Reduce the tension of the ISOfix connectors before releasing

Cap.:	Rev.: 01	Date: 2016-09-21	Pages.: 2 of 2	Name: 7.2.3.11.c Service instruction for easy ISOfix release 2016 09 13.docx
Done by: EvdV	Sign:	Saved:		



And release the ISOfix connectors with the handle



Alternative:

Pull directly on the internal ISOfix connector

Near the ISOfix connector is a hole in the tube. Use a screw driver to insert into the hole and twist the screw driver tip away from the car bench (see picture)



Check the iZi Modular base

1. Check if both ISOfix connectors can be connected: Indicator turns green



2. Check if both ISOfix connectors can be released by pulling the handle



If the release button do not work: contact your local BeSafe retailer that will help you to resolve the issue.