# UCS1502 - MICROPROCESSORS AND INTERFACING

# 8279- Keyboard Display Controller

S. Angel Deborah Assistant Professor, Dept. of CSE



## **Learning Objective**

- To understand the architecture of 8279
- To understand 8279 operation



## **Overview**


- Pin diagram of 8279
- Architecture
- Command word
- Modes of operation




### Features of 8279

- Scans and encodes up to a 64-key keyboard.
- Controls up to a 16-digit numerical display.
- Keyboard has a built-in FIFO 8 character buffer to store the keyboard Entries and an Interrupt signal with each Entry.
- The display is controlled from an internal 16x8 RAM that stores the coded display information.







## **Pin Details**

- **A0** : Selects data (0) or control/status (1) for reads and writes between microprocessor and 8279.
- **BD** : Output that blanks the displays.
- **CLK** : Used internally for timing. Maximum is 3 MHz
- **CN/ST** : Control/strobe, connected to the control key on the keyboard.
- **CS** : Chip select that enables programming, reading the keyboard, etc.
- **DB7-DB0** : Consists of bidirectional pins that connect to data bus on micro.

## **Pin Details**

• IRQ

: Interrupt request, becomes 1 when a key is pressed, data is available.

OUT A3-A0/B3-B0

: Outputs that sends data to the most significant/least significant nibble of

· RD(WR)

display.

: Connects to micro's IORC or RD signal, reads data/status registers.

RESET

: Connects to system RESET.

RL7-RL0

: Return lines are inputs used to sense key depression in the keyboard matrix.

• Shift

: Shift connects to Shift key on keyboard.

SL3-SL0 and

: Scan line outputs scan both the keyboard displays.


#### **Input Modes**

- Scanned Keyboard—with encoded (8 x 8 key keyboard) or decoded (4 x 8 key keyboard) scan lines. A key depression generates a 6-bit encoding of key position. Position and shift and control status are stored in the FIFO. Keys are automatically debounced with 2-key lockout or N-key rollover.
- Scanned Sensor Matrix—with encoded (8 x 8 matrix switches) or decoded (4 x 8 matrix switches) scan lines. Key status (open or closed) stored in RAM addressable by CPU.
- Strobed Input—Data on return lines during control line strobe is transferred to FIFO.

### **Output Modes**

- 8 or 16 character multiplexed displays that can be organized as dual 4-bit or single 8-bit (B<sub>0</sub> = D<sub>0</sub>, A<sub>3</sub> = D<sub>7</sub>).
- Right entry or left entry display formats.

# 8279 Block Diagram



# **Block Diagram**

Mainly 4 Sections:

1.KeyBoard Section

2.Scan Section

3.Display Section

4. μp Interface Section



## **Keyboard Section**

- RL0 RL7 connected to 8 columns of keyboard
- 2 modes: 2-key lockout, N key Rollover
- FIFO RAM with 8 registers to store 8 keyboard entries and each read in the order of their entries.
- Sent IRQ signal when FIFO is not empty



## **Scan Section**

- It has a Scan Counter and 4 Scan Lines
- Connected to 4 to 16 Decoder to generate 16 scan lines
- Scan lines can be connected to rows of Matrix Keyboard and Digit drivers of Display



# **Display Section**

8 Output lines divided into 2 groups:

A0 - A3 and B0 - B3

- Can be used as 8 or 4/4
- BD line for display Blanking
- 16 X 8 Display RAM



## μp Interface Section

- Data bus : DB0 DB7
- One IRQ Line
- Six interface lines and A0
- A0 = 1; signals are control/status word



# 8279 COMMAND WORDS (A0 = 1)


- 1. Keyboard/Display Mode
- 2. Program Clock
- 3. Read FIFO/Sensor RAM
- 4. Read Display RAM
- 5. Write Display RAM
- 6. Display write inhibit /Blanking
- 7. Clear
- 8. End Interrupt/Error mode set



# D7,D6,D5 Configurations

<b>D7</b>	D6	D5	Function	Purpose
0	0	0	Mode set	Selects the number of display positions, type of key scan
0	0	1	Clock	Programs internal clk, sets scan and debounce times.
0	1	0	Read FIFO	Selects type of FIFO read and address of the read.
0	1	1	Read Display	Selects type of display read and address of the read.
1	0	0	Write Display	Selects type of write and the address of the write.
1	0	1	Display write inhibit	Allows half-bytes to be blanked.
1	1	0	Clear	Clears the display or FIFO
1	1	1	End interrupt	Clears the IRQ signal to the microprocessor.

#### Keyboard/Display Mode Set



Where DD is the Display Mode and KKK is the Keyboard Mode.

#### DD

- 0 0 8 8-bit character display—Left entry
- 0 1 16 8-bit character display—Left entry\*
- 1 0 8 8-bit character display----Right entry
- 1 1 16 8-bit character display—Right entry



#### KKK

- 0 0 0 Encoded Scan Keyboard—2 Key Lockout\*
- 0 0 1 Decoded Scan Keyboard—2-Key Lockout
- 0 1 0 Encoded Scan Keyboard—N-Key Rollover
- 0 1 1 Decoded Scan Keyboard—N-Key Rollover
- 1 0 0 Encoded Scan Sensor Matrix
- 1 0 1 Decoded Scan Sensor Matrix
- 1 1 0 Strobed Input, Encoded Display Scan
- 1 1 1 Strobed Input, Decoded Display Scan



#### Program Clock

Code: 0 0 1 P P P P

All timing and multiplexing signals for the 8279 are generated by an internal prescaler. This prescaler divides the external clock (pin 3) by a programmable integer. Bits PPPP determine the value of this integer which ranges from 2 to 31.



#### Read FIFO/Sensor RAM

Code: 0 1 0 Al X A A A X = Don't Care

The CPU sets the 8279 for a read of the FIFO/Sensor RAM by first writing this command. In the Scan Keyboard Mode, the Auto-Increment flag (AI) and the RAM address bits (AAA) are irrelevant. The 8279 will automatically drive the data bus for each subsequent read ( $A_0 = 0$ ) in the same sequence in which the data first entered the FIFO. All subsequent reads will be from the FIFO until another command is issued.

In the Sensor Matrix Mode, the RAM address bits AAA select one of the 8 rows of the Sensor RAM. If the AI flag is set (AI = 1), each successive read will be from the subsequent row of the sensor RAM.

#### Read Display RAM

Code: 0 1 1 Al A A A

The CPU sets up the 8279 for a read of the Display RAM by first writing this command. The address bits AAAA select one of the 16 rows of the Display RAM. If the Al flag is set (A1 = 1), this row address will be incremented after each following read or write to the Display RAM. Since the same counter is used for both reading and writing, this command sets the next read or write address and the sense of the Auto-Increment mode for both operations.



#### Write Display RAM

Code:

1 0 0 AI A A A

The CPU sets up the 8279 for a write to the Display RAM by first writing this command. After writing the command with  $A_0 = 1$ , all subsequent writes with  $A_0$ = 0 will be to the Display RAM. The addressing and Auto-Increment functions are identical to those for the Read Display RAM. However, this command does not affect the source of subsequent Data Reads; the CPU will read from whichever RAM (Display of FIFO/Sensor) which was last specified. If, indeed, the Display RAM was last specified, the Write Display RAM will, nevertheless, change the next Read location.

#### Display Write Inhibit/Blanking

 A
 B
 A
 B

 Code:
 1
 0
 1
 X
 IW
 IW
 BL
 BL

The IW Bits can be used to mask nibble A and nibble B in applications requiring separate 4-bit display ports. By setting the IW flag (IW = 1) for one of the ports, the port becomes marked so that entries to the Display RAM from the CPU do not affect that port.

If the user wishes to blank the display, the BL flags are available for each nibble. The last Clear command issued determines the code to be used as a "blank." This code defaults to all zeros after a reset. Note that both BL flags must be set to blank a display formatted with a single 8-bit port.

#### Clear



The C<sub>D</sub> bits are available in this command to clear all rows of the Display RAM to a selectable blanking code as follows:

```
0 X All Zeros (X = Don't Care)
1 0 AB = Hex 20 (0010 0000)
1 1 All Ones


Enable clear display when = 1 (or by C<sub>A</sub> = 1)
```

If the  $C_F$  bit is asserted ( $C_F = 1$ ), the FIFO status is cleared and the interrupt output line is reset. Also, the Sensor RAM pointer is set to row 0.

C<sub>A</sub>, the Clear All bit, has the combined effect of C<sub>D</sub> and C<sub>F</sub>; it uses the C<sub>D</sub> clearing code on the Display RAM and also clears FIFO status. Furthermore, it resynchronizes the internal timing chain.

## End Interrupt/Error Mode Set

Code:




For the sensor matrix modes this command lowers the IRQ line and enables further writing into RAM.


For the N-key rollover mode—if the E bit is programmed to "1" the chip will operate in the special Error mode.



## Two ways of Reading Keyboard entry

Polled mode





Interrupt mode

#Initialization

MOV AL,00

MOV [1901],AL

# Interrupt Routine to Read Keyboard

**PUSH SI** 

**PUSH AX** 

**PUSHF** 

MOV SI,1901

MOV [1901],40

**DEC SI** 

MOV AL,[SI]

AND AL,3F

MOV [2500],AL


**POPF** 

**POPAX** 

POP SI




## Status word





# Interfacing with 8086





## Summary

- Pin diagram of 8279
- Architecture
- Command word
- Modes of operation



## Check your understanding

• What are the different modes of operation of 8279?



# Thank you

