

PayMint Hardware Setup Guide

Introduction

Welcome to the PayMint Hardware Setup Guide. This manual will walk you through setting up your tablets, printers, and other hardware to ensure a smooth and reliable point-of-sale experience.

1. Tablet Setup

PayMint is designed to work on both Android and iOS tablets. For the best performance, we recommend: - **iPad:** iPad (9th gen or later), iPad Air, or iPad Pro. - **Android:** Samsung Galaxy Tab S6 Lite or later, or similar mid-to-high-range tablets.

1.1 iOS (iPad) Setup

To ensure your staff stays focused on the POS app, we recommend using **Guided Access**.

Enable Guided Access:

- Go to **Settings > Accessibility > Guided Access**.
- Toggle **Guided Access** to ON.
- Set a passcode (different from the device passcode if possible).

Install PayMint POS:

- Open the **App Store**.
- Search for "PayMint POS" and install.

Lock to App:

- Open PayMint POS.
- Triple-click the Top button (or Home button).
- Tap **Start** in the top right corner.
- The iPad is now locked to PayMint. To exit, triple-click and enter your passcode.

1.2 Android Tablet Setup

For Android, we recommend **App Pinning** or a dedicated **Kiosk Mode**.

Enable App Pinning:

- Go to **Settings > Security > Advanced > App Pinning**.
- Toggle it ON.

Install PayMint POS:

- Open **Google Play Store**.
- Search for "PayMint POS" and install.

Pin the App:

- Open PayMint POS.
- Open the Overview (Recent Apps) view.
- Tap the app icon at the top of the PayMint card.
- Select **Pin**.
- To unpin, press and hold Back and Overview buttons simultaneously.

2. Printer Configuration

PayMint supports receipt printers via **Network (LAN/WiFi)**, **Bluetooth**, and **USB**. We highly recommend **Epson** and **Star Micronics** printers for their reliability.

2.1 Recommended Models

- **Epson:** TM-T88VI, TM-m30II (Bluetooth/Network)
- **Star Micronics:** TSP143III (LAN/Bluetooth), mC-Print3

2.2 Network (LAN/WiFi) Setup - *Recommended*

Network printers are the most stable and allow multiple tablets to print to the same kitchen printer.

Connect Hardware:

- Plug the printer into power.
- Connect an Ethernet cable from your router/switch to the printer.
- Turn the printer ON.

Get IP Address:

- Wait for the "Ready" light.

- Hold the Feed button while turning the printer on (Self-Test), OR press the reset button on the back for 3 seconds (depending on model) to print a status sheet.
- Note the **IP Address** (e.g., 192.168.1.50).

DHCP vs Static IP:

- We recommend assigning a **Static IP** via your router settings to prevent the IP from changing after a power outage.

2.3 Bluetooth Setup

Good for single-tablet setups (e.g., Food Trucks).

Enable Pairing:

- Turn on the printer.
- Press and hold the "Pair" button on the back until the blue light blinks.

Pair Tablet:

- Go to tablet **Settings > Bluetooth**.
- Select the printer (e.g., "Star Micronics").
- If prompted for a PIN, try 0000 or 1234.

3. Connect Printer to PayMint POS

Once your hardware is ready, connect it within the app.

1. **Open PayMint POS** and log in.
2. Go to **Settings > Hardware**.
3. Tap **Add New Device**.

Select **Printer**.

- **Network:** Enter the IP Address you found earlier.
- **Bluetooth:** Select the paired device from the list.

Test Print:

- Tap the "Test Print" button.
- A small slip should print confirming the connection.

Assign Roles:

- Toggle "Receipts" (for cashier) or "Kitchen" (for order tickets).
- You can have one printer do both, or separate printers for each.

4. Troubleshooting

Printer Not Printing?

- **Check Paper:** ensure the roll is loaded correctly (paper should come from *under* the roll).
- **Check Connections:** Ensure the Ethernet cable clicks when inserted.
- **Verify IP:** Print a new status sheet. If the IP says 0 . 0 . 0 . 0, check your network cable/switch.
- **Same Network:** Ensure the tablet is on the **same WiFi network** as the printer. Guest networks often block device communication.

App Crashing or Slow?

- **Update App:** Check the App Store/Play Store for updates.
- **Restart Device:** A simple reboot clears memory cache.
- **Check Internet:** PayMint works offline, but syncs faster with a stable connection.

Need More Help?

Contact our dedicated support team: - **Email:** support@paymint.com - **Phone:** +1 (800) 555-0199 - **Live Chat:** Available in the Owner Portal 24/7