

EE REED EAST COAST CORPORATE SAFETY PROGRAM

3076 Centreville Road, Suite 210
Herndon, Virginia 20171
(703) 925-0700

Revised: February 2026

Table of Contents

1. Introduction	4
2. Safety Policy and Inspections	6
3. Drug and Alcohol Testing	11
4. Disciplinary Procedures	12
5. Office Safety	15
6. Common Areas	16
7. Emergency Action Plan	17
8. Material Handling and Ergonomics.....	19
9. Fire Prevention.....	23
10. Injury Treatment and Reporting.....	25
10.1 Return-To-Work Policy	31
11. Mobile Equipment	34
12. Hand and Power Tools.....	41
13. Cord and Plug Connected Electrical Equipment.....	47
14. General Electrical Procedures.....	49
15. Electric Arc Flash Protection	55
16. Ladders and Scaffolding.....	58
17. Fall Protection	63
18. Confined Spaces.....	69
19. Personal Protective Equipment	77
20. Respiratory Protection program.....	76
21. Lockout/Tagout	90
22. Hazard Communication / GHS	95
23. Hearing Conservation	101
24. Heat/Cold Stress.....	103
25. Trenching and Excavations	106
26. Crane Safety	113
27. Demolition Operations.....	120
28. Concrete Construction	123
29. Signs, Signals, and Barricades.....	127
30. Welding and Hot Work	129
31. Silica Exposure Control Plan	134
32. Fatigue Management	139
33. Standard Work Procedures	140

34. Environmental Spill Response.....142

35. Asbestos Awareness.....144

36. Signature and Acknowledgement.....136

1. Introduction

Welcome to EE Reed East Coast. It is the policy of this company that every employee is entitled to work under the safest possible conditions. With this in mind, every reasonable effort will be made in the interest of accident prevention and health preservation.

This comprehensive written safety program will be reviewed at least annually, or as conditions of the workplace or hazards change; whichever occurs sooner.

This company will endeavor to maintain a safe and healthy workplace. We will accomplish this by complying with local, state, and federal regulations and rigorous enforcement of our own safety policies. To provide a safe working environment, the necessary personal protective equipment will be provided to all employees.

It is our belief that accidents, which injure people, damage equipment, and destroy materials, cause needless personal suffering, inconvenience and expense. Employees are responsible for exercising maximum care and good judgment, and the practice of working safely belongs to all employees.

Within this company, we all share the safety responsibility, and everyone will be asked to participate in the company's loss-control effort. To ensure this will remain viable and visible, we have and will continue to institute specific programs for the safety and wellbeing of all employees. The door to our manager(s) is always open to you to discuss any violations of our programs. If you have any new ideas or other concerns about the program, please be sure to share those with us too.

Comments and questions can be directed to your onsite supervisor, safety representative or to the corporate office:

EE Reed East Coast 3076 Centreville Road
Suite 210
Herndon, Virginia 20171
(703) 925-0700

Our Safety Commitment

EE Reed East Coast is committed to providing and maintaining a safe and healthy working environment for all employees. All EE Reed East Coast employees are responsible for knowing, understanding, and observing all applicable safety regulations and safe work practices that will safeguard them, fellow employees, and the public.

In the case of accidents that result in injury, regardless of how insignificant the injury may appear, employees should immediately notify the appropriate supervisor. Such reports are necessary to comply with laws and initiate insurance and workers' compensation benefits procedures. The purpose of this safety program is to provide employees with general rules for safe work procedures. It is recognized that publication of this handbook alone will not ensure a safe work environment. That will be accomplished only through the cooperative efforts of

supervisors and employees working together to continuously promote safety awareness and safe work practices.

This program will be reviewed with all new employees of EE Reed East Coast at the time of hire through the new-hire orientation. No employees will be permitted to work without receiving training on the safety and health hazards they may face on jobsites. Additionally, period and refresher training may occur as new safety policies and procedures are established by EE Reed East Coast.

On-Site Orientation shall be conducted using supplied/approved EE Reed On-Site Orientation Power Point

- Site Specific Orientation shall be conducted for all employees of EE Reed who are new to that specific job site.
- Site Specific Orientation shall be conducted for all visitors, suppliers, vendors and sub-contractor employees before they are allowed on the job site.

Some of the best safety improvement ideas come from employees. Those with ideas, concerns, or suggestions for improved safety in the workplace are encouraged to raise them with a supervisor or bring them to the attention of the management team. Reports and concerns about workplace safety issues may be made anonymously if the employee wishes. All reports can be made without fear of reprisal.

Each employee is expected to obey safety rules and to exercise caution in all work activities. Employees must immediately report any unsafe condition to the appropriate supervisor.

We will review this safety program annually and perform a self-audit and evaluation to ensure that all identified hazards facing our employees are accounted for and addressed in our written procedures. If program deficiencies are identified in post-accident investigations, reviews of this program will be conducted more frequently. Employees will be retrained on any new or revised policies or procedures affecting their safety on the job site.

Additionally, all our subcontractors are required to abide by all applicable safety and health regulations on our jobsites, as well as ensure that their workers are trained in the hazards they may face on our jobsites prior to the commencement of work. This program endeavors to provide a comprehensive overview for EE Reed East Coast employees on the safety practices we expect to see on our jobsites. Subcontractors are wholly responsible for the safety of their workers on our jobsites.

2. Safety Policy and Inspections

General Safety Rules

Seatbelts must be worn at all times in vehicles and equipment where one is provided or as required by the manufacturer.

Employees, while on duty, must follow all state and local laws governing the use of vehicles including that employees must not use hand-held cell phones while driving.

Speed limit around the site is set for 10mph

Speed limit in buildings is set for 5mph

Employees will be responsible for paying for any civil or criminal citations issued while operating vehicles.

Hard hats with chin straps are required to be worn at all times whenever employees are on the jobsite.

- Hard hat must comply with ANSI Z89.1 and must have a EN397 or EN12492 designation. NOTE* Helmets with an EN397 must have a chin strap.
- Chin straps are to be worn at all times on site.
- Hard hat must be classified with C, G, or E (dependent on type of work)

Safety Glasses (ANSI Z87+) are required to be worn at all times on site.

ANSI Class II Reflective Shirt/Vest are required to be worn at all times whenever employees are on the jobsite.

Long pants are required to be worn on project site at all times.

Gloves Shall be worn during all work activities, and the glove type shall reflect the type of work being performed.

Any employee found not using their issued personal protection equipment, when required, will be subject to the disciplinary action and/or the penalty established by EE Reed East Coast.

Employee Involvement

By involving our employees in safety-related decisions, whether through suggestions from our safety committee or the results of an accident investigation, we have the advantage of tapping into our employees' knowledge and experience.

EE Reed East Coast encourages our workers to be involved in improving the safety and health of our jobsites. This is strongly supported by EE Reed East Coast management. Employees can participate in the company's goal of achieving zero-injuries on our jobsites by:

- Conducting weekly site inspections.
- Documenting daily safety observations.
- Analyzing routine hazards in each step of a job or process and preparing safe work practices or controls to eliminate or reduce exposure.
- Developing and revising the site safety and health rules.
- Training both current and newly hired employees.
- Providing programs and presentations at safety and health meetings or committee meetings.
- Conducting or assisting with accident/incident investigations.
- Reporting hazards.
- Fixing hazards within our control.

- Supporting fellow workers by providing feedback on risks and assisting them in eliminating hazards.
- Performing a pre-use or change analysis for new equipment or processes in order to identify hazards up front before use.

Stop Work Authority

All employees have the right to stop work if conditions are deemed unsafe. Work must not resume until hazards are eliminated.

All employees will be trained on how to identify, stop, and report unsafe acts or conditions to prevent injuries, property damage, and environmental incidents. This applies to all employees, subcontractors, temporary workers, and supervisors on company-controlled projects.

All employees have both the authority and responsibility to stop work when a hazard is identified and are protected from retaliation when doing so in good faith.

Training will be provided at hire and site safety orientation, and includes hazard recognition, Stop Work Authority (SWA), reporting procedures, and the non-retaliation policy. Supervisors will receive additional training on supporting stop work actions, conducting hazard assessments, implementing corrective actions, and reinforcing a strong safety culture. Refresher training will be conducted at least annually and following incidents, trend concerns, or regulatory changes.

Employees are responsible for remaining alert to hazards, stopping work in imminent danger situations, notifying supervision, and participating in corrective actions. Hazards must be reported through supervision, the Site Safety Manager, or company reporting systems and will be tracked to resolution.

All training will be documented per company record retention requirements. Failure to follow procedures may result in disciplinary action, while retaliation for good-faith reporting is strictly prohibited.

Safety Inspections & Hazard Identification Program

All competent persons identified by subcontractors on jobsites will have the training to recognize all known and presumed hazards on our jobsites and have the authority of EE Reed East Coast management to take prompt corrective actions to mitigate the hazards to prevent injuries to employees, subcontractors, or the general public.

EE Reed East Coast competent persons will periodically conduct jobsite safety audits to ensure compliance with EE Reed East Coast Corporate Safety Program and applicable state or federal OSHA regulations (these audits/inspections should be done on a weekly basis and documented on ProCore). Imminent danger hazards or noncompliance identified during an audit will be eliminated or corrected immediately. Safety inspections may also lead to employee disciplinary actions as discussed previously in this written program.

Evaluation of Hazards from Other Work Activities

In addition to evaluating hazards directly related to a subcontractor's scope of work, competent persons shall evaluate additional hazards created by unrelated activities occurring within the

same general work area.

Because multiple trades frequently operate simultaneously on construction projects, hazard identification shall include, but is not limited to:

- Overhead work creating struck-by or falling object hazards
- Adjacent hot work impacting nearby combustible materials or personnel
- Operation of mobile equipment in proximity to pedestrian workers
- Energized electrical systems affecting other trades
- Confined space activities impacting surrounding areas
- Silica-generating operations affecting nearby workers
- Crane operations, suspended loads, or rigging activities
- Changes in access/egress due to other subcontractor operations

Competent persons must coordinate with other trades and supervision to:

- Communicate identified cross-trade hazards
- Establish controls such as barricades, scheduling adjustments, engineering controls, or administrative controls
- Conduct joint pre-task planning when overlapping operations exist
- Suspend work when necessary until hazards are mitigated
-

No work shall proceed when overlapping activities create an unmitigated hazard to workers, subcontractors, or the public.

A job hazard risk assessment will be conducted before each job by reviewing the scope of work and cross-referencing the Job Hazard Analysis' and safety manuals provided by all sub-contractors before work starts. Deficient items will be corrected before sub- contractors mobilize on site. (These items will be included in the trade partners Safe Start Packets. Other documentation that needs to be turned in addition to the JHA and Safety manuals are:

- Competent Person Certification (OSHA 30hr and 1st aid and CPR certification)
- Safety Data Sheets
- All employees' certifications such as forklift, aerial lift, scissor lift, rigging, etc.
- Written Silica Control Plan
- Fall rescue Plan

Roles and Responsibilities

Executive Management

- Ensure sufficient resources are allocated to implement and maintain the Safety Inspection and Hazard Identification Program.
- Grant authority to competent persons to take corrective action, including stopping work when necessary.
- Enforce accountability at all management levels for correcting identified hazards.

Project Managers

- Ensure subcontractors submit required pre-mobilization safety documentation.
- Verify that hazard assessments are completed prior to work commencement.

- Coordinate with Superintendents and Safety Managers to ensure identified deficiencies are corrected.
- Support enforcement actions, including suspension of work for non-compliance.

Site Superintendents

- Ensure weekly inspections are conducted and properly documented.
- Verify subcontractor competent persons are designated and present when required.
- Immediately address hazards identified during inspections.
- Ensure corrective actions are implemented and tracked to completion.
- Communicate inspection findings during safety meetings and daily coordination.

Safety Manager / Safety Department

- Develop and maintain inspection protocols and documentation procedures.
- Conduct and/or assist with weekly audits and hazard assessments.
- Review submitted subcontractor documentation for compliance prior to mobilization.
- Maintain inspection records in accordance with company retention policies.
- Track corrective actions and ensure timely closure.
- Provide guidance on regulatory compliance and hazard mitigation strategies.

Competent Persons (EE Reed East Coast and Subcontractor)

- Conduct frequent and regular inspections of jobsite conditions, equipment, and work practices.
- Identify known and predictable hazards.
- Take immediate corrective action to eliminate hazards.
- Stop work when imminent danger conditions exist.
- Ensure required documentation (JHAs, certifications, plans) is current and site-specific.
- Participate in incident investigations and recommend preventive measures.

Subcontractors

- Submit all required safety documentation prior to mobilization.
- Designate qualified competent persons for their scope of work.
- Conduct task-specific hazard analyses and communicate controls to their employees.
- Correct deficiencies identified during inspections immediately.
- Cooperate fully with audits, documentation reviews, and corrective action processes.

Employees

- Participate in pre-task planning and review JHAs prior to beginning work.
- Report unsafe conditions immediately to supervision or the Safety Department.
- Cooperate during inspections and audits.
- Follow all corrective measures implemented as a result of inspections

Third-Party Safety Consultants

EE Reed East Coast contracts with SEE, Inc. of Keedysville, MD to perform routine site safety inspections of our jobsites. SEE, Inc. works alongside EE Reed East Coast supervisors to

ensure a safe and healthy workplace for all employees onsite.

In the event a hazard is identified, and if it is not immediately able to be abated, SEE, Inc. will draft a written inspection report outlining their findings and providing abatement recommendations to EE Reed East Coast and/or the responsible subcontractor.

From time to time, representatives from our insurance company may also walk jobsites to provide risk management and other safety recommendations.

Subcontractor Jurisdictional Compliance

As a General Contractor, the Company requires all subcontractors and lower-tier subcontractors to comply with applicable federal, state, and local regulatory requirements, including OSHA (29 CFR 1910 and 1926), OSHA-approved State Plans, building codes, environmental regulations, and all other jurisdictional requirements governing the project. Where requirements differ, the more stringent standard shall apply.

Subcontractors must meet prequalification requirements prior to contract award, including submission of safety programs, licensing, training documentation, insurance, and performance history. Contract agreements shall require adherence to all regulatory and Company safety requirements.

Before mobilization, subcontractors shall complete site-specific orientation, submit required hazard analyses, provide proof of training and competent person designations, and comply with project-specific regulatory provisions.

The Company will monitor subcontractor compliance through site inspections, audits, documentation reviews, and coordination meetings. Identified deficiencies must be corrected immediately. The Company reserves the right to suspend work, require corrective action, remove personnel, or terminate contracts for non-compliance.

Subcontractors are required to immediately report all incidents, injuries, environmental events, and regulatory inspections to the Company and cooperate with investigations.

Subcontractor compliance performance will be considered in ongoing project evaluations and future prequalification decisions.

3. Drug and Alcohol Testing

As a condition of employment, all EE Reed East Coast employees/applicants will be required to undergo breath alcohol testing and/or urine drug tests upon request by EE Reed East Coast management. Those current employees or applicants who refuse consent to testing will be a cause for dismissal or result in a withdrawn contingent offer of employment.

During the administration of this policy, EE Reed East Coast may perform the following types of drug and/or alcohol tests:

Pre-Employment Testing

As a condition of employment, any candidate who is extended a conditional offer of employment may be required to take and pass a drug screening test. Failure of an individual to pass this screening shall result in the withdrawal of the conditional offer of employment. Additionally, employees will be required to take drug tests when required by state or federal regulations, such as the U.S. Department of Transportation Drug and Alcohol Testing regulations.

Random Testing

All employees are subject to unannounced random testing throughout the year, with selections made through a neutral valid method to ensure fairness and compliance with applicable federal state, and local regulations. Employees selected for testing must report immediately to the designated collection site. Refusal to test, failure to report, or tampering with a test will be treated as a violation of Company policy and may result in disciplinary action up to and including termination.

Post-Accident Testing

Employees who are on-duty and operating a vehicle/equipment, shall be required to immediately submit to both drug and alcohol testing when reasonable suspicion exists which would lead a reasonable person to believe that the operator caused or likely contribute to an accident. Additionally, drug and alcohol testing may be required for severe accidents if a vehicle/equipment operator is involved in an accident which results in any of the following:

- There is a fatality; or
- Injury that requires medical treatment; or
- A citation has been issued to the operator of the vehicle/equipment.

Reasonable Suspicion Testing

The basis for making a determination on when to conduct a reasonable suspicion test is drawn from specific objective and articulable facts and reasonable inferences drawn from those facts in light of experience. Incidents which result in an employee injury may be a cause for reasonable suspicion drug testing if impairment could have caused or contributed to the incident occurring.

Employees who are required to undergo a reasonable suspicion test will not be authorized to return to work until cleared to do so by EE Reed East Coast management.

Upon reasonable suspicion, the supervisor will immediately contact the accused employee and advise the employee not to operate any vehicle.

4. Disciplinary Procedure

Each employee is expected to obey safety rules and to exercise caution in all work activities. Employees must immediately report any unsafe condition to the appropriate supervisor. Employees who violate safety standards, who cause hazardous or dangerous situations, or who fail to report or remedy such situations may be subject to disciplinary action, up to and including dismissal from service.

You should be aware that there are certain major offenses, which may result in an immediate penalty of probation, or suspension subject to discharge, or discharge, without any prior counseling.

Reference the Disciplinary Action below for more details.

Disciplinary Action

Purpose

The purpose of this document is to outline a clear, fair, and consistent Progressive Disciplinary Action Process for addressing safety violations and noncompliance with EE Reed East Coast policies and procedures. This process ensures that all incidents are handled in a manner that promotes accountability, reinforces training, and supports continuous improvement in our safety culture.

Background

EE Reed East Coast maintains a comprehensive Safety Policy that is updated annually and serves as our overarching safety framework. All employees and subcontractor personnel are required to attend Site Orientation, which includes:

Review of company safety policies and procedures.

- Client-specific rules and requirements applicable to the project.
- Expectations for conduct, communication, and accountability.

While these orientations establish our standards, a Progressive Disciplinary Action Plan provides the structure for addressing violations when they occur. This process applies to both workers and supervisors, with expectations and consequences appropriate to their respective roles and responsibilities.

Philosophy

The goal of this process is not punishment but prevention, education, and accountability. Each disciplinary step should include a corrective component, such as training, counseling, or coaching, to ensure understanding and prevent recurrence.

We recognize the difference between:

- A lack of knowledge or misunderstanding of the rules, and
- A willful disregard of established safety practices.

For example:

- A worker unaware of a specific rule may receive retraining and a verbal warning with his/her foreman notified.
- A worker who skips fall protection “because they were rushing” may receive a written warning and as well as foreman receive the same written warning reinforcing that safety always takes precedence over production speed.

Documentation and Communication

All disciplinary actions - verbal or written - must be documented. Documentation should include:

- Description of the violation.
- Corrective actions or training assigned.
- Acknowledgment by the involved employee.
- Copies provided to the subcontractor’s Project or Field Team and the EE Reed project team for transparency.

Escalated disciplinary measures (e.g., suspensions or terminations) should be reviewed with the VP/General Superintendent and, if appropriate, company ownership after each encounter past the verbal warning.

Remember: From a compliance perspective - whether OSHA, legal, or insurance - “if it isn’t documented, it didn’t happen.”

Progressive Disciplinary Action Flow

For Workers & Supervisors (i.e. foreman, superintendents)

Infraction Type	Example	Action
Minor (first occurrence)	Missing PPE, improper housekeeping	Verbal warning and notify foreman, document via email for tracking.
Minor (repeat)	Repeated PPE violations	Written warning & foreman notified.
Serious	Unsafe behavior creating potential injury risk (e.g., failure to tie-off at heights)	Immediate written warning of worker & foreman (& possible suspension).
Major	Fighting, substance abuse, theft, or other zero-tolerance actions	Immediate termination based on EHS teams discretion

Conclusion

The Progressive Disciplinary Action Process reinforces our shared responsibility for maintaining a safe, compliant, and respectful work environment with our trade-partners. Consistent application of this process ensures fairness, transparency, and continuous improvement across all EE Reed East Coast projects.

Written Warning

The document below must be used when issuing a disciplinary action to ensure proper documentation.

Written Warning – Safety Violation

Employee Name:

Date of Violation:

Employer (Subcontractor):

Date of Notice:

Project Name:

Issued By (EE Reed Employee)

1. Description of the Violation

On _____ the following safety violation was observed:

(Clearly describe what occurred, including the task being performed, location, and specific safety requirement that was not followed. Be factual and objective.)

This behavior is a violation of EE Reed/Client safety expectations, site-specific safety requirements, and/or applicable OSHA standards.

2. Corrective Actions / Training Assigned

To address this violation and prevent recurrence, the following corrective actions are required:

- Corrective action #1

- Corrective action #2

- Deadline for Re-Training: _____

Failure to complete the assigned corrective actions or any repeat violations may result in further disciplinary action, up to and including removal from the project site.

3. Employee Acknowledgment

My signature below acknowledges that this safety violation has been reviewed with me. I understand the expectations moving forward and the potential consequences of future violations. My signature does not necessarily indicate agreement.

Employee Signature: _____

Date: _____

4. Supervisor / EE Reed Representative

Name & Title:

Signature: _____

Date: _____

5. Office Safety

General Office Safety

All files, desks, and table drawers must be kept closed when not in use. Do not overload top file cabinet drawers. Never open more than one drawer at a time as the cabinet could tip over. Do not use chairs, desks, tables, or other office furniture as makeshift ladders. Care should be exercised when using scissors, paper cutters, razor blades, and other equipment with sharp edges. Keep blades of paper cutters closed when not in use. Keep your hands clear of moving parts on office equipment. To prevent back problems, use proper ergonomics in your workstation. Take periodic breaks to avoid eyestrain when using computer terminals. Get assistance before attempting to move heavy office furniture or equipment.

Extension Cords

Use only UL listed extension cords of appropriate gauge for electrical load. Examine both the cord and connection carefully before using it. Protect cords against contact with oil, hot surfaces, chemicals, and other liquids. Replace any extension cords that are damaged. Extension cords shall not be used in place of permanent wiring.

Employee Conduct

Each employee bears primary responsibility for ensuring his or her own personal safety. Employees are responsible for learning and obeying the safety rules and wearing all required personal protective equipment. Each employee shall carefully study all the Safety Rules and become familiar with the rules as they pertain to their job. Employees must notify their supervisor immediately of any unsafe conditions or actions. EE Reed East Coast will take every means possible to reduce and/or eliminate the safety risk. Any unsafe conditions or acts shall be dealt with immediately. Employees are expected to report to work in healthy, alert physical condition. Employees who are intoxicated or drug-impaired are potential hazards to themselves and their co-workers.

Workplace Violence

No employee should feel threatened or that his/her personal safety is in danger because of the actions or speech of employees/civilians/contractors. In order to minimize the chance of workplace violence, EE Reed East Coast advocates that all employees promote positive behavior and lead by example, by treating everyone with respect and dignity. If workplace violence does happen, the employee must immediately contact their supervisor. In cases of extreme emergency, contact Law Enforcement by calling 9-1-1 if necessary.

6. Common Areas

Building Entrances and Walkways

- All building entrances, pedestrian walkways inside buildings, restrooms, work areas, and storage areas shall be:
 1. Kept free from refuse, slippery and wet substances, portable equipment, tools, supplies, electric extension cords, and any other tripping hazard.
 2. Provide adequate lighting. In areas without adequate lighting, use a flashlight or electrical “trouble” light. Never use matches or an open flame for lighting.
 3. Maintained at a safe level of cleanliness.
- Be alert to potentially slippery conditions at building entrances and stairways. Always use handrails on stairs.
- Use caution when pushing open a door to avoid injuring people opposite the door. Approach a door that opens towards you with caution.
- Keep outdoor pedestrian walkways clean and clear of obstructions and debris.
- In inclement weather, wear footwear that provides good traction.
- If a spill or slippery conditions exist, apply an absorbent material immediately to oil, grease, and other flammable materials, then clean the floor as soon as possible.

7. Emergency Action Plan

This plan is designed to inform and prepare employees for various types of emergencies that may occur on the job site. The goal is to minimize risk, ensure prompt response, and provide effective care in the event of an emergency.

Regulatory Compliance

In accordance with OSHA 29 CFR 1926.50(c), EE Reed East Coast requires that trained and certified personnel are available to provide emergency first aid and CPR on all job sites and at our main office.

Medical Emergencies:

Minor Injuries

If a situation arises that may require minor first aid:

1. Immediately notify your supervisor or any nearby employee.
2. The injured employee, if able, must report directly to their supervisor.
3. The supervisor will contact a certified first aid responder to assess the injury.
4. The supervisor is responsible for ensuring a timely incident report and investigation is completed.

Major Injuries

1. Notify the nearest supervisor immediately
2. Do not move the injured person if they are:
 - Unconscious
 - Have a suspected head, neck, back, or spinal injury
 - Have a visible fracture or severe trauma
3. Check for responsiveness and breathing:
 - Open airway and provide rescue breathing if necessary
 - Begin CPR and use AED if needed and available
4. Call 911 or emergency medical services as needed
1. Communicate with the emergency services (911), giving the full description of the victim, the situation, the location and the victim's condition.
2. Control bleeding using pressure and elevation techniques.
3. Treat for shock by keeping the person calm, warm, and still
4. Assign someone to meet the ambulance crew at the entrance and guide them directly to the scene
5. Stay with the victim until the medical emergency has passed or the victim is transported.

Emergency Medical transportation

In the event the injured person needs additional medical attention, the preferred method of emergency transport is the local ambulance. Transportation by personal vehicle should be avoided except for the most minor injuries.

Examples of injuries requiring emergency transport by the rescue squad are:

1. A head, neck or spine injury.
2. Injuries/illnesses involving the respiratory or circulatory (heart) systems.
3. Injuries with severe bleeding and if the injured person shows signs of shock or disorientation.

Injured persons are not allowed to transport themselves from the jobsite to obtain external medical evaluation/treatment, except in minor sprain/strain injuries where the employee is completely un-medicated and is willing to drive themselves home or to doctor's treatment.

8. Material Handling and Ergonomics

Ergonomics

The purpose of this ergonomics program is to prevent the occurrence of work-related musculoskeletal disorders by controlling or eliminating the risk factors which cause them. This program ensures that all affected employees are aware of job-related risk factors and provides information and solutions to elevate them. EE Reed East Coast promotes continuous improvement for the efficiency, comfort, and well-being of all employees through a team effort of management and employee involvement.

In a more practical sense, ergonomics is the science of human comfort. When aspects of the work or workplace exceed the body's capabilities, the result is often a musculoskeletal disorder (MSD). To help avoid MSDs, work demands should not exceed the physical capabilities of the worker. The most common, recognizable name for MSDs is cumulative trauma disorders or CTDs. Whatever the name used, these injuries belong to a family or group of wear and tear illnesses that can affect muscles, nerves, tendons, ligaments, joints, cartilage, blood vessels or spinal discs of the body. MSDs do not include slips, trips and falls, cuts, motor vehicle accidents or other similar accidents; although a close look at the reasons for acute injuries often reveals design problems that can be corrected.

Triggers for a worksite evaluation:

- When an employee reports an MSD sign or symptom.
- Jobs, processes, or work activities where work-related ergonomic risk factors have been identified which may cause or aggravate MSDs.
- Any change of jobs, tasks, equipment, tools, processes, scheduling, or changes in work shift hours (for example, going from a traditional 5-day, 8-hour shift to a compressed 4-day, 10-hour shift).
- When a safety walk-through or scheduled inspection or survey has uncovered potential MSD hazard.

Work-related risk factors to be considered in the evaluation process include, but are not limited to:

- Physical risk factors including force, postures (awkward and static), static loading and sustained exertion, fatigue, repetition, contact stress, extreme temperatures, and vibration.
- Administrative issues including job rotation/enlargement, inadequate staffing, excessive overtime, inadequate or lack of rest breaks, stress from deadlines, lack of training, work pace, work methods, and psychosocial issues.
- Environmental risk factors including noise, lighting, glare, air quality, temperature, humidity, and personal protective equipment and clothing.
- Combination of risk factors such as, but not limited to, highly repetitive, forceful work with no job rotation or precision work done in a dimly lit room.

Worksite evaluations will be scheduled based upon the following:

- Any job, process, operation, or workstation which has contributed to a worker's current MSD.

- A job, process, operation, or workstation that has historically contributed to MSDs.
- Specific jobs, processes, operations, or workstations that have the potential to cause MSDs.

Various methods will be used to evaluate problem jobs including:

- Walk-through and observations
- Interviews
- Surveys and questionnaires Checklists
- Detailed worksite evaluations

Control of the Ergonomic Risk Factors:

EE Reed East Coast will take steps to identify ergonomic risk factors and reduce hazards by using a five-tier hierarchy of controls:

1. **Elimination.** The complete and permanent removal of a hazard from the workplace so that exposure is no longer possible. Elimination provides the highest level of protection and requires no ongoing behavioral compliance.
2. **Substitution.** The replacement of a hazardous material, process, or condition with an alternative that presents a lower level of risk. Substitution shall not introduce new hazards equal to or greater than the original condition.
3. **Engineering controls.** The most desirable and reliable means to reduce workplace exposure to potentially harmful effects. This is achieved by focusing on the physical modifications of jobs, workstations, tools, equipment, or processes.
4. **Administrative controls.** This means controlling or preventing workplace exposure to potentially harmful effects by implementing administrative changes such as job rotation, job enlargement, rest/recovery breaks, work pace adjustment, redesign of methods, and worker education.
5. **Personal protective equipment (PPE).** Although not recognized as an effective means of controlling hazards and does not take the place of engineering or administrative controls, there are acceptable forms of PPE, which include kneepads and anti-vibration gloves.

Every employee of EE Reed East Coast is responsible for conducting himself/herself in accordance with this policy and program. All employees will:

- When provided, use the appropriate tools, equipment, parts, materials, and procedures in the manner established by managers and supervisors.
- Ensure that equipment is properly maintained in good condition and when not, report it immediately.
- Provide feedback to supervisors regarding the effectiveness of design changes, new tools or equipment, or other interventions.
- Attend ergonomics training as required and apply the knowledge and skills acquired to actual jobs, tasks, processes, and work activities.
- Report MSD signs or symptoms and work-related MSD hazards to the supervisor as early as possible to facilitate medical treatment.
- Take responsibility for their personal health and safety.

Lifting Materials

- Do not attempt to carry a load that may jeopardize your health or safety. When possible, split it into two loads or receive assistance from a co-worker or use mechanical assistance.
- Do not carry objects that will obstruct your vision.
- Always apply proper lifting techniques, whether working alone, as a team, or with the aid of mechanical assistance.
 1. Keep your feet close to the load and parted for balance.
 2. Keep your back straight.
 3. Keep the load being lifted close to your body.
 4. Lift the object with a secure grip.
 5. Tuck your chin in.
 6. Use your leg muscles to do the lifting; not your back.
- Where material handling equipment is used, keep areas clear and in good repair.
- When there is a change of elevation, use ramps, blocks or grading to ensure safe movement.

Storage

- Materials stored in tiers must be stacked, racked, blocked or interlocked. This prevents objects from sliding, falling or collapsing.
- Don't place stored materials within 6 feet of hoist way or floor openings.
- Keep storage areas free from accumulated materials that cause tripping, fires, or explosions, or that may contribute to harboring rats and pests.

Daily Inspections

1. Inspect slings each day before use or when service warrants.
2. Remove from service if slings are damaged or defective, always look for the following:
 - Pitting
 - Splitting
 - Excessive wear
 - Chain-stretch
 - Kinking or bird-caging
3. Daily inspection checklist must be completed to verify that material hoist is operating safely.

Disposal of Waste

- Enclosed chute must be used when dropping materials more than 20 feet outside of building.
- Connect the chutes to construction waste containers.
- Set up barricade to enclose the drop area.
 1. Required if dropping through holes in floors without chutes.
- Remove all scrap lumber, waste material, and rubbish from the immediate work area as work progresses.

- Keep all solvent waste, oily rags, and flammable liquids in fire resistant covered containers until removed from worksite.
- Keep portable fire extinguishers available onsite.

9. Fire Prevention

General Guidelines

- Smoking is prohibited in areas where flammable or combustible liquids are used or stored.
- Smoking is allowed only in specific designated areas.
- Fire exits will be kept clear and shall not be locked from the inside so as not to impede proper evacuation.
- Smoking is prohibited during the workday other than breaks if the jobsite has designated smoking areas.
- Smoking is prohibited in all company owned equipment.

Construction Site Specific OSHA Requirements

- All firefighting equipment provided by EE Reed East Coast shall be conspicuously located.
- All firefighting equipment must be periodically inspected and maintained in operating condition; immediately remove all defective equipment.
- Ensure there is temporary or permanent water supply of sufficient volume, duration and pressure to operate the firefighting equipment when there is an accumulation of combustible materials.

NOTE: Every effort will be made to ensure there is not an accumulation of combustible materials on construction jobsite. At the end of each shift, scrap and combustibles will be properly stored or disposed of in onsite refuse containers.

- A fire extinguisher, rated not less than 2A, shall be provided for each 3,000 square feet of the protected building area.
- Travel distance from any point of the protected area to the nearest fire extinguisher shall not exceed 100 feet.
- One or more fire extinguishers, rated not less than 2A, shall be provided on each floor. In multistory buildings, at least one fire extinguisher shall be located adjacent to stairway.
- A fire extinguisher, rated not less than 10B, shall be provided within 50 feet of wherever more than 5 gallons of flammable or combustible liquids or 5 pounds of flammable gas are being used on the jobsite.

Fire Extinguishers

- Fire extinguishers will be prominently displayed, labeled for usage, and always kept clear for easy access.
- Know the locations of fire extinguishers and how to use them.
- After using an extinguisher, report it immediately to your supervisor so a replacement may be obtained or recharged.
- NEVER return a partially used extinguisher to its storage place.
- All extinguishers, in both vehicles and buildings, will be inspected annually by a qualified person.

- A company designee will inspect department extinguishers on a monthly basis to ensure extinguishers are present to determine if they have been used and to inspect gauges and tubing.
- Do not use water-type extinguishers on electrical fires because of the danger of electrocution. They are intended for use on Class A (paper, wood) fires only.
- Use Class D fire extinguisher on combustible metals only.
- An inspection log shall be kept at the jobsite trailer and shall have visible the tag indicating the most recent annual inspection performed.

Refueling Protocols

- Avoid refueling gasoline powered equipment in enclosed areas, particularly near equipment like generators and chop saws.
- Allow equipment to cool before refueling.
- Use a funnel when refueling generators and other equipment, when applicable.

Storage of Flammable or Combustible Materials

- No storage of flammable or combustible materials is allowed in furnace rooms, boiler rooms, or any other unauthorized areas.
- Drums of flammables must be grounded, and a bond wire must be used to electrically interconnect the drum and container used in dispensing liquid.
- Oily and greasy rags must be put in a metal container with a self-closing lid.
- Gasoline must not be used for cleaning purposes.
- Cleaning solvents with flammable properties must be kept in approved safety containers, labeled and used in accordance with manufacturer's instructions.
- Secondary containers must be labeled with the name of the chemical, mixture, or element contained therein. It is also a best practice to label secondary containers with HMIS labels.

OSHA/DOT Gas Can Requirements

OSHA 29 CFR 1926.152(a)(1) states that "Only approved containers and portable tanks shall be used for storage and handling of flammable and combustible liquids. Approved safety cans or Department of Transportation approved containers shall be used for the handling and use of flammable liquids in quantities of 5 gallons or less. We will require all gas cans onsite to be an approved, closed container, of not more than 5 gallons in capacity, have a flash arresting screen, spring closing lid and spout cover and so designed that it will safely relieve internal pressure when subject to fire exposure.

10. Injury Treatment and Reporting

Jobsite injuries must be reported immediately to: Jorge Castro
571-296-9059
jcastro@eereedeast.com

Immediate Actions

It is the policy of EE Reed East Coast to provide employees with proper and timely medical treatment for any work-related injuries. In case of severe or life-threatening injuries, call 911 immediately. Follow-up treatment arrangements must be made with an authorized company physician.

First Report of Injury forms must be submitted by the Project Superintendent or Safety Representative to Jorge Castro as soon as reasonably practicable and no later than the same day the accident takes place.

The Superintendent or Project Manager must collaborate with the Safety Manager to complete the EE Reed Accident/Near Miss Report. Submit the preliminary report to Jorge Castro as soon as possible on the same day of the incident.

Reporting Injuries

An injured employee shall immediately, on the occurrence of an accident, or as soon as practicable thereafter, notify his or her foreman and/or supervisor of the accident and/or injury.

All incidents/accidents involving personnel injury and/or property damage are to be reported to EE Reed East Coast EHS Department. Timely reporting of all claims of injury or property damage is essential to filing insurance claims

Notification Chain:

1. The injured employee must notify their supervisor or foreman immediately.
2. The Superintendent or On-Site Lead notifies the General Superintendent.
3. The Project Manager notifies the Senior PM and Project Executive.
4. The Project Executive notifies the Senior Vice President (SVP) and Chief Operating Officer (COO).
5. The COO will inform Doug Peterson.
6. The PM or SPM must inform the client.

Incident Report- Procore

After completing initial reporting steps, incidents must be documented in Procore:

1. Navigate to the Incidents tool.
2. Add Injury/Illness under 'Add Record'.
3. Complete details including location, people, description, photos, body parts, treatment, and return-to-work info.
4. Enter provider details, facility, and hospitalization status.

5. Attach follow-up records including training, observations, or RCA.
6. Maintain and update incident status.

Medical Treatment Instructions

Injury/Incident - the supervisor, safety manager or an authorized company representative whose employees were injured will provide the injured employee with instructions for obtaining necessary medical treatment.

EE Reed East Coast employees who, while injured during their employment, will be instructed to seek medical treatment at the closest Urgent Care Center.

Injured employees will be directed to the nearest Urgent Care Center or, if the severity warrants, the Emergency Room. All follow-up care must be coordinated through authorized company physicians. Contact information for doctors, hospitals, and ambulance services will be clearly posted on all job sites.

Emergency Room Treatment

The severity of an injury may require that an employee visits the nearest hospital emergency room for treatment. If this occurs and follow-up treatment is necessary, arrangements must be made to have the employee visit an authorized company physician.

A telephone list of doctors, nearest hospitals and ambulance services will be conspicuously posted on all jobsites.

First Aid Policies & Procedures

All subcontractors are required to have at least (1) one certified First Aid and CPR provider on site while they are working. For subcontractor crews that are working with less than (10) ten people on the site, this requirement shall be waived.

First aid equipment, CPR barrier masks, and Bloodborne Pathogen Control Kits shall be made available on each job site.

All EE Reed East Coast jobsites will be equipped with a first aid cabinet regardless of the number of personnel. If there are more than 50 people on the site, a second cabinet shall be provided for the site.

All exposures to body fluids including blood, and urine shall be reported to the site foreman immediately, and a First Report of Injury form and exposure report shall be completed.

All employees who are trained in first aid and CPR are required to provide care to the best of their ability for their co-workers in the event of an injury.

First Aid Cases

Employees will report all injuries, no matter how slight they may appear, to the job superintendent. These cases will be promptly treated and recorded in the following manner:

1. Name, age and address of injured employee.
2. Date and time of accident.

3. Nature of injury.
4. Brief description of accident.
5. Brief statement by supervisor concerning method of preventing similar type accident.

First Aid Kits are stocked with adequate supplies of first aid materials and personal protective equipment in compliance with the provisions of the Occupational Exposure to Bloodborne Pathogens standard 29 CFR 1910.1030(d)(3).

Subcontractors must ensure that medical personnel are easily accessible to workers. At least one person on jobsites will be trained to provide first aid if the jobsite is not close to a hospital or clinic.

Each job site must have one certified First Aid/CPR provider per subcontractor (unless the crew is under 10 people). Each site will be equipped with at least one first aid cabinet; sites with over 50 personnel require two. Bloodborne Pathogen Control Kits and CPR barrier masks must be available. Any bodily fluid exposure (blood, urine) must be reported immediately and documented. First aid must be rendered by trained employees to the best of their ability. All supplies must comply with OSHA's 29 CFR 1910.1030(d)(3).

Bloodborne Pathogens

EE Reed East Coast is committed to providing a safe and healthy work environment for our entire staff.

Bloodborne Pathogen – pathogenic microorganisms that are present in human blood and can cause disease in humans. Pathogens include but are not limited to, hepatitis B virus (HPV) and human immunodeficiency virus (HIV).

Universal Precautions – an approach to infection control. According to this philosophy all human blood and bodily fluids are treated as if known to be infectious for bloodborne pathogens.

All employees using PPE must observe the following precautions:

1. Wash hands immediately or as soon as feasible after removing gloves or other PPE.
2. Remove PPE after it becomes contaminated and before leaving the work area.
3. Used PPE may be disposed of in (List appropriate containers for storage, laundering, decontamination, or disposal.)
4. Wear appropriate gloves when it is reasonably anticipated that there may be hand contact with blood or OPIM, and when handling or touching contaminated items or surfaces; replace gloves if torn, punctured or contaminated, or if their ability to function as a barrier is compromised.
5. Utility gloves may be decontaminated for reuse if their integrity is not compromised; discard utility gloves if they show signs of cracking, peeling, tearing, puncturing, or deterioration.
6. Never wash or decontaminate disposable gloves for reuse.
7. Wear appropriate face and eye protection when splashes, sprays, spatters, or droplets of blood or OPIM pose a hazard to the eye, nose, or mouth.
8. Remove immediately or as soon as feasible any garment contaminated by blood or OPIM, in such a way as to avoid contact with the outer surface.

Accident Reporting

OSHA Reporting Requirements

Beginning January 1, 2015, employers must now report all in-patient hospitalizations of 1 or more employees, and any amputations or loss of eye(s) to OSHA within 24 hours of the event. Additionally, employers must report fatalities to OSHA within 8 hours of event occurring. EE Reed East Coast will follow Federal OSHA's reporting requirements, and all employees should be familiar with this section. While all employees have the right to a safe and healthful workplace, EE Reed East Coast management should be the ones to call OSHA in the event of a reportable injury occur.

1. For injuries meeting the above criteria which occur in Maryland, contact Maryland OSHA at 410-527-4447 to report such cases.
2. For injuries meeting the above criteria which occur in Virginia, contact Virginia OSHA at 804-321-2327 to report such cases.
3. For injuries meeting the above criteria which occur in Washington DC, contact Federal OSHA at 1-800-321-6742 to report such cases.
4. For injuries meeting the above criteria which occur in Georgia, contact Federal OSHA at 1-800-321-6742 to report such cases.
5. For injuries meeting the above criteria which occur in South Carolina, contact SC OSHA at 803-321-6742 to report such cases.

Accident Investigations, Reports and Logs: Site supervisor or member of management will conduct accident investigations when the accident involves lost time or property damage.

- A written report will be maintained on each accident, injury or on the-job illness requiring medical treatment. A record of each such injury or illness recorded on OSHA Log and Summary of Occupational Injuries Forms 300A according to the instructions; and Supplemental records of each injury are maintained on OSHA Form 300. Every year a summary of all reported injuries or illness is posted no later than February 1 through April 30, on OSHA Form 300A. These records are maintained for five years from the date of preparation.

If your condition requires you to leave your job, you must present an acceptable, verifiable and objective written statement from a physician when you return to work, stating that you are well and able to resume your job duties. EE Reed East Coast reserves the right to verify any/all doctor's information/documentation.

Injured employees must bring the following upon returning to work: copies of all medical receipts for treatment, copies of bills, and a written return to work order from their treating physician.

Any injured employee who is on either light duty, restricted duty, or off work status due to a work-related injury shall stay in weekly contact with their supervisor and/or human resources designee.

Employees must accept any modified or light-duty offered to them as a condition of employment. In limited situations, federal law may supersede this requirement.

Medical Records Retention and Confidentiality

All medical and exposure records generated as part of injury treatment, post-accident response, medical surveillance, respirator evaluations, audiometric testing, exposure monitoring, drug and alcohol testing, return-to-work evaluations, and workers' compensation cases shall be maintained in compliance with applicable federal and state regulations.

The Company complies with:

- OSHA 29 CFR 1910.1020 – Access to Employee Exposure and Medical Records
- 29 CFR 1926 Construction Standards
- OSHA-approved State Plan requirements (where applicable)
- HIPAA Privacy and Security Rules
- Applicable state medical privacy and retention laws

Where state requirements are more stringent than federal requirements, the more stringent requirement shall apply.

Record Retention

Unless otherwise required by state law:

- Employee medical records shall be retained for the duration of employment plus thirty (30) years.
- Employee exposure records shall be retained for at least thirty (30) years.
- OSHA 300, 300A, and 301 records shall be retained for five (5) years following the end of the calendar year covered.
- Drug and alcohol testing records shall be retained in accordance with company policy and applicable state law (minimum one year for negative results; minimum five years for positive results and follow-up testing).
- Workers' compensation records shall be retained per applicable state law, but no less than OSHA minimum requirements when exposure-related.

For employees working in multiple jurisdictions, the Company shall apply the longest applicable retention requirement.

Confidentiality and HIPAA Compliance

All medical records are considered confidential and shall:

- Be maintained separately from personnel files.
- Be accessible only on a need-to-know basis.
- Not be disclosed without written authorization except as required by law (e.g., OSHA, State Plan agencies, or workers' compensation authorities).

Electronic records shall be stored on secure, access-controlled systems. Physical records shall be maintained in locked, restricted-access locations. Business Associate Agreements (BAAs) shall be maintained with third-party occupational health providers where required.

Employee Access

Employees may request access to their medical or exposure records in accordance with 29 CFR 1910.1020. Access shall be provided within required regulatory timeframes, and all requests shall be documented.

Record Transfer and Destruction

In the event of acquisition, merger, or closure, medical records shall be transferred in accordance with OSHA requirements and employees shall be informed of their access rights. Records may only be destroyed after the legally required retention period has expired and must be destroyed in a secure and documented manner.

Corporate EHS and Human Resources shall review these requirements annually to ensure continued compliance across all operating states.

10.1 Return to Work Policy

Note: This document is not designed as a substitute for reasonable accommodation under any applicable federal or state laws, such as Americans with Disabilities Act, The Rehabilitation Act of 1973, or other applicable laws.

To preserve the ability to meet company needs under changing conditions, this company reserves the right to revoke, change, or supplement guidelines at any time with written notice. The policies and procedures in this return-to-work program are not intended to be contractual commitments, and they shall not be construed as such by our employees. This policy is not intended as a guarantee of continuity of benefits or rights. No permanent employment for any term is intended or can be implied by this policy.

Objectives

EE Reed East Coast has developed a return-to-work policy. Its purpose is to return workers to employment at the earliest date following any injury or illness. We desire to speed recovery from injury or illness and reduce insurance costs. This policy applies to all workers and will be followed whenever appropriate.

EE Reed East Coast defines “transitional” work as temporary modified work assignments within the worker’s physical abilities, knowledge, and skills.

Where feasible, transitional positions will be made available to injured employees in order to minimize or eliminate time loss.

For any business reason, at any time, we may elect to change the working shift of any employee based on the business needs of this company.

The physical requirements of transitional/temporary work will be provided to the attending physician. Transitional/temporary positions are then developed with consideration of the worker’s physical abilities, the business needs of EE Reed East Coast and the availability of transitional work.

Job Related Incident

If you have a work-related injury and are missing time from work, contact our Human Resources or Personnel Department for details regarding time loss.

Transitional Temporary Work

EE Reed will determine appropriate work hours, shifts, duration, and locations of all work assignments. EE Reed reserves the right to determine the availability, appropriateness, and continuation of all transitional assignments and job offers.

Communication

It is the responsibility of the worker and/or supervisor to immediately notify Personnel of any changes concerning a transitional/temporary work assignment. Personnel will then communicate with the insurance carrier and attending physician as applicable.

- An accident is any unplanned event that disrupts normal work activities and may or may not result in injury or property damage. All work-related accidents, injuries, and near misses must be reported immediately to Personnel.
- If an accident occurs, but does not require professional medical treatment, the supervisor should immediately be informed so that an accident analysis can be completed. If first-aid treatment is needed, it should be sought on-site. If an accident occurs which requires professional medical treatment, the worker should follow the emergency response plan and inform supervisor immediately.

Worker's Physical Condition

1. If professional medical treatment is sought, the worker should inform the attending physician that EE Reed has a return-to-work program with light duty/modified assignments available.
2. The worker should obtain a Release to Return-to-Work form and completed Job Description form (if available) from Personnel. This should be provided to the treating physician and should be returned to Personnel following the initial medical treatment.

Worker Able to Return to Work

1. If the attending physician releases the worker to return to work, as evidenced by completion of a Release to Return-to-Work form and Job Description Form, the form(s) must be returned to Personnel within 24 hours for assignment of light duty/modified work. The worker must report for work at the designated time.
2. The worker cannot return to work without a release from the attending physician.
3. If the worker returns to a transitional/temporary job, the worker must make sure that he or she does not go beyond either the duties of the job or the physician's restrictions. If the worker's restrictions change at any time, he or she must notify his or her supervisor at once and give the supervisor a copy of the new medical release.

Worker Unable to Return to Work

1. If the worker is unable to report for any kind of work, the worker must call in at least weekly to report medical status.
2. While off work, it is the responsibility of the worker to supply Personnel with a current telephone number (listed or unlisted) and an address where the worker can be reached.
3. The worker will notify Personnel within 24 hours of all changes in medical condition.
4. The supervisor/safety department will conduct an accident analysis on all accidents, regardless of whether an injury occurs.
5. Other information will be forwarded as soon as developed, including:
 - Name of worker's attending physician
 - Completed Release to Return-to-Work Form from attending physician and medical documentation, if appropriate
 - Completed transitional/modified or regular Job Description
 - Job Offer letter and responses
6. The supervisor will notify the insurance carrier of any changes in the worker's medical or work status as soon as possible.

Medical Treatment and Temporary/Transitional Duty Physical Condition

1. A Release to Return-to-Work form and a completed Job Description form (if available) will be provided to the worker to take to the attending physician for completion and/or approval.
2. At the time of first medical treatment the Release to Return-to-Work form must be completed and returned to Personnel. If one is not, Personnel will request one from the attending physician.
3. The completed Release to Return-to-Work form will be reviewed by Personnel. A temporary/transitional Job Description form will be prepared from information obtained from the attending physician for review and approval.
4. The supervisor will monitor the worker's performance to ensure the worker does not exceed the worker's physician release.
5. The supervisor will monitor the worker's recovery progress through regular contact to assess when and how often duties may be changed.
6. The supervisor will assess the company's ability to adjust work assignments upon receipt of changes in physical capacity.

11. Mobile Equipment

Serious injury or even death can result from workers coming into contact with mobile equipment on a jobsite.

Examples of Mobile Equipment on EE Reed's Construction site include are but not limited to:

- Excavators
- Bulldozers
- Loaders (e.g., skid-steer, wheel loaders)
- Cranes
- Forklifts
- Graders
- Scrapers
- Articulated Dump Trucks
- Rollers
- Trenchers
- Aerial Lifts
- Scissor Lifts
- UTV's

In order to protect workers from being struck by equipment, EE Reed East Coast will require that employees:

- Conduct daily inspections of equipment
- Install barricades when necessary
- Use required hand signals
- Require audible alerts or alarms when equipment is backing up

Pedestrian Paths

EE Reed to establish personnel walkways and provide hard barricades separating mobile equipment and vehicles from pedestrian pathways including from the construction office trailers to and around the construction site areas. The plan is to be frequently updated as conditions change.

Operator Responsibilities

All equipment must always be kept clean and orderly. Equipment must be locked when not in use. It is the operator's responsibility to regularly check fluid levels and inspect for deficiencies. Any equipment in need of repairs must be reported to the supervisor at once.

All equipment shall be equipped with:

- Beacon Lights or Strobes
- Visibility Flags (UTV's)
- Back-up alarms if rear visibility is obstructed.

Any accident, damage or fines incurred may be the responsibility of the employee and could, at the supervisor's discretion, be reason for immediate termination.

Any fines resulting from speeding or any other traffic violation while operating company equipment will be the sole responsibility of the employee.

Workers will be trained to know where to look to determine proper load rating capacity of equipment.

General Guidelines

- Operate all equipment in accordance with the manufacturer's specifications, and other applicable safety rules.
- Never use a cellphone or communication device while the equipment is in motion.
- Do not leave equipment unattended while in operation.
- Personnel must be trained and authorized by EE Reed East Coast prior to operating any self-propelled pieces of mobile equipment.
- Always shut equipment off when not in use.
- Do not alter or remove machine safety guards except for repair purposes. Immediately report known equipment safety problems or concerns to your supervisor for evaluation, maintenance, and/or replacement.
- Once equipment use is complete, be sure to properly secure, clean, and store in its designated area. When finished using equipment, be sure it is properly secured, cleaned, and stored in its designated area.
- Employee(s) shall conduct a 360-degree inspection of equipment prior to use of all equipment.
- Off-road equipment used on jobsites will be equipped with rollover protection.
- Employees must ensure that all vehicles have fully operational braking systems and brake lights.
- All vehicles with cabs shall be equipped with windshields and powered wipers.
- Cracked and broken glass shall be replaced.
- Vehicles operating in areas or under conditions that cause fogging or frosting of the windshields shall be equipped with operable defogging or defrosting devices.
- 100% seat belt use required when transporting workers in motor and construction vehicles.
- Equipment must maintain a 10 ft. minimum distance from overhead power lines, distance requirements increase incrementally based on the voltage, refer to a competent person for safe working distances.

Workers will not be allowed under suspended loads at any time. Only lifting chains or straps made in the USA to ASTM/ANSI standards and approved for the load rating being hoisted are to be used. Under no circumstance are other lifting devices to be used. Employees should stay clear of backing and turning vehicles, and equipment with rotating cabs.

Preventing Falls While Loading/Unloading Flatbeds

Portable steps or ladders designed with flatbed trailers must be used to access trailer beds during loading and unloading activities. Additionally, temporary railings or appropriate fall

protection systems must be put in place before accessing or working from the trailer bed (i.e. mobile anchor point)

Preventing Struck-By Injuries and Fatalities

OSHA defines “struck” as injuries produced by forcible contact or impact between the injured person and an object or piece of equipment.

There are 4 Main Types of Struck-By Hazards:

1. Struck-by **falling object**
2. Struck-by **flying object**
3. Struck-by **swinging object**
4. Struck-by **rolling object**

Tips to protect against **falling object** hazards:

1. Proper storage of materials.
2. Keep safe distance from suspended loads.
3. Properly plank and install toe-boards on all scaffolding.
4. Wear appropriate PPE, including hardhats.
5. Use Controlled Access Zones (CAZ) to demarcate areas where there is a potential for falling object hazards.

Tips to protect against **flying object** hazards:

1. Wear appropriate PPE, including safety glasses.
2. Properly guard and inspect all power tools prior to use.
3. Keep hands and limbs clear when using power tools or nail guns.

Tips to protect against **swinging object** hazards:

1. Do not work under a load while it is being lifted, suspended, or otherwise.
2. Ensure that all loads are properly secured and lifted to prevent swinging or slipping.
3. Do not work within the swing radius of cranes or excavators that rotate when in use.

Tips to protect against **rolling object** hazards:

1. Making visual contact with operator prior to entering work area.
2. Wear proper PPE to make yourself visible.
3. Do not walk behind equipment without notifying operator or spotter. Be cognizant of back-up alarms.

Working around Heavy Equipment

- Use caution when approaching heavy equipment.
- Don't approach moving equipment.
- Don't approach equipment from behind.
- Only approach equipment/operator if absolutely necessary.
- Never cross the path of a backing vehicle.
- Be cognizant of swing radius of equipment.
- Maintain eye contact and visual communication with operator if you are entering any

- danger zones (i.e., where injury may occur if conditions change).
- Stay clear of equipment if you are not essential to the work being performed.
- Be aware and practice strong caution in the presence of unbalanced and/or unsecure loads.
- Always allow yourself an exit/escape route.
- Practice the 20-20-20 Rule: Every 20 minutes, for 20 seconds, look 20 feet around you. This can help to enhance situational awareness and personal responsibility.

Backup Rule

This section applies to all vehicles, machinery and equipment operating with an “obstructed view to the rear”.

Vehicles, machinery and equipment must not be operated in reverse, unless:

1. The vehicle has a reverse signal alarm audible above the surrounding noise level, and
2. Either the vehicle is backed up only when a designated observer or ground guide (spotter) signals that it is safe to do so, or-
3. Before operating the covered vehicle in reverse, the driver visually determined that no employee is in the path of the covered vehicle.

“Obstructed View to the Rear” – means that anything that interferes with the view of the driver to the rear of the vehicle at ground level and includes structural members of the vehicle; its load (e.g., gravel, dirt, machinery parts); its height relative to the ground level viewing; damage to windows or side mirrors, etc. used for rearview movement; restricted visibility due to weather conditions (e.g., fog, snow); or work being done after dark without proper lighting.

Ground Guides Must Not

Must not do any activities other than those related to the vehicle being signaled, use cell phones/headphones, etc. that could pose a distraction, go behind in close proximity to a vehicle while it is backing up.

Ground Guides Must

Be trained on proper backing procedures, always stay in the line of sight of the vehicle driver while it is backing up, stay a safe working distance from the vehicle, be provided with and wear during proper PPE

Drivers/Operators Must

Be trained in the requirements of proper backing, not operate any equipment in reverse unless they keep constant line of sight of the ground guide. If visual contact with the ground guide is lost, the operator must immediately stop the vehicle until sight of the ground guide is regained and a signal is received from the ground guide to restart backup operations.

All Employees Must Not

Stand or walk in close proximity to a backing vehicle.

Training

All personnel designated to operate equipment will be trained in the standards for safe operation of the equipment, including:

- Limitations and use Rated load capacities

- Special hazards (i.e., tip-over)

EE Reed East Coast will keep a copy of this safety training program and make it available to the Federal, State, and Local authorities upon request. The information to be kept includes:

- Written description of its employee training program.
- Documentation of where an employee received safety training, if the training was not provided by EE Reed East Coast, or the employer of any subcontractors.
- Proof that the training covers the manufacturer specific equipment available to each operator.
- Post operating instructions as required by regulation (i.e., operators manual should be placed in the cab of vehicles).

Refresher training shall be provided for any driver or ground guide when they have violated the regulation, been involved in an accident or near miss, or received an evaluation indicating they have not been operating under this regulation in a safe manner.

Other Provisions:

If the reverse signal alarm stops working properly and an immediate fix is unavailable, the equipment shall either back-up only with assistance from a ground guide or removed from service until the alarm is repaired.

Covered vehicles that did not have back-up alarm when manufactured or were not later retrofitted with an alarm are exempt from the requirement to have a back-up alarm. If the manufacturer of the covered vehicle offered the employer a back-up alarm retrofit package at a reasonable and economically feasible cost and the employer did not have the retrofit package installed, this exemption does not apply.

Covered vehicles with operable video or similar technological capability providing the driver with a full view behind the vehicle are exempt from the requirement to use a ground guide.

Aerial Lifts (MEWPs)

Specific Requirements:

- Lift controls must be tested each day prior to use to ensure safe working conditions.
- ALL occupants must be trained to operate aerial lifts.
- It is prohibited to belt-off to an adjacent pole, structure, or equipment while working from an aerial lift.
- Employees must stand firmly on the floor of the basket and shall not sit or climb on the edge of the basket or use planks, ladders, or other devices for a work platform.
- Employees shall wear a full body harness with appropriate length lanyard. The use of body belts while working from an aerial lift is prohibited.
- Brakes must be set when equipment is in use.
- Aerial lift must not be moved when the boom is elevated in a working position with men in basket; except for which equipment is specifically designed for this type of operation.
- All electrical tests must conform to ANSI A92.2-1969 Section 5.
- Employees will stand a minimum of 5 feet away from operating lifts.
- No employees shall lean against a lift while in operation.

Training

EE Reed East Coast will train all employees who perform work on aerial lifts in the following areas:

- The nature of any electrical hazards, fall hazards, and falling object hazards in the work area.
- The correct procedures for dealing with electrical hazards. The proper use and handling of the aerial lift.
- The maximum intended load carrying capacities.

When EE Reed East Coast has reason to believe that an employee lacks the skill or understanding to operate this equipment safely, they will be retrained. Additionally, retraining will occur when processes or changes in the workplace are instituted, or when new hazards are introduced.

Scissor Lifts

All scissor lifts shall be operated on level solid ground unless equipped with off-road tires and a leveling system or out-riggers.

- Scissor lifts shall not be used as elevators or material hoists.
- Scissor lifts shall not be driven on or near uneven terrain, unstable surfaces, curbs, drop-off, or other hazardous conditions while in an elevated position.
- Gates and / or entrance chains shall be in place prior to elevating the work Platform.
- Employees will maintain 100% fall protection (harness/lanyard) while working from the basket of a scissor lift.
- Standing on the side rails is prohibited on any scissor lift or aerial device; these rails are part of the fall protection standard.
- Employees will not at any time leave the confines of the deck while operating a scissor lift.
- No ladders may be used on the inside of the scissor lift.
- Lifts must be kept a minimum of 10 feet from live electrical wires or poles.
- Employees must stand a minimum of 5 feet away from operating lifts.
- No employee shall lean against a lift while in operation.
- Lifts will be turned off when working in an elevated position.

Mobile Equipment Spotter Minimum Requirements

Damage caused by mobile equipment has resulted in significant impacts to our projects. Due to the severity of these incidents, the following minimum spotter requirements have been established.

- Immediately after setting exterior equipment (generators, switchgear, transformers, chillers, etc.) a 20' physical boundary line shall be installed around the equipment.
- Exterior mobile equipment/vehicle work occurring within 20' of exterior equipment (generators, switchgear, transformers, chillers, etc) shall require a trained and dedicated spotter.

- Exterior mobile equipment/vehicle work occurring within 10' of the building shell shall require a dedicated spotter.
- ALL forklift movement inside the building shell shall require a dedicated spotter.
- Scissor lift activities within 5' of interior critical equipment shall require a dedicated spotter when moving.
- Aerial lift activities within 20' of interior critical equipment shall require a dedicated spotter when moving.

Notes:

1. A trained and qualified spotter is expected to have undergone oral, written, and practical testing. The spotter is also expected to be familiar with the mobile equipment being monitored, including its capabilities, limitations, and dynamics involved in movement and lifting activities.
2. A designated spotter must have no other concurrent tasks while performing their spotter role. The spotter may only perform other work while the monitored equipment is OFF.
3. The number of spotters shall be suitable to the number of equipment and area of work. A spotter must be able to maintain eye contact with the equipment operator at all times and cannot direct multiple moving equipment simultaneously.

12. Hand and Power Tools

Hand Tools

General Guidelines

Always select and use the correct tool for the task. Makeshift or modified tools are strictly prohibited. Ensure the tool is the proper size, type, and rating for the work being performed.

Inspect tools frequently for damage or wear. Defective tools shall be removed from service immediately and reported to a supervisor for evaluation, repair, or replacement. Before leaving the shop or beginning work, verify that tools are in good condition, properly adjusted, and sharp where applicable.

Use appropriate personal protective equipment (PPE), including gloves when necessary to protect hands and eye protection when using impact tools. Carry sharp tools in protective covers and always use them in a direction away from the body.

Do not place tools on ladders, scaffolds, or elevated surfaces where they could fall and cause injury. Never throw or toss tools to another person.

Use non-sparking tools in hazardous atmospheres and insulated tools when performing electrical work. Do not use the blunt end of a tool as a hammer, and never push chisels or similar tools toward any part of the body.

Do not use pipes or extensions to increase leverage on hand tools unless the tool is specifically designed for such use. Ensure tool handles are smooth, free of splinters or defects, and securely fitted to the tool head. Keep tools clean and free of oil or grease to prevent slipping.

Power Tools

Power tools and rotating equipment significantly increase both the number and severity of workplace hazards. Risks include electrical shock, burns, entanglement, struck-by hazards from flying debris, abrasive wheel failure, and contact with rotating or moving parts. Strict adherence to safe work practices is required at all times.

All machine guards shall remain in place while equipment is in operation. Tampering with, bypassing, or removing guards is strictly prohibited without prior supervisory approval. Guards removed for maintenance or repair must be properly reinstalled before equipment is returned to service. When servicing electrically driven machinery, energy sources shall be controlled in accordance with the Company's Lockout/Tagout (LOTO) procedure. Disconnect switches shall be placed in the off position and secured by the authorized employee performing the work. Locks and tags shall not be removed until work is complete and the area is clear.

Where guarding cannot fully eliminate exposure to hazards, appropriate personal protective equipment (PPE) shall be used. This may include safety glasses with side shields, face shields, hearing protection, gloves (when appropriate and not creating entanglement risk), flame-

resistant clothing, aprons, respirators, hard hats, and safety footwear. Supervisors are responsible for ensuring employees are properly protected.

General Safety Practices

- Use tools only for their intended purpose and within their design limitations.
- Never carry a tool by its cord or hose, and never yank cords to disconnect from power.
- Keep cords and hoses away from heat, oil, sharp edges, and moving parts.
- Disconnect tools when not in use, before servicing, and when changing accessories such as blades, bits, or wheels.
- Secure workpieces with clamps or a vise to keep both hands free.
- Maintain proper footing and balance at all times.
- Avoid accidental starting; do not carry plugged-in tools with a finger on the switch.
- Keep tools clean, sharp, and properly maintained in accordance with the manufacturer's instructions.
- Remove damaged tools from service immediately and tag "Do Not Use."
- Do not wear loose clothing, jewelry, or anything that could become entangled in moving parts.
- Keep bystanders at a safe distance from the work area.

Electric tools shall not be used in damp or wet conditions unless specifically rated for such environments. Work areas shall be well-lit. Tools shall be stored in a dry location when not in use.

Only trained and authorized personnel may operate power tools and rotating equipment. Training shall include safe operation, hazard recognition, emergency shutoff procedures, and applicable lockout/tagout requirements. Refresher training shall be provided as needed.

Abrasive Wheel Machinery and Rotating Equipment safety

Special precautions apply to grinders, cut-off saws, bench grinders, polishers, and other abrasive or rotating equipment:

- Abrasive wheels must be compatible with the tool's speed rating (RPM). Never exceed the manufacturer's maximum operating speed.
- Perform a ring test (where applicable) on new grinding wheels before mounting to check for cracks or defects.
- Ensure wheels are properly mounted, balanced, and tightened per manufacturer specifications.
- Adjustable work rests on bench grinders shall be kept within 1/8 inch of the wheel. Tongue guards shall be adjusted within 1/4 inch of the wheel.
- Stand to the side of the wheel during startup and allow it to reach full operating speed before beginning work.
- Do not grind on the side of a wheel unless it is specifically designed for side grinding.
- Never use a wheel that has been dropped or damaged.
- Allow wheels to stop completely before setting the tool down.
- Do not force material into the wheel; apply steady, moderate pressure.
- Ensure sparks are directed away from combustible materials and personnel.
- Use appropriate eye and face protection at all times; a face shield is required when operating grinders.

- Hearing protection shall be worn where noise levels exceed permissible limits.
- Ensure guards fully cover the spindle end, nut, and flange projections.

For all rotating equipment, employees shall avoid placing hands near rotating parts, shall never attempt to stop moving components by hand, and shall ensure long hair is secured.

Powder-Actuated Tools

Purpose

To establish safe work practices for the inspection, use, storage, and maintenance of powder-actuated tools (PAT) to ensure employee safety and prevent injury or property damage.

Scope

This procedure applies to all employees, contractors, and subcontractors of EE Reed East who operate, handle, or work near powder-actuated fastening tools on any worksite.

Responsibilities

Supervisors

- Ensure only trained and authorized personnel operate PAT tools.
- Verify employees maintain current certification.
- Provide appropriate PPE and ensure its use.
- Stop work if unsafe conditions or improper tool use is observed.

Authorized Operators

- Follow all requirements in this procedure and the tool manufacturer's manual.
- Inspect PAT tools before each use and report defects immediately.
- Maintain possession of the tool and cartridges at all times while in use.

Safety Department

- Maintain training records.
- Conduct periodic inspections and audits of PAT use.

Definitions

- Powder-Actuated Tool (PAT): A tool that uses an explosive-type charge to drive fasteners into hard materials such as steel or concrete.
- Cartridges/Loads: Single-use, color-coded power charges used to operate PAT tools.

Training Requirements

- Operators must complete manufacturer-approved training and demonstrate competency before use.
- Refresher training required every 3 years or after unsafe operation is observed.
- Training must include:
 1. Tool operation
 2. Inspection procedures
 3. Load selection
 4. Safe firing procedures
 5. Misfire handling

Pre-Use Safety Requirements

Daily Tool Inspection

Before use, the operator must verify:

- Tool is clean and free of cracks, damage, or missing parts.
- Safety mechanisms operate correctly.
- Barrel is unobstructed.
- Fasteners and loads are appropriate for the tool and task.

Defective tools must be removed from service immediately.

Work Area Assessment

- Ensure the material to be fastened is suitable (concrete, steel; not brittle materials like brick/glass unless designed for it).
- Confirm no one is behind or beneath the work surface.
- Identify and avoid hidden hazards such as:
 1. Electrical wiring
 2. Gas lines
 3. Plumbing
 4. Voids in materials

Operating Procedures

General Requirements

- Use only manufacturer-recommended fasteners and loads.
- Keep hands and body clear of the muzzle end.
- Point the tool only at the work surface, never at yourself or others.

- Load the tool only when ready to fire.
- Ensure the tool is held perpendicular to the work surface.

Firing the Tool

1. Press the tool firmly against the surface.
2. Maintain full contact and proper alignment.
3. Warn nearby workers: "Firing!"
4. Pull the trigger using controlled and deliberate action.
5. Verify that the fastener has penetrated the material as intended.

Load Selection

- Use the lowest-power level that successfully drives the fastener.
- Increase load strength only as required.

Misfire Procedure

If the tool fails to fire:

1. Keep the tool pressed firmly against the work surface.
2. Maintain control for 30 seconds.
3. After 30 seconds, remove the tool from the surface.
4. Follow manufacturer instructions to clear the misfire safely- typically removing the cartridge and disposing of it in a designated misfire container.
5. Do not reuse misfired cartridges.

Prohibited Practices

- Never use PAT tools in an explosive or flammable atmosphere.
- Do not modify the tool or bypass safety mechanisms.
- Do not use the tool when footing or body position is unstable.
- Never shoot into:
 1. Cast iron
 2. Glass or tile
 3. Redwood or very hard woods
 4. Any surface that does not provide proper resistance
- Do not leave a loaded tool unattended.

Storage & Transportation

- Tools must be unloaded before transport or storage.
- Cartridges are to be stored in:

1. Original containers
 2. Locked, dry, temperature-controlled storage
 3. Away from ignition sources
- Transport cartridges separately from the tool.

Maintenance

- Perform cleaning and lubrication at manufacturer-recommended intervals.
- Only qualified personnel may conduct repairs.
- Document all maintenance activities.

Personal Protective Equipment

Employees exposed to falling, flying, abrasive, or splashing objects, or to harmful dusts, fumes, mists, vapors, or gases, shall be provided and required to use appropriate PPE based on the hazard assessment.

Core Safety Principles

All hazards associated with hand and power tools can be minimized by following these fundamental practices:

- Maintain tools in safe operating condition through regular inspection and maintenance.
- Use the correct tool and accessory for the job.
- Inspect tools and equipment before each use.
- Follow manufacturer instructions and Company procedures.
- Use required guarding and personal protective equipment at all times.

No task shall proceed if proper guards, controls, or protective measures are not in place.

13. Cord and Plug Connected Electrical Equipment

Extension electric cords connected to equipment may not be used for raising or lowering the equipment. Flexible cords may not be fastened with staples or otherwise hung in such a fashion as could damage the outer jacket or insulation.

Portable cord and plug-connected equipment and extension cords shall be visually inspected before use and any shift for external defects (such as loose parts, deformed and missing pins or damage to outer jacket or insulation) and for evidence of possible internal damage (such as pinched or crushed outer jacket).

Cord and plug connected equipment and extension cords which remain connected once they are put in place and are not exposed to damage need to be visually inspected until they are relocated.

If there is a defect or evidence of damage that might expose an employee to injury, the defective or damaged item shall be removed from service and no employee may use it until repairs and testing necessary to render the equipment safe have been made.

When an attachment plug is to be connected to a receptacle including an extension cord, the relationship of the plug and receptacle contacts shall be checked to ensure that they are of proper mating configurations.

Extension cords used with ground-type equipment shall contain an equipment grounding conductor.

Attachment plugs and receptacle may not be connected or altered in a manner which would prevent proper continuity of the equipment grounding conductor at the point where plugs are attached to receptacles. Additionally, these devices may not be altered to allow the grounding pole of a plug to be inserted into slots intended for connection to the current-carrying conductors.

Adapters which interrupt the continuity of the equipment grounding connection may not be used.

Portable electric equipment and extension cords used in highly conductive work location (such as those inundated with water or other conductive liquids) or in job locations where employees are likely to contact water or conductive liquids shall be approved for those locations.

Employees' hands may not be wet when plugging and unplugging extension cords, and cord and plug-connected equipment if energized equipment is involved.

Energized plug and receptacle connection may be handled only with insulating protective equipment if the condition of the connection could provide a conductive path to the employee's hand.

Locked type connectors shall be properly secured after connection.

Any cord and plug connected equipment supplied by other than premises wiring shall meet the following:

- It shall be equipped with a cord containing an equipment grounding conductor connected

to the tool frame and to a means for grounding the other end (however, this option may not be used where the introduction of the ground to the work environment increases the hazard to an employee); or

- It shall be of double-insulated type.

14. General Electrical Procedures

Communicate all safety procedures to employees, including any new or revised requirements, and ensure understanding prior to performing work.

Do not use frayed, worn, or damaged electrical cords or cables. Flat cords, job-made “Romex” extension cords, and household-type extension cords are prohibited on construction sites. Only use three-wire extension cords with an intact grounding pin, rated for hard or junior-hard service and approved for jobsite use.

Protect extension cords from damage when routed through doors, windows, or similar openings, and ensure they are not subject to pinch points, sharp edges, or vehicle traffic.

Maintain all electrical tools and equipment in safe operating condition and inspect them regularly for defects. Broken, damaged, or defective tools and equipment shall be removed from service immediately and tagged “Do Not Use.”

All temporary power sources—including extension cords connected to permanent building wiring—shall be protected by approved Ground Fault Circuit Interrupters (GFCIs). Employees shall plug into GFCI-protected temporary power poles or use GFCI-equipped extension cords to prevent electrical shock hazards.

Do not bypass, alter, or disable any protective system or safety device designed to prevent contact with electrical current.

Identify and maintain awareness of overhead electrical power lines. Ensure that ladders, scaffolds, materials, and equipment remain at least 10 feet from energized power lines. For crane operations, maintain a minimum clearance of 20 feet unless otherwise specified by regulation and proper controls are implemented.

Use and Installation

All listed, labeled, or certified electrical equipment shall be installed and used strictly in accordance with the instructions and limitations provided in the listing, labeling, or certification. Manufacturer instructions for safe installation, operation, and maintenance shall be followed at all times.

Electrical components shall not be modified unless specifically permitted by the manufacturer. Homemade junction boxes or fabricated devices used in conjunction with flexible cords (extension cords) are strictly prohibited.

Electrical equipment shall not be used unless it bears the manufacturer’s name or trademark and includes required markings indicating voltage, current, wattage, or other applicable ratings. The manufacturer must be identifiable so that product specifications and installation requirements can be verified.

Each service, feeder, and branch circuit shall be legibly marked at its disconnecting means or overcurrent device to clearly indicate its purpose, unless its function is obvious by its location and arrangement.

Grounding and Wiring Identification

Grounded conductors (neutral conductors) shall be clearly identifiable and distinguishable from all other conductors. Equipment grounding conductors shall also be identifiable and distinguishable from other conductors in accordance with applicable electrical codes and standards. Proper grounding and bonding practices shall be maintained to ensure employee protection.

Ground-Fault Circuit Interrupter (GFCI) Protection

All 120-volt, single-phase, 15- and 20-ampere receptacle outlets used by employees on construction sites, and not part of the permanent building wiring, shall be protected by approved Ground-Fault Circuit Interrupters (GFCIs) for personnel protection.

GFCIs shall be tested in accordance with manufacturer recommendations, and any defective device shall be removed from service immediately.

Selection and Use of Work Practices

Safety-related work practices shall be implemented to prevent electric shock, arc flash, burns, and other injuries resulting from direct or indirect contact with energized equipment or circuits. The work practices selected shall be appropriate to the voltage, energy level, and nature of the electrical hazard involved.

De-Energized Work

Exposed live parts to which an employee may be exposed shall be de-energized before work is performed on or near them, unless a qualified person determines and can demonstrate that:

- De-energizing introduces additional or increased hazards; or
- De-energizing is infeasible due to equipment design or operational limitations.

Live parts operating at less than 50 volts to ground are not required to be de-energized provided there is no increased risk of electrical burns or arc-related injury.

When equipment or circuits are de-energized, they shall be locked and/or tagged out in accordance with the Company's Lockout/Tagout (LOTO) procedure. Verification of de-energization shall be performed prior to beginning work.

Conductors and equipment that have been de-energized but not properly locked and tagged shall be treated as energized.

Energized Work

If exposed live parts are not de-energized due to increased hazard or infeasibility, additional protective measures shall be implemented to protect employees from electrical contact and arc flash hazards.

When working on or near energized parts:

- Only qualified employees shall perform the work.
- Appropriate shock and arc flash protection boundaries shall be established.
- Insulated tools and equipment rated for the voltage involved shall be used.
- Employees shall wear appropriate personal protective equipment (PPE), including arc-rated clothing, voltage-rated gloves, face shields, and other protective equipment as required by hazard assessment.
- Conductive objects, including jewelry and tools not rated for the task, shall be kept away from energized components.

No employee shall contact energized parts directly or indirectly through conductive materials without proper authorization, controls, and protective measures in place.

All electrical work shall be planned to minimize exposure to energized components whenever possible.

Work Practices When Working on or Near Exposed Energized Parts

This section applies to work performed on exposed energized (live) parts, including direct contact or contact through tools, materials, or equipment, as well as work performed close enough to expose employees to electrical hazards.

Only qualified persons are permitted to work on electric circuit parts or equipment that has not been de-energized in accordance with Company procedures. Qualified persons must be trained and capable of working safely on energized circuits and shall be familiar with special precautionary techniques, hazard recognition, shock and arc flash boundaries, insulating and shielding materials, insulated tools, and required personal protective equipment (PPE).

Illumination

Employees shall not enter spaces containing exposed energized parts unless adequate illumination is provided to perform work safely. Work shall not be performed where poor lighting or obstructions prevent clear observation of the task. Employees shall not reach blindly into areas that may contain energized parts.

Conductive Materials and Equipment

Conductive materials and equipment in contact with any part of the body shall be handled in a manner that prevents contact with exposed energized conductors or circuit parts. When handling long conductive objects (such as pipe, conduit, or ductwork) near energized parts,

hazards shall be minimized through insulation, guarding, barricading, or controlled material handling techniques.

Portable Ladders

Portable ladders used in areas where the employee or the ladder could contact exposed energized parts shall be non-conductive (wood or fiberglass).

Conductive Apparel

Conductive articles of jewelry and clothing—including rings, bracelets, necklaces, key chains, metal headgear, or garments with conductive thread—shall not be worn where they may contact exposed energized parts unless effectively insulated or removed.

Housekeeping

Employees shall not perform housekeeping duties near exposed live parts where contact is possible unless adequate safeguards such as insulating barriers or protective equipment are provided. Electrically conductive cleaning materials shall not be used near energized parts unless procedures are in place to prevent electrical contact.

Interlocks

Electrical safety interlocks shall not be defeated except temporarily by a qualified person performing testing or servicing. Interlocks must be restored to proper operating condition immediately upon completion of the work.

Overhead Power Lines

Employees shall maintain a minimum clearance of 10 feet from overhead power lines rated up to 50 kV, including clearance for any conductive object being handled. Greater distances may be required for higher voltages or where cranes and derricks are in use. When cranes are utilized, applicable crane standards and required clearance distances shall be followed.

Energized Work Requirements

If exposed live parts are not de-energized due to infeasibility or increased hazard, additional safety-related work practices shall be implemented to protect employees. Examples may include diagnostic testing that must be performed with circuits energized.

Work practices shall include:

- Establishment of shock and arc flash protection boundaries
- Use of voltage-rated and arc-rated PPE
- Use of insulated tools and test instruments
- Restriction of access to qualified personnel only

When testing circuits over 600 volts nominal, test instruments shall be verified for proper operation immediately before and immediately after testing by a qualified person.

Under no circumstances shall unqualified personnel work on or near energized electrical circuit parts.

Guarding Live Parts and Use of Covers

Exposed live parts of electrical equipment operating at 50 volts or more shall be properly guarded to prevent accidental contact. Guards or enclosures shall provide effective protection against employee exposure.

Conductors entering boxes, cabinets, or fittings shall be protected from abrasion by approved bushings, fittings, or connectors. All openings through which conductors enter shall be properly secured and sealed to maintain the integrity of the enclosure.

Unused openings in cabinets, panelboards, junction boxes, pull boxes, switches, receptacles, and fittings shall be effectively closed using approved covers or knockout seals. All electrical boxes and enclosures shall be equipped with securely fastened covers appropriate for the environment and application.

Use of Equipment

Extension Cord Use

- All extension cords used on jobsites shall be protected by an approved Ground Fault Circuit Interrupter (GFCI).
- Extension cords shall be grounding type (three-wire with intact ground pin), constructed with UL-listed components, and maintained in good physical condition.
- Extension cords shall not be spliced, lengthened, or repaired with tape. Damaged cords must be removed from service.
- Power strips are intended only for equipment requiring surge protection (e.g., computers) and shall not be used as a substitute for extension cords on construction sites.
- Extension cords shall not be plugged into power strips, and power strips shall not be "piggy-backed" or connected to one another.
- Extension cords shall not be run through holes in walls, ceilings, or floors; through doorways or windows; or concealed behind walls, ceilings, or floors.
- Extension cords shall not be attached to building surfaces or used in place of permanent wiring.
- Cords shall not be routed across high-traffic areas or in locations where they may be damaged.
- The use and placement of extension cords shall not create trip hazards.

Handling

Portable electric equipment shall be handled in a manner that prevents damage. Flexible cords shall not be used to raise, lower, or carry equipment.

Flexible cords shall not be stapled, nailed, or otherwise fastened in a way that could damage the insulation or outer jacket.**Visual Inspection**

Portable cord-and-plug connected equipment and extension cords shall be visually inspected before each shift for external defects and signs of internal damage.

Equipment and cords that remain connected and are not subject to damage do not require reinspection until relocated.

Defective or damaged equipment shall be removed from service immediately and tagged "Do Not Use" until properly repaired or replaced.

Grounding Requirements

Flexible cords used with grounding-type equipment shall include an equipment grounding conductor.

Attachment plugs and receptacles shall not be altered in any manner that interrupts the continuity of the equipment grounding conductor.

Adapters ("cheater plugs") that defeat grounding protection are strictly prohibited.

Conductive Work Locations

Portable electric equipment and extension cords used in highly conductive environments (such as areas with standing water or conductive liquids) shall be approved and rated for those specific conditions. Additional protective measures shall be implemented as necessary.

Connecting and Disconnecting Plugs

Employees shall not plug or unplug energized equipment with wet hands.

If there is potential for contact with energized conductive parts, insulating protective equipment shall be used.

Locking-type connectors shall be fully engaged and secured after connection to prevent accidental disconnection.

All portable electrical equipment shall be used in accordance with manufacturer instructions and Company electrical safety procedures.

15. Electric Arc Flash Protection

It is the policy of EE Reed East Coast to eliminate or control arc flash hazards associated with the maintenance and servicing of electrical building components on all jobsites. Standard operating procedures shall be implemented to prevent arc flash incidents and reduce employee exposure to electrical shock and burn hazards.

De-Energized Work (Required Whenever Feasible)

All electrical circuits and equipment shall be placed in an electrically safe work condition prior to maintenance unless de-energizing introduces additional hazards or is infeasible.

The following procedures shall be followed:

- Identify all possible sources of electrical supply.
- Open and secure all disconnecting means for each energy source.
- Apply Lockout/Tagout (LOTO) devices in accordance with EE Reed East Coast LOTO procedures.
- Test each conductor with an adequately rated voltage testing device to verify absence of voltage.
- Apply grounding devices where stored energy, induced voltage, or the possibility of contact with energized conductors exists.

Work shall not proceed until verification of zero energy has been completed.

Energized Electrical Work (When Justified)

When energized work is necessary, the following minimum safety measures shall be implemented:

Safe Work Practices

- Establish and maintain required approach boundaries.
- Keep unqualified personnel at least ten (10) feet away, or as required by voltage and hazard level.
- Use insulated tools rated for the voltage involved.
- Consider the use of insulating floor mats where applicable.
- Wear approved eye protection.
- Wear voltage-rated gloves appropriate for the task.
- Wear hard-soled leather work shoes or dielectric overshoes.
- Utilize appropriate arc-rated PPE based on voltage and incident energy level.

Minimum PPE by Voltage

1. **50–120 Volts**
 - Standard cotton work shirt and cotton pants (non-melting materials)
 - Safety glasses
 - Voltage-rated gloves as required

2. 120–600 Volts (Minimum Category 2)

- Category 2 arc-rated coat over standard uniform
- Low-voltage rated gloves
- Hard hat with arc-rated face shield
- Hearing protection (earplugs)

3. Above 600 Volts (Minimum Category 4)

- Category 4 arc-rated coat and pants
- High-voltage rated gloves
- Arc-rated switching hood
- Hearing protection

All PPE shall be inspected prior to use and rated for the applicable voltage and incident energy level.

Approach Boundaries to Live Parts for Shock Protection

(All distances are measured from the exposed live part to the employee.)

Nominal System Voltage (phase to phase)	Limited Approach Boundary (fixed circuit parts)	Restricted Approach Boundary (includes inadvertent movement adder)	Prohibited Approach Boundary
Less than 50V	Not specified	Not specified	Not specified
50V to 300V	3 feet, 6 inches	Avoid contact	Avoid Contact
301V to 750V	3 feet, 6 inches	1 foot	1 inch
751V to 15 kV	5 feet	2 feet, 2 inches	7 inches
Over 15 kV or movable conductor	See NFPA 70 E Table 130.2 (C)		

Limited Approach Boundary

The distance from an exposed live part within which a shock hazard exists. An unqualified person shall not cross this boundary unless continuously escorted by a qualified person.

Restricted Approach Boundary

The distance from an exposed live part within which there is an increased risk of shock due to arc-over and inadvertent movement. Only a qualified person who is properly insulated or guarded from the live parts may cross this boundary.

Prohibited Approach Boundary

The distance from an exposed live part within which work is considered equivalent to making direct contact with the energized part. Only a qualified person may cross this boundary, and only when:

- Specifically trained to work on energized equipment;
- An approved Energized Electrical Work Permit has been issued (except for testing, troubleshooting, and voltage measuring); and
- Appropriate voltage-rated and arc-rated PPE is used.

Flash Protection Boundary

The distance from exposed live parts within which a person could receive a second-degree burn in the event of an arc flash. Only qualified persons wearing appropriate arc-rated PPE may cross this boundary.

- For systems **600 volts or less**, the Flash Protection Boundary shall be a minimum of four (4) feet unless an incident energy analysis indicates otherwise.
- For systems **above 600 volts**, an arc flash analysis shall be conducted to determine the appropriate Flash Protection Boundary.

Supervisors are responsible for ensuring compliance with this program. Only qualified and properly trained employees shall perform electrical work involving potential arc flash exposure.

16. Ladders and Scaffolding

Ladders Last Policy

What Is “Ladders Last”?

The “Ladders Last” policy requires that ladders be used only as a last resort on EE Reed East Coast projects. Ladders are permitted only after the EE Reed Team has determined that all safer alternatives are infeasible for completing the task.

If it is determined that a ladder is the only practical means of performing elevated work:

- A Ladder Use Permit (issued only by an EE Reed Team Member) must be submitted and approved prior to starting work.
- No ladder greater than six (6) feet shall be permitted onsite without a current Ladder Permit and completed Safety Inspection Checklist.
- Job-built ladders are strictly prohibited.
- Temporary stair towers or prefabricated stair systems shall be used for access between building levels whenever feasible.

Implementation Strategy (Eliminate Ladder Use)

Superintendents and subcontractors shall preplan work to eliminate ladder use whenever possible by:

- Constructing assemblies at ground level and raising them into position
- Installing permanent stairs as early as possible
- Utilizing personnel hoists and elevators
- Substituting safer alternatives such as:
 - Boom lifts
 - Scissor lifts
 - Stair towers
 - Trailer-mounted access ladders designed for flatbeds

Permanent Stair Installation Strategy

- Early release of stair packages
- Close coordination with fabricators
- Install stairs immediately with each deck
- Install pan fills promptly
- Maintain two means of egress
- Eliminate gang ladders and scaffold stair towers whenever feasible

When Ladder Use Is Necessary

When a ladder is the only means to perform the work:

- Complete a Pre-Task Plan (PTP).

- Obtain an approved Ladder Use Permit.
- A Competent Person must evaluate fall protection requirements.
- Maintain three (3) points of contact at all times.
- If three points of contact cannot be maintained, employees must tie off at any height.
- At heights greater than six (6) feet, 100% fall protection is required, and a retractable lanyard shall be used to limit fall distance.
- Follow the "First Man Up" procedure as applicable.

Platform ladders are the preferred ladder type on EE Reed projects.

Prior to use, the EE Reed Team must review and approve:

- Job Hazard Analysis (JHA)
- Pre-Task Plan (PTP)
- Ladder Use Permit

Pre-Use Planning Questions

Before selecting and using a ladder, employees shall consider:

1. Will I be working near electrical or energized lines?
 - If yes, use a fiberglass ladder. Never use metal ladders near electrical sources.
2. What height is required to reach the work area?
 - Select the proper ladder length accounting for:
 - Proper pitch (4:1 ratio)
 - Minimum three (3) feet extension above landing surface
 - Required rung overlap
3. Is the surface stable and level?
 - Ensure the ladder is placed on a flat, solid base.
4. Can the ladder be secured?
 - Secure ladders at the top and bottom to prevent displacement.
 - On slippery surfaces, tie off the base to a substantial support.
5. Is assistance required?
 - If the ladder is heavy or difficult to maneuver, obtain a second person for support.

General Safe Work Practices

1. Hard hats with chin straps are required when working from ladders or scaffolds.
2. All ladders shall be inspected prior to each shift for cracks, warping, loose rungs, splinters, and overall condition.
3. Complete and affix the EE Reed Ladder Safety Inspection Checklist to each ladder prior to use.
4. Ladders shall be stored on racks or in designated storage areas.

5. Defective ladders shall be immediately tagged “Out of Service” and removed until repaired or discarded.
6. Report defective equipment to a supervisor immediately.
7. Only one person may occupy a ladder at a time (fire service ladders exempt).
8. Maintain the 4:1 ratio when setting extension ladders.
9. Avoid placing ladders near swinging doors or blind corners.
10. Do not paint ladders, as paint may conceal defects.
11. Always face the ladder when ascending or descending.
12. Do not carry materials that could cause loss of balance.
13. Do not overreach. Never allow your belt buckle or navel to pass beyond the ladder side rails.

Supervision is responsible for enforcing this policy. The goal of “Ladders Last” is to eliminate unnecessary ladder exposure and reduce fall-related injuries on EE Reed East Coast projects.

Scaffolding

Training Requirements

Prior to erecting, using, modifying, or dismantling scaffolding, employees must be trained by their employer to recognize and understand scaffold hazards. Training shall include safe work practices, load capacities, fall protection requirements, and proper inspection procedures.

Scaffold erection, modification, and dismantling shall be performed under the supervision of a Competent Person.

Safe and Proper Use of Scaffolds

- Scaffolds shall be constructed of 2-inch O.D. steel tubing (or equivalent approved system), certified for use, and utilized only for their intended purpose and rated load capacity.
- Each scaffold must be capable of supporting its own weight and at least **four (4) times** the maximum intended load.
- Scaffolds shall be erected on firm, level, and properly drained foundations.
- Screw jacks, base plates, and mudsills shall be used to ensure stability and prevent settlement.
- A Competent Person must inspect scaffolding daily and prior to each use.

Safe access (ladders, stair towers, or equivalent) shall be provided to allow employees to safely mount and dismount scaffolds.

Guardrails and Toe Boards

- Guardrails and toe boards shall be installed on all open sides and ends of platforms more than 6 feet above the ground or floor (except needle beam scaffolds and floats).
- Scaffolds between 4 and 6 feet in height, with horizontal dimensions less than 45 inches, shall have standard guardrails installed on all open sides and ends.
- Scaffold platforms more than 10 feet above a lower level shall be protected with standard guardrails or an approved fall protection system if guardrails are not feasible.

Guardrail Specifications:

- Toprail: 42 inches ($\pm$ 3 inches) above the platform
- Midrail: Approximately 21 inches above the platform
- Toe boards: Required when workers are below or when materials are present that could fall

Platform and Planking Requirements

- All working levels shall be fully planked using scaffold-grade wood or approved decking.
- Planks shall extend at least 6 inches over end supports but not more than 12 inches beyond supports unless properly secured.
- Platforms shall not extend beyond base supports on mobile scaffolds.
- Platforms must be level; tilting or unstable decking is prohibited.
- Ladders, boxes, or other makeshift devices shall not be used to increase working height while on a scaffold.

General Safe Work Practices

- Provide safe access to all scaffold platforms.
- Keep platforms free of debris, tools, and materials that may create trip hazards or falling object hazards.
- Hard hats shall be worn where required.
- Portable metal ladders shall not be used near electrical conductors or for electrical work.
- Ladders must remain free of oil, grease, and other slip hazards.
- When portable ladders are used for access, side rails must extend at least **3 feet** above the landing surface or be secured with a grasping device provided.

Fall Protection on Scaffolds

- Employees working more than 10 feet above a lower level must be protected from falls.
- Fall protection may consist of guardrails or a Personal Fall Arrest System (PFAS).
- PFAS shall be attached to a vertical or horizontal lifeline or a scaffold structural member.
- Vertical lifelines must be secured to an anchorage independent of the scaffold.
- Horizontal lifelines must be secured to at least two structural scaffold members.

Mobile Scaffolds

- Cross, horizontal, or diagonal bracing shall be installed to prevent racking and ensure the scaffold remains plumb and level.
- Casters and wheels shall be equipped with locking devices and locked while in use.
- Caster stems and wheel stems must be pinned or otherwise secured.
- Screw jacks or equivalent means shall be used to level the scaffold.
- Manual force used to move a scaffold shall not be applied more than **5 feet** above the supporting surface.
- Forklifts, trucks, or similar equipment shall not be used to move scaffolds unless specifically designed for that purpose.
- Employees must be warned prior to scaffold movement.

Employees Riding on Mobile Scaffolds

Employees shall not ride on manually propelled scaffolds unless all of the following conditions are met:

1. The surface is level (within 3 degrees) and free of holes or obstructions.
2. The height-to-base width ratio during movement does not exceed **2:1**.
3. Outriggers, if used, are installed on both sides of the scaffold.
4. Power systems (if used) are applied directly to the wheels.
5. No employee is on any portion of the scaffold extending beyond the wheels or base supports.
6. All tools and materials are secured or removed before movement.
7. Wheels are equipped with rubber or resilient tires.

Compliance with this policy is mandatory on all EE Reed East Coast jobsites. Supervisors and Competent Persons are responsible for enforcing these requirements

17. Fall Protection

EE Reed East Coast will require all employees and subcontractors to conform and comply with at least the minimum safe work practices contained in 29 CFR 1926 Subpart M – Fall Protection regulations. This section of EE Reed East Coast Safety Program is meant to provide employees with an understanding of OSHA's requirements and is not meant to provide the only or sole means of compliance. OSHA's fall protection standard (Subpart M) allows employers to obtain compliance through a variety of conventional and non-conventional fall protection systems.

EE Reed East Coast will train employees in hazard recognition and safety on the jobsite. All EE Reed East Coast employees will be provided with instructions on the proper use of fall protection equipment before they begin work or are exposed to fall or similar hazards on a jobsite.

EE Reed East Coast will require that fall protection systems be provided anytime workers are exposed to fall hazards **6 feet or more** above the next lower level. This is commonly referred to as the "trigger height" for when fall protection must be afforded to workers on construction sites.

Each work crew will have a Competent Person assigned to implement the fall protection practices and policies of EE Reed East Coast. The Competent Person will have the authority to stop work if an unsafe condition exists.

There is a difference between a Competent and Qualified Person(s). A Qualified Person is one who by possession of a recognized degree, certificate, or extensive experience and the ability to solve fall protection problems on the worksite.

Fall Protection Equipment / Methods Utilized on Jobsites: Personal Fall Arrest System

- Full Body Harness
- Lifeline (horizontal and rope grab, self-retracting lifelines)
- Approved Anchor Points
- Shock Absorbing Lanyard

The Competent Person will evaluate the jobsite and will determine which fall protection system, or combination of systems, will best protect workers on the jobsite. If a question regarding compliance with OSHA arises, immediately call your supervisor or competent person. EE Reed East Coast does not allow workers to be suspended by a forklift (powered industrial trucks). Forklifts used on EE Reed East Coast jobsites will only be used to transport trash or materials. No employees are allowed to work in a suspended box off a forklift.

As stated previously, this written safety program should serve as guidance for subcontractors to make them aware of how compliance with Federal and State Occupational Safety & Health regulations is achieved. Additionally, it is important to mention that EE Reed East Coast does not supervise, inspect or correct safety and health hazards of subcontractor's employees on our jobsites. The ultimate responsibility for the safety and health of subcontractor's employees lies with their employer.

Training and Hazard Identification

EE Reed East Coast will train employees in fall-related hazard recognition and about safety. Employees will be taught to use the safe work practices contained in the EE Reed East Coast

Safety Manual to prevent accidents on the jobsite.

Common hazards that may exist include missing guardrail, unprotected openings, broken or missing rungs on ladders, improper footing on sloped surfaces, full body harness not worn correctly, etc. The employee's ability to identify the hazards on jobsites is a critical component in the prevention of fall incidents.

All employees will be provided instructions on the proper use of fall protection equipment before they begin work. Before workers are allowed to access areas in which fall hazards exist, they will be trained in order to understand the requirements of EE Reed East Coast's Fall Protection Plan.

All training will be documented by EE Reed East Coast management, including the date, name of instructor, topic, and signature of attendees.

Training will be provided both in a formal classroom style and on-the-job. Toolbox talks will be used to serve as refresher training on various safety related topics, including fall protection and awareness.

Specifically, training will be conducted by a Competent or Qualified Person and will address at a minimum the following:

- The nature of the fall hazards in the work area.
- The correct procedures for erecting, maintaining, disassembling, and inspecting the fall protection systems to be used.
- The use and operation of guardrail systems, personal fall arrest systems, safety net systems, warning line systems, safety monitoring systems, controlled access zones, and other protection to be used.
- The role of each employee in the safety monitoring system, when this system is used.
- The limitations on the use of mechanical equipment during the performance of roofing work on low-sloped roofs.
- The correct procedures for the handling and storage of equipment and materials and the erection of overhead protection.
- The role of employees in the fall protection plans.
- The standards contained in OSHA's 1926 Subpart M – Fall Protection

Fall Protection Plan- Implementation and Requirements

The EE Reed East Coast Fall Protection Plan establishes the safe work practices required on all jobsites. This plan outlines how and where fall protection systems will be implemented. Because each jobsite presents unique conditions and hazards, this plan cannot address every possible situation. Employees must seek guidance from a supervisor, Competent Person, or Qualified Person whenever questions arise regarding compliance with the EE Reed East Coast Fall Protection Plan or applicable OSHA standards.

This program establishes the minimum safety requirements for employees who may be exposed to fall hazards of six (6) feet or more above the next lower level.

Trigger Heights

- 6 feet – Fall protection required for construction activities.
- 10 feet – Fall protection required when working from scaffolds.
- Ladders – No specific trigger height; ladder safety and fall protection requirements must be followed at all times in accordance with company policy and OSHA regulations.

This program applies to all EE Reed East Coast jobsites.

Competent and Qualified Persons

Each crew shall have a designated **Competent Person** responsible for implementing and enforcing this Fall Protection Plan. The Competent Person has full authority to stop work when unsafe acts or conditions are identified.

Competent Person Responsibilities

- Identify and evaluate existing and predictable fall hazards.
- Select the appropriate fall protection system for each unique task or condition.
- Ensure employees are properly trained in the systems being used.
- Understand the limitations and manufacturer recommendations of all fall protection equipment.
- Stop work and implement prompt corrective action when hazards are identified.

Only a **Qualified Person** has the authority to modify or approve changes to the EE Reed East Coast Fall Protection Plan.

Guardrail System Requirements

Height Requirements

- **Top Rail:** 42 inches ($\pm$ 3 inches) above the walking/working surface
- **Mid Rail:** 21 inches ($\pm$ 3 inches)
- **Toe Board:** Minimum 3½ inches high (4 inches nominal)

Structural Requirements

- Vertical supports shall be installed no more than 8 feet apart.
- Guardrails must be capable of withstanding at least 200 pounds of outward and downward force applied along the top rail.

Applications

- Wall openings greater than 18 inches must be protected.
- When framing is spaced 24 inches on-center, guardrails shall be installed to prevent falls through openings.

Hole Covers

Hole covers shall be used to protect employees from stepping, tripping, or falling into floor openings and to prevent objects from falling through.

Hole covers must:

- Protect holes greater **than 2 inches by 2 inches, or trenches 2 inches wide or greater.**
- **Support at least two (2) times** the anticipated load.
- Be secured in place to prevent accidental displacement (nailed, screwed, or otherwise fastened).
- Be clearly marked to indicate the presence of a floor opening.

Compliance with these requirements is mandatory on all EE Reed East Coast projects. Supervisors and Competent Persons are responsible for ensuring fall hazards are properly identified, evaluated, and controlled to protect all workers onsite.

Personal Fall Arrest System (PFAS)

A Personal Fall Arrest System (PFAS) is designed to stop an employee's fall from a working level and minimize the forces imposed on the body. A PFAS consists of an anchorage, connectors, a full-body harness, and may include a lanyard, deceleration device, lifeline, or a combination of these components.

Inspection Requirements

Employees shall inspect all PFAS components prior to each use for signs of damage, deterioration, or excessive wear. Any defective or questionable component shall be immediately removed from service and replaced.

Additionally, a competent person shall conduct and document an annual inspection of all fall protection equipment.

Fall Clearance Calculations

Prior to using a PFAS, a competent or qualified person shall calculate total fall clearance to ensure adequate distance exists to prevent contact with a lower level. The fall distance calculation shall include:

- Length of anchorage connector
- Length of lanyard
- Maximum elongation of deceleration device
- Harness stretch
- Worker height (measured to the dorsal D-ring)
- Required safety clearance factor

Equipment Inspection Criteria

Full Body Harnesses

- Inspect before each use.
- Examine nylon webbing for burns, cuts, frays, broken fibers, pulled stitches, or excessive wear.
- Inspect D-rings for cracks, pits, deformation, or excessive wear.
- Ensure buckles are not cracked or deformed and function properly.
- Verify grommets (if present) are secure and not distorted.
- Confirm no additional holes have been punched in the harness.
- Ensure rivets are tight and undamaged.
- Check straps for excessive wear from repeated use.

Storage: Harnesses shall be hung in an enclosed, protected area to prevent damage.

Post-Fall: Any harness subjected to a fall arrest shall be immediately removed from service.

Lanyards and Shock-Absorbing Lanyards

- Inspect before each use.
- Check material for cuts, burns, abrasions, kinks, knots, broken stitching, or excessive wear.
- Inspect snap hooks and carabiners for distortion, cracks, wear, and proper locking operation.
- Ensure locking mechanisms fully engage and prevent accidental opening.
- Inspect shock absorbers for signs of deployment or damage.
- Verify attachment points are free of defects.

Snap Hooks

- Inspect before each use.
- Ensure no distortion, cracks, or pitting on hook or eye.
- Verify keeper latch is not bent, obstructed, or damaged.
- Confirm keeper latch seats properly without binding.
- Test locking mechanism to ensure proper operation.

Self-Retracting Lanyards (SRLs) / Lifelines

- Inspect before each use.
- Examine housing for physical damage; ensure nuts and rivets are secure.
- Inspect full length of strap or cable for cuts, burns, abrasions, broken strands, kinks, or excessive wear.
- Ensure lifeline retracts freely.
- Conduct a sharp pull test to confirm locking mechanism engages.
- If required by the manufacturer, return SRLs for scheduled annual servicing and inspection.

Rescue Plan

A site-specific rescue plan shall be developed prior to exposure to fall hazards. The rescue plan shall include:

1. Procedures for contacting emergency services.
2. Methods for safely rescuing a suspended worker (e.g., ladders, aerial lifts).
3. Provisions to rescue a suspended worker within 3–4 minutes, whenever feasible, to prevent suspension trauma.

Rescuing a fallen worker promptly is as critical as preventing the fall itself.

Perimeter Protection

To protect employees from falls at unprotected sides, edges, and openings, guardrail systems shall be installed in accordance with regulatory requirements. A combination of:

- Guardrails
- Hole covers
- Personal Fall Arrest Systems

may be utilized to ensure adequate fall protection.

Controlled Access Zones

Used to control access to areas where leading edge work and other operations are taking place the controlled access zone shall be defined by a control line or by other means to restrict access.

Control Lines

- Placed not less than 6 feet nor more than 25 feet from the unprotected or leading edge.
- Must extend the entire length of the unprotected or leading edge.
- Must consist of ropes, wires, tapes or equivalent materials and be supported by stanchions.
 1. Each line must be flagged at no more than 6 ft. intervals with high-visibility material.
 2. Each stanchion must be at least 39 inches from the ground and no more than 45 inches.
 3. Each line must have a minimum breaking strength of 200 lbs.

18. Confined Spaces

On May 4, 2015 the Federal Occupational Safety and Health Administration (OSHA) issued then Final Rule on Confined Spaces in Construction. Confined spaces, such as manholes, tanks, or sewers, are work areas that are not designed for continuous occupancy and may be difficult to exit in the event of an emergency.

Examples of locations where confined spaces may occur include, but are not limited to, the following: Bins; boilers; pits (such as elevator, escalator, pump, valve or other equipment); manholes (such as sewer, storm drain, electrical, communication, or other utility); tanks (such as fuel, chemical, water, or other liquid, solid or gas); incinerators; scrubbers; concrete pier columns; sewers; transformer vaults; heating, ventilation, and air-conditioning (HVAC) ducts; storm drains; water mains; precast concrete and other pre-formed manhole units; drilled shafts; enclosed beams; vessels; digesters; lift stations; cesspools; silos; air receivers; sludge gates; air preheaters; step up transformers; turbines; chillers; bag houses; and/or mixers/reactors.

A confined space has;

- Limited means of entry and/or exit,
- It is large enough for a worker to enter it, and
- It is not intended for regular/continuous occupancy.

If a space meets the definition of “confined space” and contains recognized serious health or safety hazards, it is a “permit-required confined space” and OSHA requires workers to have a permit to enter these spaces. A space with no potential to have atmospheric hazards may be classified as a non-permit confined space only when all hazards are eliminated in accordance with the standard.

General Requirements

Prior to the start of work at any jobsite, each employer, including EE Reed East Coast, shall ensure that a competent person identifies all confined spaces in which one or more employees may work. Each identified space shall be evaluated to determine whether it qualifies as a permit-required confined space (permit space). This evaluation shall include consideration of the space’s characteristics and potential hazards, including atmospheric testing when necessary.

If Permit-Required Confined Spaces Are Identified

If a space is determined to be permit-required, the following actions shall be taken:

1. Employee Notification
 - Employees shall be informed of the existence, location, and dangers posed by each permit space.
 - Danger signs shall be posted at each permit space entry point.
 - A sign reading:

“DANGER – PERMIT REQUIRED CONFINED SPACE – DO NOT ENTER”

or other equivalent language shall be used to satisfy this requirement.

2. Notification to Representatives and Controlling Contractor

- Employees' authorized representatives and the controlling contractor shall be informed of the existence, location, and hazards associated with each permit space.

Entry Determination

If EE Reed East Coast receives notice of a permit-required confined space, a determination shall be made as to whether employees will enter the space.

If Employees Will Not Enter:

EE Reed East Coast shall implement effective measures to prevent employees from entering the permit space. These measures shall be in addition to compliance with all other applicable regulatory requirements.

If Employees Will Enter:

EE Reed East Coast shall implement a written Permit-Required Confined Space Program at the construction site. The written program shall:

- Be fully implemented prior to entry operations.
- Be made available to employees and their authorized representatives for review.
- Remain accessible during all entry operations

Entry Procedures

Eliminate any conditions making it unsafe to remove an entrance cover.

When entrance covers are removed, the opening must be **immediately guarded** by a railing, temporary cover, or other temporary barrier that will prevent an accidental fall through the opening and that will protect each employee working in the space from foreign objects entering the space.

Before an employee enters the space, the internal atmosphere will be tested, for oxygen content, flammable gases, and vapors, and for potential toxic air contaminants, in that order.

- Any employee who enters the space, or that employee's authorized representative, must be provided an opportunity to observe the pre-entry testing required by this paragraph.

No hazardous atmosphere is permitted within the space whenever any employee is inside the space.

Continuous forced air ventilation must be used, as follows:

1. An employee must not enter the space until the forced air ventilation has eliminated any hazardous atmosphere.

2. The forced air ventilation must be so directed as to ventilate the immediate areas where an employee is or will be present within the space and must continue until all employees have left the space.
3. The air supply for the forced air ventilation must be from a clean source and must not increase the hazards in the space.
4. The atmosphere within space must be continuously monitored. Monitoring equipment has an alarm that will notify all entrants if a specified atmospheric threshold is achieved.

If a hazard is detected during entry:

1. Each employee must leave the space immediately.
2. The space must be evaluated to determine how the hazard developed.
3. Subcontractors or general contractor whose employees are entering the space will implement measures to protect employees from the hazard before any subsequent entry takes place.

Subcontractors or general contractor performing the work inside the space will verify that the space is safe for entry and that the pre-entry measures have been taken, through a written permit system that contains the date, the location of the space, and the signature of the person providing the certification. The permit must be made before entry and will be made available to each employee entering the space.

When there are changes in the use or configuration of a non-permit confined space that might increase the hazards to entrants, or some indication that the initial evaluation of the space may not have been adequate, the subcontractor or general contractor performing the work will have a competent person reevaluate that space and, if necessary, reclassify it as a permit required confined space.

Prior to Entry

Permit Space Entry Communication and Coordination:

Before entry operations begin, Owner/Owner's Rep. must provide the following information, if it has it, to EE Reed East Coast:

1. The location of each known permit space;
2. The hazards or potential hazards in each space or the reason it is a permit space; and
3. Any precautions that the host employer or any previous controlling contractor or entry employer implemented for the protection of employees in the permit space.

Before entry operations begin, Entry Employer must:

1. Obtain all of the controlling contractor's information regarding permit space hazards and entry operations; and
2. Inform the controlling contractor of the permit space program that the entry employer will follow, including any hazards likely to be confronted or created in each permit space.

The controlling contractor and entry employer(s) must coordinate entry operations when:

1. More than one entity performs permit space entry at the same time.
2. Permit space entry is performed at the same time that any activities that could foreseeably result in a hazard in the permit space are performed.

After Entry

1. The Controlling Contractor must debrief each entity that entered a permit space regarding the permit space program followed and any hazards confronted or created in the permit space during entry operations.
2. Entry Employer must inform Controlling Contractor in a timely manner of the permit space program followed and of any hazards confronted or created in the permit space(s) during entry operations.

Permit Required Confined Space Program

Subcontractor or general contractor whose employees are entering the space will provide:

1. Testing and monitoring equipment Ventilating equipment Communications equipment
2. Personal protective equipment insofar as feasible engineering and work- practice
3. controls do not adequately protect employees
4. Lighting equipment that meets the minimum illumination requirements Barriers and shields
5. Equipment, such as ladders, needed for safe ingress and egress by authorized entrants;
6. Rescue and emergency equipment (tripod, full body harness, rescue winch)

Subcontractors or general contractor entering the space will:

1. Test conditions in the permit space to determine if acceptable entry conditions exist before changes to the space's natural ventilation are made, and before entry is authorized to begin by:
 - Perform pre-entry testing before entry is authorized; and
 - If entry is authorized, continuously monitor entry conditions in the areas where authorized entrants are working,
 - Continually monitor the space for atmospheric hazards.

The subcontractor or general contractor entering the space will provide at least one attendant outside the permit space. Additionally, that subcontractor or general contractor will designate each person who is to have an active role (as, for example, authorized entrants, attendants, entry supervisors, or persons who test or monitor the atmosphere in a permit space) in entry operations, identify the duties of each such employee, and provide each such employee with the training required.

Permitting Process

Before entry begins, the entry supervisor identified on the permit must sign the entry permit to authorize entry.

The completed permit must be made available at the time of entry to all authorized entrants or their authorized representatives, by posting it at the entry portal or by any other equally effective means so that the entrants can confirm that pre-entry preparations have been completed. The duration of the permit may not exceed the time required to complete the assigned task or job identified on the permit

Terminating Entry

Subcontractors or general contractor entering a space will retain each canceled entry permit for at least 1 year to facilitate the review of the permit-required confined space program.

The entry supervisor must terminate entry and take the following action when any of the following apply:

1. Cancel the entry permit when the entry operations covered by the entry permit have been completed; or
2. Suspend or cancel the entry permit and fully reassess the space before allowing reentry when a condition that is not allowed under the entry permit arises in or near the permit space and that condition is temporary in nature and does not change the configuration of the space or create any new hazards within it; and Cancel the entry permit when a condition that is not allowed under the entry permit arises in or near the permit space

Entry Permit

The entry permit that documents compliance with this section and authorizes entry to a permit space will identify (as required by OSHA):

- The permit space to be entered;
- The purpose of the entry;
- The date and the authorized duration of the entry permit;
- The authorized entrants within the permit space, by name or by such other means (for example, through the use of rosters or tracking systems) as will enable the attendant to determine quickly and accurately, for the duration of the permit, which authorized entrants are inside the permit space;
- Means of detecting an increase in atmospheric hazard levels in the event the ventilation system stops working;
- Each person, by name, currently serving as an attendant;
- The individual, by name, currently serving as entry supervisor, and the signature or initials of each entry supervisor who authorizes entry;
- The hazards of the permit space to be entered;
- The measures used to isolate the permit space and to eliminate or control permit space hazards before entry. Those measures can include, but are not limited to, the lockout or tagging of equipment and procedures for purging, inerting, ventilating, and flushing permit spaces.
- The acceptable entry conditions;
- The results of tests and monitoring performed, accompanied by the names or initials of the testers and by an indication of when the tests were performed;
- The rescue and emergency services that can be summoned and the means (such as the equipment to use and the numbers to call) for summoning those services;
- The communication procedures used by authorized entrants and attendants to maintain contact during the entry;
- Equipment, such as personal protective equipment, testing equipment, communications equipment, alarm systems, and rescue equipment, to be provided for compliance with this standard;
- Any other information necessary, given the circumstances of the particular confined space, to ensure employee safety; and
- Any additional permits, such as for hot work, that have been issued to authorize work in the permit space.

The entry permit that documents compliance with this section and authorizes entry to a permit space will identify (as required by OSHA)

Before entry into the space this permit must be completed and submitted to EE Reed.

Authorized Entrants Responsibility

Subcontractors or General Contractor whose employees are entering the space must verify that authorized entrants have been trained to:

- Understand the hazards that may be faced during entry, including information on the mode, signs or symptoms, and consequences of the exposure.
- Properly use equipment as required.
- Proper Personal Protective Equipment (PPE) used.
- Constantly communicate with the attendant as necessary to enable the attendant to assess entrant status and to enable the attendant to alert entrants of the need to evacuate the spaces.
- Alert the attendant whenever:
 1. There is any warning sign or symptom of exposure to a dangerous situation
 2. The entrant detects a prohibited condition
- Exit from the permit space as quickly as possible whenever:
 1. An order to evacuate is given by the attendant or the entry supervisor
 2. There is any warning sign or symptom of exposure to a dangerous situation
 3. The entrant detects a prohibited condition
 4. An evacuation alarm is activated.

Attendants Responsibility

Subcontractors or General Contractor whose employees are entering the space must verify that attendants have been trained to:

- Understand the hazards that may be faced during entry, including information on the mode, signs or symptoms, and consequences of exposure
- Recognize possible behavioral effects of hazard exposure in authorized entrants
- Continuously maintain an accurate count of authorized entrants in the permit space and ensures that the means used to identify authorized entrants
- Remain outside the permit space during entry operations until relieved by another attendant
- Communicate with authorized entrants as necessary to assess entrant status and to alert entrants of the need to evacuate the space;
- Assess activities and conditions inside and outside the space to determine if it is safe for entrants to remain in the space and orders the authorized entrants to evacuate the permit space immediately under any of the following conditions:
 1. If there is a prohibited condition;
 2. If the behavioral effects of hazard exposure are apparent in an authorized entrant
 3. If there is a situation outside the space that could endanger the authorized entrants
 4. If the attendant cannot effectively and safely perform all the duties required;
- Summon rescue and other emergency services as soon as the attendant determines that authorized entrants may need assistance to escape from permit space hazards;
- Take the following actions when unauthorized persons approach or enter a permit space while entry is underway:
 1. Warns the unauthorized persons that they must stay away from the permit space;
 2. Advises the unauthorized persons that they must exit immediately if they have entered the permit space; and

3. Informs the authorized entrants and the entry supervisor if unauthorized persons have entered the permit space;
- Perform non-entry rescues as specified by the rescue procedure
 - Perform no other duties that might interfere with the attendant's primary duty to assess and protect the authorized entrants.

Entry Supervisor Responsibility

Subcontractors or General Contractor whose employees are entering the space must verify that entry supervisors have been trained to:

- Understand the hazards that may be faced during entry, including information on the mode, signs or symptoms, and consequences of the exposure
- Verify, by checking that the appropriate entries have been made on the permit, that all tests specified by the permit have been conducted and that all procedures and equipment specified by the permit are in place before endorsing the permit and allowing entry to begin
- Terminate the entry and cancels or suspends the permit as required;
- Verify that rescue services are available and that the means for summoning them are operable, and that the employer will be notified as soon as the services become unavailable
- Remove unauthorized individuals who enter or who attempt to enter the permit space during entry operations
- Determines, whenever responsibility for a permit space entry operation is transferred, and at intervals dictated by the hazards and operations performed within the space, that entry operations remain consistent with terms of the entry permit and that acceptable entry conditions are maintained.

Rescue and Emergency Services:

In the event of any emergency employees will be trained to call **911**.

Non-Entry Rescue

Subcontractor or general contractor whose employees are in the space will provide the following for non-entry rescue:

- Provide each affected employee with the personal protective equipment (PPE) needed to conduct permit space rescues safely and train each affected employee so the employee is proficient in the use of that PPE;
- Train each affected employee to perform assigned rescue duties
- Train each affected employee in basic first aid and cardiopulmonary resuscitation (CPR)
- Ensure that affected employees practice making permit space rescues before attempting an actual rescue, and at least once every 12 months, by means of simulated rescue operations in which they remove dummies, manikins, or actual persons from the actual permit spaces or from representative permit spaces, except practice rescue is not required where the affected employees properly performed a rescue operation during the last 12 months in the same permit space the authorized entrant will enter, or in a similar permit space. Representative permit spaces must, with respect to opening size, configuration, and accessibility, simulate the types of permit spaces from which rescue to be performed.

Non-entry rescue is required unless the retrieval equipment would increase the overall risk of entry or would not contribute to the rescue of the entrant.

19. Personal Protective Equipment

EE Reed East Coast requires the use of Personal Protective Equipment (PPE) for all employees, contractors, or visitors who are on the premises who are exposed to hazards which may cause injury or illness. Where employees provide their own protective equipment, EE Reed East Coast will ensure its adequacy, including proper maintenance and sanitation of such equipment for our employees. Subcontractors are responsible for the purchase and providing of personal protective equipment for their employees and visitors on the jobsite.

Purpose

This document defines the PPE guidelines in order to standardize the use of it on EE Reed East Coast work sites.

Scope

This section applies to all EE Reed East Coast projects. Everyone entering an EE Reed project including tour groups, suppliers, owners, and subcontractors shall comply with requirements of this section.

Protective equipment includes equipment for eyes, face, head, and extremities; protective clothing; respiratory devices; and protective shields and barriers.

General Guidelines

Consider other measures before resorting to the use of PPE for protection. The use of PPE shall be the last choice in controlling exposure to known hazards. When potential exposures are encountered the following control measures must be applied, in the specified order, before PPE is considered.

1. Substitute the material (eliminate the hazard)
2. Change the process (reduce the hazard)
3. Make use of engineering controls (reduce the hazard)
4. Change work practices (minimize the risk)

EE Reed East Coast will evaluate each workplace to determine if there are hazards present, or are likely to be present, which necessitate the use of PPE. If such hazards are present.

When PPE is required a hazard assessment will be conducted by EE Reed Safety to determine the proper PPE.

EE Reed East Coast will:

Select and have each affected employee use, the types of PPE that will protect the affected employee from the hazards identified in the hazard assessment. Communicate selection decisions to each affected employee.

Select PPE that properly fits each affected employee.

Training

EE Reed East Coast will train all employees on at least the following elements:

- When PPE is necessary What PPE is necessary
- How to properly don, doff, adjust, and wear PPE The limitations of the PPE, and
- The proper care, maintenance, useful life and disposal of the PPE.

All employees will be responsible for demonstrating an understanding of the training and the ability to properly use the PPE, before being allowed to perform the work requiring its use.

Any employee who does not have the understanding or skill to properly wear the PPE will be retrained. Additionally, retraining will take place anytime changes in the workplace render previous training obsolete, changes in the type of PPE to be used, or inadequacies in any employees understanding or skill in the use of PPE.

EE Reed East Coast will verify that each affected employee has received and understood the required training through a written certification that contains the name of each employee trained, the date of training, and a description of the subject of the certification. Copies of the training records are available upon request. Certifications shall be turned in with the Safe Start Packets prior to trade mobilizing on the site.

Damaged or defective equipment will not be used and will be tagged from service and discarded.

Eye Protection

EE Reed East Coast will ensure that all safety glasses used will comply with ANSI Z87.1 standard. Additionally, side shields or safety glasses with side shields shall be worn where there is a hazard from flying object hazards.

Safety glasses are not required if vehicles or equipment are fully enclosed with tempered glass and windows are closed. Safety glasses are required if windows are open.

Safety glasses are not required during breaks and lunch times if all potential eye hazards are eliminated.

Tinted lenses may only be worn by those working outdoors.

Foot Protection

All employees, contractors, or visitors must wear closed-toes shoes with thick soles to prevent puncture injuries on jobsites.

Chemical-resistant boots must be worn where there is the potential of contacting corrosive or other hazardous material.

Foot guards shall be worn when using jack hammers or similar tools that could strike the foot while operating.

Employees may also wear safety-toed shoes. Protective footwear shall comply with ASTM F-

2413 standards.

Head Protection

- Employees shall wear hard hats whenever overhead, falling, or flying object hazards exist, or when there is a potential for electrical shock.
- Hard hats must comply with **ANSI Z89.1** and carry the appropriate Class designation (Class C, G, or E) based on the work being performed. Helmets meeting **EN397** or **EN12492** standards may be used where applicable; helmets with an EN397 designation must be equipped with a chin strap.
- Hard hats shall be inspected routinely for dents, cracks, penetration, UV degradation, or other signs of deterioration.
- Any hard hat subjected to a significant impact or electrical shock must be removed from service and replaced immediately, even if no visible damage is present.
- Stickers or decals shall be kept to a minimum to ensure proper daily visual inspection, as required by OSHA. Hard hats must not be drilled, painted, cleaned with strong detergents or solvents, or stored in extreme temperatures.
- Headlamps shall be worn when entering dark tunnels, shafts, or other low-visibility areas, or when required by the client.
- All affected employees must wear head protection that meets ANSI Z89.1 (1986 or most current revision)

Hand Protection

Persons involved in activities which subject the hands to injury (e.g. cuts, abrasions, punctures, burns, chemical irritants, and toxins) shall use hand protection appropriate to the hazard.

All employees who encounter a situation in which a special glove is needed should contact their foreman, superintendent, or safety professional for assistance.

Clothing

Employees exposed to the hazards created by welding, cutting, or brazing operations shall be provided appropriate protective clothing for the task at hand. The level of protection may vary depending upon the activity being performed and the magnitude of the hazards.

High visibility reflective vest or high visibility shirts are to be worn by all workers (EE Reed, Trade Partners, or visitors) at all times during construction.

Noise Protection

If engineering controls are insufficient to reduce noise exposures below the “action level” and hearing protection is required.

Hearing protectors shall be made available to all employees who request them at no cost to the employees. Employees shall be required to wear hearing protectors in all areas where noise levels are equal or exceed 85 dBA.

Workers must use hearing protection (i.e., earmuffs or earplugs) when exposed to hazardous levels of sound from tools or heavy equipment.

If hearing protection is required on jobsite, a written hearing-protection program will be implemented.

An Example of Reducing the NRR

8-hour TWA noise exposure: 93 dBA

NRR of hearing protectors: 29 dB

Subtract 7 dB from the NRR: $29 \text{ dB} - 7 \text{ dB} = 22 \text{ dB}$

Divide by 2: $22 \div 2 = 11 \text{ dB}$

Subtract 11 dB from the
8-hour TWA noise exposure: $93 \text{ dBA} - 11 \text{ dB} = 82 \text{ dB}$

Decide if 82 dB (known as the "Protected Exposure")
is below the PEL for noise

20. Respiratory Protection Program

The Occupational Safety and Health Administration (OSHA) construction industry regulations relating to respiratory protection (29 CFR 1926.103) are actually found under the general industry regulations applicable to respiratory protection in 29 CFR 1910.134. Those provisions mandate respiratory protection if engineering controls are not feasible or are ineffective. OSHA requires methods such as substituting less toxic materials or ventilating the work area to prevent atmospheric contamination. When engineering controls fail to reduce employee exposures to harmful contaminants below the permissible exposure limit (PEL) of a contaminant, respiratory protection and accompanying program elements must be put in place.

Purpose

This Respiratory Protection Program (RPP) establishes procedures to protect employees from exposure to harmful airborne contaminants and oxygen-deficient atmospheres in accordance with **29 CFR 1910.134** and **29 CFR 1926.103**.

This program applies to all EE Reed employees and subcontractors who are required to wear respiratory protection while performing work on company-controlled job sites.

Scope

This program applies where employees are exposed to:

- Dusts (e.g., silica, concrete, drywall, wood)
- Fumes (e.g., welding, cutting)
- Mists and vapors (e.g., paints, solvents, adhesives)
- Gases
- Oxygen-deficient atmospheres (less than 19.5% oxygen)
- Confined space environments
- Any airborne contaminant exceeding OSHA Permissible Exposure Limits (PELs)

Responsibilities

Employer

EE Reed shall:

- Identify respiratory hazards through job hazard analysis (JHA) and exposure assessments.
- Implement feasible engineering and administrative controls before requiring respirators.
- Provide appropriate respirators at no cost to employees.
- Provide medical evaluations, fit testing, and training.
- Maintain required documentation.

Program Administrator

The Safety Director (or designated competent person) is responsible for:

- Administering and maintaining the program.
- Conducting hazard assessments.
- Selecting appropriate respirators.
- Ensuring medical evaluations and fit testing are completed.
- Reviewing and updating the program annually.

Supervisors

Supervisors shall:

- Enforce proper respirator use.
- Ensure employees are trained and fit-tested.
- Remove employees from exposure if respirator requirements are not met.

Employees

Employees shall:

- Use respirators in accordance with training.
- Inspect respirators before each use.
- Maintain, clean, and store respirators properly.
- Report medical concerns or equipment defects immediately.

Hazard Assessment

A hazard assessment shall be conducted prior to beginning work activities that may generate airborne contaminants.

Assessment methods may include:

- Review of Safety Data Sheets (SDS)
- Air monitoring results
- Task-based exposure evaluations
- Confined space atmospheric testing
- Historical exposure data

Respirators shall not be used as a substitute for engineering controls unless such controls are not feasible or while they are being implemented.

Engineering and Administrative Controls

Whenever feasible, the following controls shall be implemented before requiring respirators:

- Local exhaust ventilation

- Wet methods for dust suppression
- Isolation or enclosure
- Substitution of less hazardous materials
- Scheduling work to limit exposure time

Respirator Selection

Respirators shall be selected based on:

- Type of contaminant
- Concentration level
- Oxygen level
- Assigned Protection Factor (APF)
- Work conditions and duration

Air-Purifying Respirators (APR)

Used where:

- Oxygen levels are $\geq 19.5\%$
- Contaminant concentration is known
- Appropriate filter/cartridge is available

Examples:

- N95 for nuisance dust
- P100 for silica
- Organic vapor cartridges for paints/solvents

Powered Air-Purifying Respirators (PAPR)

Used when:

- Higher protection factor is needed
- Extended wear is required
- Employees cannot pass tight-fitting fit test

Supplied Air Respirators (SAR) or (SCBA)

Required when:

- Oxygen levels are $< 19.5\%$
- Atmosphere is Immediately Dangerous to Life or Health (IDLH)
- Contaminant concentration is unknown
- Confined space entry requires it

Only positive-pressure SCBA or combination SAR/SCBA units shall be used in IDLH atmospheres.

Compressed Breathing Air Operating Practices (SCBA & SAR Only)

Purpose

In the event these are to be used, the following safe operating practices for compressed breathing air systems will be established. Specifically SCBA cylinders and supplied-air systems (SARs)-in compliance with OSHA 29 CFR 1910.134(i), which regulates breathing air quality and air-supply equipment.

Grade of Breathing Air (Required by OSHA)

All breathing air used in SCBA and SAR systems must meet Grade D requirements as defined in ANSI/CGA G-7.1-1989, mandated by OSHA.

Grade D air must contain:

- 19.5%–23.5% oxygen
- ≤10 ppm carbon monoxide (CO)
- ≤1,000 ppm carbon dioxide (CO₂)
- ≤5 mg/m³ hydrocarbons
- No noticeable odor

OSHA confirms Grade D specifications have not changed since adoption.

Compressed Air Sources for SAR Systems

Compressor Requirements

Per OSHA 1910.134(i)(5), compressors used for breathing air must be designed and located to prevent introduction of contaminated air. Examples of prohibited intake areas include:

- Vehicle or mobile-equipment zones
- Near chemicals or solvents
- Near combustion equipment

Filtration and Monitoring Requirements

Breathing air compressors must include:

- Filtration that removes water, oil, particulates, odors
- Carbon monoxide (CO) monitoring and alarm if compressor is oil-lubricated

Distribution System Requirements

- Pressure regulators must match respirator requirements.

- SAR airlines may not exceed 300 feet in total length.
- Quick-connect fittings must be unique to breathing-air systems to prevent accidental connection to shop air.

SCBA Cylinder Specifications & Handling

Cylinder Requirements

- Cylinders must be compliant with DOT pressure-vessel standards.
- Cylinders shall contain only Grade D or better breathing air.

Inspection & Hydrostatic Testing

- Inspect cylinders before each use for physical damage, pressure, valve condition, or contamination.
- Hydrostatic testing must follow DOT and manufacturer requirements.

Filling Cylinders

- Fill SCBA cylinders only from certified Grade D air systems.
- Ensure CO alarm and filtration systems are active at fill stations. [\[isienviro.com\]](https://www.isienviro.com/)

Operating Practices (SCBA and SAR)

Pre-Use Requirements

- Verify air supply meets Grade D quality.
- Inspect SCBA/SAR components (hoses, facepiece, valves, regulators).
- Confirm CO monitor is functional.
- Confirm compressor intake area is clean and free of contamination sources.

Use During Operations

- Maintain communication and monitoring during use.
- Replace or exit immediately if low pressure, equipment malfunction, or contamination breakthrough occurs.
- Protect airlines from heat, pinch points, and chemicals.

Post-Use Requirements

- Shut off cylinder, bleed lines, remove pressure.
- Clean and disinfect facepieces.
- Inspect equipment and return to proper storage.

- Report deficiencies immediately.

Prohibited Practices

- Do not use shop air or uncertified compressed air as breathing air.
- Do not disable filtration systems or CO alarms.
- Do not use compressors not designed for breathing air.
- Do not bypass SCBA/SAR safety mechanisms.

Documentation and Testing Requirements

- Maintain air-quality test records per OSHA 1910.134(i).
- Maintain compressor logs, CO monitor calibration, and SCBA maintenance records.

Training Requirements

Training on compressed breathing air systems shall cover:

- SCBA/SAR operation
- Grade D air requirements
- Air source hazards and identification
- Emergency procedures
- Cylinder handling and inspections

Medical Evaluation

Before fit testing or respirator use, employees must:

- Complete OSHA Respirator Medical Evaluation Questionnaire
- Be evaluated by a licensed healthcare professional (PLHCP)

Medical clearance must be obtained:

- Prior to initial respirator use
- If employee reports medical symptoms
- If workplace conditions change significantly
- As determined necessary by PLHCP

Fit Testing

Fit testing is required for tight-fitting respirators:

- Prior to initial use
- Annually thereafter
- Whenever a different respirator facepiece is used
- When facial changes occur (weight change, dental work, scarring, etc.)

Qualitative or quantitative fit testing shall be performed in accordance with OSHA protocols.

Employees shall be clean-shaven in areas where the respirator seals to the face.

Use of Respirators

Employees must:

- Perform user seal check each time respirator is donned.
- Not wear respirators with facial hair interfering with seal.
- Leave the work area if:
 - Respirator malfunctions
 - Breakthrough of contaminant occurs
 - Dizziness or breathing difficulty occurs

In oxygen-deficient or IDLH atmospheres:

- Standby rescue personnel must be present.
- Confined space entry procedures must be followed.
- Continuous atmospheric monitoring is required.

Cleaning, Maintenance, and Storage

Reusable respirators shall be:

- Cleaned and disinfected after each use.
- Inspected before and after use.
- Stored in a clean, dry, temperature-controlled area.
- Protected from dust, sunlight, chemicals, and deformation.

Damaged or defective respirators shall be removed from service immediately.

Cartridge and Filter Change Schedule

Cartridges shall be replaced:

- According to manufacturer recommendations.
- Based on calculated service life.
- Immediately if breakthrough is detected.
- At end of each shift if exposure is heavy or unpredictable.

End-of-service-life indicators (ESLI) shall be used where available.

Voluntary Use

If employees voluntarily use filtering facepiece respirators:

- They shall receive Appendix D information from OSHA.

- Medical evaluation is not required unless using elastomeric respirator.
- Respirator use shall not create additional hazards.

Training

Employees required to wear respirators shall receive training:

- Prior to initial use
- Annually thereafter
- When workplace conditions change

Training shall include:

- Respiratory hazards
- Proper donning and doffing
- Limitations and capabilities
- Emergency procedures
- Maintenance and storage
- Recognition of medical symptoms

Program Evaluation

The Program Administrator shall:

- Conduct annual program review.
- Evaluate effectiveness through site inspections.
- Consult employees regarding respirator use issues.
- Update program as regulations or site conditions change.

Recordkeeping

The following records shall be maintained:

- Medical clearance documentation
- Fit testing records
- Training records
- Air monitoring data
- Program review documentation

Records shall be retained in accordance with OSHA requirements.

Emergency and Oxygen-Deficient Atmospheres

No employee shall enter:

- Oxygen-deficient atmosphere (<19.5%)
- IDLH atmosphere
- Permit-required confined space

Without:

- Proper atmospheric testing
- Continuous monitoring
- Appropriate supplied-air respiratory protection
- Rescue provisions in place

21. Lockout/Tagout

All employees of EE Reed East Coast are required to adhere to the procedures, practices, and policies established in the Lockout/Tagout (LOTO) Program. This program is designed to protect personnel from the hazards associated with the unexpected energization, startup, or release of stored energy from machinery or equipment during servicing and maintenance activities. To ensure its effectiveness and compliance, the LOTO Program will be actively managed and routinely audited.

Scope

This program applies to the control of hazardous energy during servicing and maintenance of machines and equipment. Employees must follow these procedures whenever a guard or safety device is removed or bypassed, or when they are required to place any part of their body into a machine or equipment area where work is actively being performed on materials also known as the point of operation. It also applies to situations where employees are exposed to danger zones during a machine's operating cycle. The purpose of this program is to prevent injuries that may result from direct contact with moving parts, electrical energy, pneumatic or hydraulic systems, or other hazardous energy sources.

Exception

The Lockout/Tagout Program does not apply to work involving cord- and plug-connected electrical equipment if the equipment is unplugged and the plug remains under the exclusive control of the employee performing the servicing or maintenance. In such cases, the risk of unexpected energization or startup is considered controlled through the employee's direct management of the energy source.

Contractor Responsibility

All contractors performing work on behalf of EE Reed East Coast are responsible for implementing and maintaining their own Lockout/Tagout procedures in accordance with OSHA regulations and this program's standards. Contractors must ensure their employees are properly trained in these procedures and must enforce compliance throughout the duration of their work. It is the contractor's responsibility to monitor and manage adherence to these safety practices within their respective teams and departments.

Preparation for Lockout/Tagout

Before any machine or equipment is turned off for servicing or maintenance, the authorized employee must assess the type and magnitude of the energy involved, understand the specific hazards associated with that energy, and determine the appropriate methods or devices required to safely control it. Shutdown procedures must not begin until the authorized individual has verified the potential risks and implemented the necessary energy control measures.

- Machines or equipment must be turned off or shutdown using orderly procedures to avoid any additional or increased hazards to employees as the result of equipment stoppage.

Locking Out Equipment

Employees who are required to utilize the lockout/tagout procedure must be knowledgeable of the different energy sources and the proper sequence of shutting off or disconnecting energy means. The four most common types of energy sources are:

1. electrical (most common form);
2. hydraulic or pneumatic;
3. fluids and gases; and
4. mechanical (including gravity).

More than one energy source may be utilized on some equipment and the proper procedure must be followed in order to identify energy sources and lockout/tagout accordingly.

Electrical Isolation

1. Shut off power at the machine using normal stopping procedures.
2. Isolate the equipment from its energy source by disconnecting the power supply.
3. The disconnecting means must be locked out or tagged out in accordance with company LOTO procedures.
4. Verify isolation by attempting to start the equipment (press the start button) to ensure all energy sources are properly locked out.
5. Return all controls to their safest (neutral/off) position after verification.

Points to remember

- If the machine or equipment contains capacitors, all stored electrical energy must be discharged prior to beginning work.
- Possible disconnecting means include:
 - Power cords and plugs
 - Electrical panels (verify both primary and secondary voltage)
 - Circuit breakers
 - Operator control stations
 - Motor circuits
 - Relays
 - Limit switches
 - Electrical interlocks
- Some equipment may have both:
 - A motor isolating disconnect, and
 - A control circuit isolating disconnectBoth must be properly isolated.
- If electrical energy is controlled by unplugging a power cord, the plug must remain under the direct control of the authorized employee at all times, or the plug must be locked out or tagged out using an approved device.

Hydraulic/Pneumatic Isolation

- Shut off all energy sources (pumps and compressors).
 - If the pumps and compressors supply energy to more than one piece of equipment, lockout or tagout the valve supplying energy to the piece of equipment being serviced.

- Stored pressure from hydraulic/pneumatic lines shall be drained/bled when release of stored energy could cause injury to employees.
- Make sure controls are returned to their safest position (off, stop, standby, inch, jog, etc.).

Fluids and Gases Isolation

1. Identify the type of fluid or gas involved and determine the appropriate personal protective equipment (PPE) required.
2. Locate and close all valves necessary to stop the flow of energy. Apply lockout/tagout (LOTO) devices in accordance with company procedures.
3. Identify the primary isolating device(s), close them fully, and apply lockout/tagout.
4. Drain, vent, or bleed all lines and components to relieve stored pressure and bring the system to a verified zero-energy state.
5. If the system includes electrically controlled valves, disconnect and lock/tag the electrical energy source in addition to isolating the fluid or gas source.
6. Verify zero energy at the equipment before beginning work.

Mechanical energy Isolation

Mechanical energy may include gravity forces, stored energy in springs, hydraulic or pneumatic pressure, elevated components, or other moving parts.

1. Secure or block all components to prevent movement. Use appropriate blocking devices, cribbing, pins, or a die/ram safety chain where applicable.
2. Lock out or tag out all mechanical safety devices in accordance with established LOTO procedures.
3. Shut off and lock out or tag out all associated electrical systems supplying the equipment.
4. Verify the zero-energy state prior to beginning work.
5. After verification, return all controls to their safest (neutral/off) position.

Release from Lockout/Tagout

1. **Inspection:** Verify that all work has been completed. Inspect the equipment and ensure all tools, parts, and materials used during servicing have been removed and accounted for.
2. **Clean-Up:** Remove all towels, rags, temporary supports, and work aids from the equipment and surrounding area.
3. **Replace Guards:** Reinstall all machine guards and safety devices. In limited cases, a specific guard may need to remain off temporarily to allow for startup adjustments; however, all other guards must be properly reinstalled before re-energizing.
4. **Check Controls:** Ensure all controls are returned to their safest (neutral/off) position.
5. **Employee Verification:** Confirm that all employees are safely positioned or clear of the equipment. Notify affected employees that lockout/tagout devices are about to be removed and the equipment will be re-energized.
6. **Remove Locks/Tags:** Each authorized employee shall remove only their own lock or tag in accordance with company LOTO procedures

Service or Maintenance Involving More than One Person

When servicing and/or maintenance is performed by more than one person, each authorized employee shall place his own lock or tag on the energy isolating source. This shall be done by utilizing a multiple lock scissors clamp if the equipment is capable of being locked out. If the equipment cannot be locked out, then each authorized employee must place his tag on the equipment.

Removal of Unauthorized Employee's Lockout/Tagout by the Company

Lockout or tagout devices must only be removed by the employee who originally applied them. This rule is critical for maintaining the integrity of the lockout/tagout process and ensuring employee safety. However, in the rare instance where the authorized employee who installed the device is not available due to absence, emergency, or other exceptional circumstances the device may be removed only under the direct supervision of EE Reed East Coast management. In such cases, strict procedures must be followed. Management must verify that the employee who applied the lock or tag is not present and cannot be contacted. They must also ensure that it is safe to remove the device by confirming that the equipment is no longer being serviced and that no personnel are in harm's way. Documentation of the removal must be completed, and the employee who originally applied for the device must be informed of the removal as soon as possible upon their return.

Shift or Personnel Changes

To ensure equipment remains properly secured during shift or personnel changes, the following procedures shall be followed:

- The maximum permitted duration for a lockout is one shift or the completion of the assigned task, whichever occurs first.
- Equipment shall never be left in an unsecured or uncontrolled state.

If the lockout task cannot be completed before the end of the shift, one of the following two methods must be implemented:

Option 1: Direct Lock Transfer

1. Authorized employees from the outgoing shift shall remain present at the equipment.
2. Incoming authorized employees shall apply their personal locks to all energy isolation devices.
3. Once incoming employees' locks are properly installed, outgoing employees may remove their personal locks.
4. The zero-energy state shall be verified in accordance with the equipment-specific lockout procedure before work resumes.

This method ensures continuous lock protection without interruption.

Option 2: Supervisor-Controlled Transition Lock

1. A supervisor shall install a designated transition lock on each energy isolation device prior to the removal of outgoing employees' locks.
2. Outgoing authorized employees shall remove their personal locks.
3. Incoming authorized employees shall apply their personal locks to the energy isolation devices.
4. Incoming employees shall verify zero energy state in accordance with the equipment-specific lockout procedure.
5. The supervisor shall remove the transition lock once all incoming personal locks are properly installed.

This method ensures the equipment remains secured at all times during personnel transition.

Under no circumstances shall equipment be left without an applied lock or otherwise unsecured during shift changes.

Procedures for Outside Personnel/Subcontractors

Outside personnel/subcontractors shall be advised that the company has and enforces the use of lockout/tagout procedures. They will be informed of the use of locks and tags and notified about the prohibition of attempts to restart or re-energize machines or equipment that are locked out or tagged out.

Training and Communication

Each authorized employee who will be utilizing the lockout/tagout procedure will be trained in the recognition of applicable hazardous energy sources, type and magnitude of energy available in the workplace, and the methods and means necessary for energy isolation and control.

Each affected employee (all employees other than authorized employees utilizing the lockout/tagout procedure) shall be instructed in the purpose and use of the lockout/tagout procedure, and the prohibition of attempts to restart or re-energize machines or equipment that are locked out or tagged out.

Training certifications will be retained in the employee personnel files.

Periodic Inspection

A periodic inspection (at least annually) will be conducted of each authorized employee under the lockout/tagout procedure. This inspection shall be performed by EE Reed East Coast employees.

The inspection will include a review between the inspector and each authorized employee of that employee's responsibilities under the energy control (lockout/tagout) procedure. The inspection will also consist of a physical inspection of the authorized employee while performing work under the procedures.

22. Hazard Communication / GHS

The management team of EE Reed East Coast, Inc. is committed to preventing accidents and ensuring the safety and health of our employees. We will comply with all applicable federal laws, state, and local health laws, and safety rules.

Under this program employees are informed of the contents of the OSHA Hazard Communications Standard, the hazardous properties of chemicals with which they work, safe handling procedures, and measures to take to protect themselves from these chemicals. These chemicals may cause harm and can cause physical or health related issues.

Identifying Hazardous Chemicals

A list is available that identifies all hazardous chemicals with potential for employee exposure at this workplace. Detailed information about the physical, health, and other hazards of each chemical is included in a Safety Data Sheet (SDS); the product identifier for each chemical on the list matches and can be easily cross-referenced with the product identifier on its label and on its Safety Data Sheet.

Identifying Containers of Hazardous Chemicals

To ensure proper identification and safe handling, EE Reed East Coast adheres to the labeling standards set forth in the 2024 revision of the OSHA Hazard Communication Standard, which aligns with the United Nations' Globally Harmonized System (GHS) of Classification and Labeling of Chemicals. Under this system, every container of hazardous chemicals must bear a label designed to clearly communicate the chemical hazards through standardized elements. These elements include pictograms (symbols), signal words such as "Danger" or "Warning," and hazard statements that describe the nature and severity of the chemical risks. This labeling approach allows employees to quickly recognize hazardous substances and take appropriate precautions, ensuring compliance and enhancing workplace safety.

All hazardous chemical containers used at this workplace will have:

- The original manufacturer's label that includes a product identifier, an appropriate signal word, hazard statement(s), pictogram(s), precautionary statement(s) and the name, address, and telephone number of the chemical manufacturer, importer, or other responsible party.
- A label with the appropriate label elements just described.
- Workplace labeling that includes the product identifier and words, pictures, symbols, or combination that provides at least general information regarding the hazards of the chemicals.

EE Reed East Coast's Site Management

Ensure that all containers are appropriately labeled.

No container will be released for use until this information is verified. Workplace labels must be legible and in English. Information in other languages is available at: The manufacturer's website listed on the label

Small quantities intended for immediate use may be placed in a container without a label,

provided that the individual keeps it in their possession at all times and the product is used up during the work shift or properly disposed of at the end of the workday. However, the container should be marked with its contents.

Keeping Safety Data Sheets

The manufacturer or importer of a chemical is required by OSHA to develop a Safety Data Sheet (SDS) that contains specific, detailed information about the chemical's hazard using a specified format. The distributor or supplier of the chemical is required to provide this SDS to the purchaser.

SDS's are readily available to all employees during their work shifts. Employees can review SDS for all hazardous chemicals used at this workplace. A paper file copy will be stored in the field office and electronic files will be maintained as well.

All foreman will also have the link to the SDS's on their phones, along with the paper file copies in the field office.

If an SDS is not immediately available for a hazardous chemical, employees can obtain the required information by calling EE Reed East Coast's Main Office.

Before they start their jobs or are exposed to new hazardous chemicals, employees must attend a hazard communication training that covers the following topics:

- An overview of the requirements in OSHA's Hazard Communication Standard.
- Hazardous chemicals present in their workplace.
- Any operations in their work area where hazardous chemicals are used.
- The location of the written hazard communication plan and where it may be reviewed.
- How to understand and use the information on labels and in Safety Data Sheets.
- Physical and health hazards of the chemicals in their work areas.
- Methods used to detect the presence or release of hazardous chemicals in the work area.
- Steps we have taken to prevent or reduce exposure to these chemicals.
- How employees can protect themselves from exposure to these hazardous chemicals through use of engineering controls, work practices, and personal protective equipment.
- An explanation of any special labeling present in the workplace.
 1. What are pictograms?
 2. What are the signal words?
 3. What are the hazard statements?
 4. What are the precautionary statements?

EE Reed East Coast is responsible to ensure that employees receive this training. After attending the training, employees will sign a form verifying that they understand the above topics and how the topics are related to our hazard communication plan.

Prior to introducing a new chemical hazard into any department, each employee in that department will be given information and training as outlined above for the new chemical hazard.

Informing Employees Who Do Special Tasks

Before any employee begins a special or non-routine task that may involve exposure to hazardous chemicals, their supervisor is responsible for providing a thorough briefing on the specific chemical hazards associated with the task. This includes clear explanations of the nature of the hazards, potential health risks, and any unique conditions that may be encountered. In addition to identifying the hazards, supervisors will also instruct employees on how to properly control their exposure through safe work practices and the use of appropriate engineering or administrative controls. Employees will be informed about the required emergency procedures in case of accidental exposure or chemical release. The employer will conduct a hazard evaluation for each non-routine task and ensure that all necessary protective measures are in place, including the provision of Personal Protective Equipment (PPE) and any additional training required to perform the task safely and in compliance with applicable regulations.

Informing Contractors and Other Employers About Hazardous Chemicals

If employees of other employer(s) may be exposed to hazardous chemicals at our workplace (for example, employees of a subcontractor working on-site) It is the responsibility of EE Reed East Coast's Project Manager to provide them the following information:

- The identity of the chemicals, how to review our Safety Data Sheets, and an explanation of the container labeling system.
- Safe work practices to prevent exposure.

EE Reed will also obtain a Safety Data Sheet for any hazardous chemical a contractor brings into the workplace.

New Pictograms

Health Hazard



- Carcinogen
- Mutagenicity
- Reproductive Toxicity
- Respiratory Sensitizer
- Target Organ Toxicity
- Aspiration Toxicity

Flame



- Flammables

- Pyrophorics
- Self-Heating
- Emits Flammable Gas
- Self-Reactives
- Organic Peroxides

Exclamation Mark



- Irritant (skin and eye)
- Skin Sensitizer
- Acute Toxicity
- Narcotic Effects
- Respiratory Tract Irritant
- Hazardous to Ozone Layer (Non- Mandatory)

Gas Cylinder



- Gases Under Pressure

Corrosion



- Skin Corrosion
- Eye Damage
- Corrosive to Metals

Exploding Bomb



- Explosives
- Self-Reactives
- Organic Peroxides

Flame Over Circle



- Oxidizers

Environment (non-Mandatory)



- Acute Toxicity (Fatal or Toxic)

Signal Words

“Danger” – used for more severe hazards “Warning” – used for less severe hazards

Workplace Labeling Requirements

The current standard provides employers with flexibility regarding the type of system to be used in their workplaces and OSHA has retained that flexibility in the GHS standard. Alternative labeling systems such as the National Fire Protection Association (NFPA) 704 Hazard Rating and the Hazardous Material Information System (HMIS) are permitted for workplace containers. However, the information supplied on these labels must be consistent with the revised HCS, e.g., no conflicting hazard warnings or pictograms.

Safety Data Sheets

Safety Data Sheets (SDS) provide information on how to work safely with chemicals, how to handle spills, how to provide first aid and how to properly clean- up spills.

The format of the 16-section SDS should include the following sections:

- Section 1. Identification
- Section 2. Hazard(s) identification
- Section 3. Composition/information on ingredients
- Section 4. First-Aid measures
- Section 5. Fire-fighting measures
- Section 6. Accidental release measures
- Section 7. Handling and storage
- Section 8. Exposure controls/personal protection
- Section 9. Physical and chemical properties
- Section 10. Stability and reactivity
- Section 11. Toxicological information
- Section 12. Ecological information
- Section 13. Disposal considerations
- Section 14. Transport information
- Section 15. Regulatory information

- Section 16. Other information, including date of preparation or last revision

Hazard Determination

EE Reed East Coast will rely on safety data sheets obtained from product suppliers to meet hazard determination requirements.

Labeling

EE Reed East Coast will be responsible for seeing that all containers entering the workplace are properly labeled.

All labels shall be checked for:

- Identity of the material.
- Appropriate hazard warning for the material.
- Name and address of the responsible party. (Only if the container is received from the manufacturer, distributor, or importer.)

Each employee shall be responsible for ensuring that all portable containers used in their work area are labeled with the appropriate identity and hazard warning.

Multi-Employer Worksites: Informing Contractors

If our company exposes any employee of another employer to any hazardous chemicals that we produce, use, or store, the following information will be supplied to that employer:

- The hazardous chemicals they may encounter.
- Measures their employees can take to control or eliminate exposure to hazardous chemicals.
- The container and pipe labeling system used on-site.
- Where applicable MSDSs can be reviewed or obtained.

Periodically, our employees may potentially be exposed to hazardous chemicals brought on our site by another employer. When this occurs, we will obtain from that employer information pertaining to the types of chemicals brought on-site, and measures that should be taken to control or eliminate exposure to the chemicals.

List Hazardous Chemicals

A list of all hazardous chemicals used by EE Reed East Coast is available. Further information regarding any of these chemicals can be obtained by reviewing its respective SDS.

Materials which can be purchased by the ordinary household consumer, and which are used in the same fashion and amount as by the ordinary household consumer, are not required to be included in this list.

23. Hearing Conservation

The purpose of this section is to identify sound levels at which protective measures must be utilized on EE Reed projects and offer information to assist in complying with these requirements.

Engineering controls are the most effective defense against the hazards of noise. In many instances, however, the application of engineering controls in construction is not feasible due to the configuration of equipment, tools, or the tasks being performed. When noise controls, through engineering controls, are not feasible, or until controls can be installed, an effective hearing conservation program (HCP) must be emphasized.

Most activities performed by EE Reed East Coast will fall under the OSHA 1926 Construction Regulations, therefore the Hearing Conservation Program likewise follows the standards promulgated in 29 CFR 1926.101 Hearing Protection.

Training will cover the effects of noise on hearing, the purpose of hearing protectors, the advantages, disadvantages, selection, fitting and use. Additionally, training will cover the purpose of audiometric testing and an explanation of the test procedures.

All affected employees will be responsible for wearing the appropriate personal protective equipment with the proper noise reduction rating to protect against noise hazards in the workplace.

EE Reed East Coast provides personal protective equipment to protect against noise hazards in the workplace.

Is this just for our employees or is it for all trade partners on site

The primary objective of this program shall be to:

- Evaluate noise levels and exposures in the workplace. This can be accomplished through monitoring or existing data or studies.
- Identify job positions/tasks with noise exposures equal to or exceeding the “action level” (85 dBA as an 8-hour TWA) and positions with noise exposures exceeding the permissible exposure limit (90 dBA 8-hour TWA).
- Ensure availability and use of hearing protectors in areas/tasks where noise levels exceed 85 dBA.
- Provide an effective training program for all EE Reed employees exposed to noise at or above action level.
- Require EE Reed trade partners, of any tier, to provide for its employees the requirements and protections provided by EE Reed to its employees in this section.
- When noise levels are below the requirement to have a HCP in place, workers are encouraged to use hearing protection even though it may not be required. Hearing protection in noisy locations although not required may reduce the long term effects of hearing loss.

For most tasks, disposable ear plugs may be used to protect against noise hazards. Use the following steps for properly inserting foam ear plugs:

1. Ensure your hands and ear plugs are clean.
2. Roll ear plug between thumb and index finger.
3. If inserting into right ear (lift top of ear with left hand while holding plug in right hand).
4. Insert and hold into ear allowing the foam to expand to fit your ear canal.
5. Follow the same steps for opposite ear and reverse step 4.
6. Dispose after each use or if plugs become dirty.

Workers must use hearing protection (i.e., earmuffs or earplugs) when exposed to hazardous levels of sound from tools or heavy equipment.

If hearing protection is required on jobsite, a written hearing-protection program will be implemented.

When occupational noise levels exceed those permissible levels found in OSHA's Table D-2 - Permissible Noise Exposures (below), workers will be required to wear hearing protection personal protective equipment (PPE) with proper noise reduction rating (NRR). Depending on the level of noise exposure, workers may have to utilize a combination of controls.

Table D-2- Permissible Noise Exposures

<u>Duration per day/hours</u>	<u>Sound level dBA</u>
8.....	90
6.....	92
4.....	95
3.....	97
2.....	100
1/2.....	102
1.....	105
1/2.....	110
1/4 or less.....	115

Anytime noise levels are above 90 dBA, workers must don and properly wear ear plugs or muffs. Workers will be trained in the proper selection and use of these hearing protective devices. When noise levels are above 100 dBA, workers will be required to wear both ear plugs and earmuffs.

Workers should consult a competent person to understand whether they need to wear hearing protection onsite.

24. Heat/Cold Stress

Heat Related Injury Prevention

EE Reed East Coast recognizes that heat stress and heat-related illnesses are a serious and dangerous hazard that workers face in the construction industry.

Excessive exposure to heat can cause a range of heat-related illnesses, from heat rash and heat cramps to heat exhaustion and heat stroke.

In order to protect workers from heat-related illnesses, workers and supervisors will be encouraged to monitor the U.S. National Oceanic and Atmospheric Administration (NOAA) heat index system. Supervisors will download the U.S. OSHA Heat Safety Tool which allows workers and supervisors to easily calculate the NOAA heat index.

Additionally, we will require supervisors to take proactive measures to protect workers from heat-related illnesses such as, drinking enough fluids, scheduling rest breaks, planning for emergencies, adjusting work conditions, gradually acclimating workers, training and monitoring for signs and symptoms of heat-related illness.

The U.S. OSHA Heat Safety Tool is a free “app” on the Android and iPhone marketplace.

A sample showing the heat-indexes, risk levels and protective measures contained in this app is below:

Heat Index	Risk Level	Protective Measures
Less than 91°F	Lower (Caution)	Basic heat safety and planning
91°F to 103°F	Moderate	Implement precautions and heighten awareness
103°F to 115°F	High	Additional precautions to protect workers
Greater than 115°F	Very High to Extreme	Triggers even more aggressive protective measures

OSHA recommends that workers who may be susceptible to heat-related illnesses drink water often, take breaks in shaded areas, report heat symptoms early, and understand what to do in emergency situations.

Training Elements

- Training on heat-related illnesses and how it can be prevented and the control measures to be taken.
- Method used to monitor for heat stress, including standards being utilized and the responsible party for monitoring heat stress.
- Signs and symptoms of heat-related illnesses and first aid procedures for each condition.
- Exacerbation of heat related injury and illness based on various types of clothing,

including general work clothing, semi-permeable and non-permeable clothing, arc flash clothing, and other protective clothing which reduces the evaporation rate.

- The dangers of using drugs and alcohol in hot work environments

Potable Water

Potable drinking water will be available to employees and employees are encouraged to frequently drink small amounts, (e.g., 1/2 cup every 15-20 minutes).

Additionally, each site will have multiple coolers throughout the site during the summer months filled with cold water bottles.

Acclimatization

Workers who have not previously worked in a hot environment or have had a previous heat-related injury, or are known to be on medication, shall acclimatize with a regimen of increasing exposure each day of work.

Break Tents

Each jobsite is to set up a shaded break area. The break area is to be kept clean and protected from weather exposures, including provisions for hot and cold weather seasons. Break area will be equipped with seating, tables, and trash receptacles near for trash disposal.

Cool Down Stations

Each site must establish a designated cool-down area for workers displaying symptoms of heat-related illness, such as heat exhaustion or heat stroke. The area should be secluded from direct sunlight and preferably located in an air-conditioned space with a temperature set at 72 degrees Fahrenheit or lower. It is imperative to allocate dedicated resources on each worksite to facilitate the cooling down of individuals exhibiting symptoms of heat-related illness. Resources such as ice packs or a misting station are essential in beginning the cool-down process until the arrival of an EMT. It is recommended that the workers, supervisors, and employers are equipped with the knowledge of the appropriate utilization of the dedicated resources. This knowledge, coupled with the availability of resources, ensures prompt treatment of workers experiencing heat-related illnesses.

Cold Related Injury Prevention

In cold environments the following guidelines shall be followed to prevent cold-related injury.

- Warming shelters should be made available nearby when the wind chill drops below 10°F (-12°C).
- A change of clothing shall be available if there is an opportunity for a worker to become wet.
- When the wind chill drops below 0°F (-17°C), the following work practices shall apply.
- Workers shall use the buddy system to watch for signs and symptoms of cold related injuries or illnesses.
- The work rate shall be moderated to prevent sweating.
- Heat shelters shall be provided.
- New workers shall be given time to acclimate.

- If any extremity or body part is immersed in water where the air temperature is below 40°F (4°C), the employee shall be required to change any clothing that became wet and to dry off in a warm area.

Environmental monitoring.

- As the wind chill drops below 20°F (-7°C), the air temperature and wind speed (wind chill index) shall be monitored a minimum of every 4 hours or as warranted.
- When the wind chill falls below 0°F (-17°C), the air temperature and wind speed shall be monitored every 2 hours or more frequently if it drops below this level.

25. Trenching and Excavations

This Trenching & Excavation Safety Program has been developed to protect employees from safety hazards that may be encountered while performing work in trenches and excavations. This program is intended to assure that employees who perform work in excavations are aware of their responsibilities and know how to perform the work safely.

EE Reed East Coast will ensure that all persons involved in excavation and trenching work have received appropriate training in the safe work practices that must be followed in accordance with applicable OSHA regulations.

Basic Excavations Requirements

Before opening any excavation, the approximate location of utility installations, including sewer, cable, fuel/gas, electric, water lines, fiber optic, or any other underground installations that reasonably may be expected to be encountered during this work must be determined and properly marked.

EE Reed East Coast employees will hand-dig in order to expose underground facilities when we are working within 18-inches of the underground utility. Competent person must be aware of local and state requirements as they may be more stringent than the 18-inches referenced in this policy.

Each state has its own variation of the Underground Utility Damage Prevention Act, and the basics of the act are typically the same. The first step to planning to excavate is to call before you dig; this can be done by calling the nationwide one call number – 811.

Utility Companies or owners must be contacted within established local response times, advised of the proposed work, and asked to establish the location of the utility underground installations prior to the start of the actual excavation.

When excavation operations approach the estimated or approximate location of underground utilities; the exact location of the utilities must be determined.

While the excavation is open, the underground utilities must be so marked, protected, supported or removed as necessary to protect and safeguard workers in the trench.

No employee will be permitted underneath loads handled by lifting or digging equipment.

When mobile equipment is operated adjacent to an excavation, or when equipment is required to approach the edge of an excavation – a mechanism to warn the operator of the edge; this can be done with hand signals or stop logs. A spotter should direct the operator when navigating near the edge of a trench or excavation. If a loader is used, horizontal stabilizers can be used to protect the equipment from moving or tipping into the trench; be cognizant that this may place additional pressure near the soil surrounding the trench. Spoil piles and equipment must be placed at least 2 feet from the edge of the excavation; this will be discussed in more detail later.

Access

A ladder must be placed in trenches that are greater than 4 feet in depth. Additionally, ladders must be placed in order to require no more than 25 feet of lateral travel for employees. Extension ladders should be used at a 4 to 1 pitch. For every 4 ft. in height, the bottom of the ladder should be 1 ft. away from the trench walls. When using extension ladders, always extend ladder at least 3 feet beyond landing to provide a handhold for getting on and off the ladder.

PPE

All employees working in trenches or excavations must wear approved hardhats.

Employees exposed to flying fragments, dust or other materials produced by drilling, sawing, sanding, grinding, and similar operations must wear approved safety glasses with side shields. When employees are engaged in grinding operations; face shields and gloves must be worn.

Employees exposed to public vehicular traffic must wear ANSI-approved Class 2 or Class 3 vests constructed of high visibility and/or reflective material.

Roles and Responsibilities

All employees involved in excavation and trenching work have received appropriate training in the safe work practices that must be followed when performing this type of work.

In administering the Excavation Safety Program, EE Reed East Coast will:

- Monitor the overall effectiveness of the program
- Provide atmospheric testing and equipment selection as needed. Provide personal protective equipment as needed.
- Provide protective systems as needed.
- Provide training to affected employees and supervisors so that all affected employees understand the hazards associated with trenching & excavation, as well as EE Reed East Coast policies.
- Provide technical assistance as needed.
- Preview and update the program on at least an annual basis, or as needed.

The Competent Person for EE Reed East Coast in reference to this program must assure that:

- The procedures described in this program are followed.
- Employees entering excavations or trenches are properly trained and equipped to perform their duties safely.
- All required inspections, tests, and recordkeeping functions have been performed.

All employees who work in or around excavations must comply with the requirements of this program.

Employees are responsible for reporting hazardous practices or situations to EE Reed East Coast management, as well as reporting incidents that cause injury to themselves to the competent person.

Employees must notify their supervisor if they have not been properly trained on the hazards associated with the trenching and excavation safety policies of EE Reed East Coast.

Daily Inspection

The Competent Person will conduct daily inspections of excavations, adjacent areas, and protective systems for evidence of a situation that could result in possible cave-ins, failure of protective systems, hazardous atmospheres, or other hazardous conditions.

An inspection must be conducted by Competent Person prior to the start of work and as needed throughout the shift.

Inspections must also be made after every rainstorm or other hazard-increasing occurrence. These inspections are only required when the trench will be or is occupied by employees.

Where the Competent Person finds evidence of a situation that could result in a possible cave-in, failure of protective systems, hazardous atmosphere, or other hazardous conditions, exposed employees will be removed from the hazardous area until precautions have been taken to assure their safety.

Competent Person is responsible for maintaining a written log of all inspections conducted. This log shall include the date, work site location, results of the inspection, and a summary of any action taken to correct existing hazards.

Determining Soil Types

Types of soil or categories range from the most stable to the least stable (Stable Rock, Type A, Type B, Type C) and are based on an analysis of a variety of properties.

Solid Rock is a natural solid mineral material that can be excavated with vertical sides and remain intact while exposed.

Type A is a cohesive soil with an unconfined compressive strength of 1.5 ton per square foot (tsf) or greater; examples include clay. Type A soil can never be previously disturbed.

Type B is a cohesive soil with an unconfined compressive strength greater than 0.5 tsf but less than 1.5 tsf. Examples of Type B soil can be soil that meets the characteristics of type A soil but is fissured, is subject to vibrations, or has been previously disturbed.

Type C is cohesive soil with unconfined compressive strength of 0.5 tsf or less, or granular soil including gravel or sand. Most previously disturbed soil is classified as Type C soil.

If different types of soil exist in a single trench or excavation the soil must be classified based on the weakest soil layer found. The competent person has the option of classifying the layers individually if a more stable layer exists below a weaker layer.

Soil testing and analysis will be performed in accordance with OSHA 29 CFR 1926, Subpart P.

EE Reed East Coast will always assume the soil is Type C and will provide the proper employee

protection for Type C soil, regardless of the type of soil present, soil testing is not required if Type C soil is classified and protective systems utilized. The only exception is if the soil is classified by a registered professional engineer familiar with soil typing and protective systems.

Visual Tests

Visual tests are performed as the soil is being excavated. The competent person is looking to see how the soil is staying together, see if the soil clumps as it is dug or breaks up with ease. The competent person will watch the sides of the excavation to see how easily the soil caves in, looks for freely seeping water, and looks for signs that the soil was previously disturbed.

When conducting visual tests, the competent person will:

- Observe samples of soil that are excavated and soil in the sides of the excavation; estimate the range of the particle sizes.
- Observe the soil that is excavated, soil that remains in clumps when excavated is cohesive.
- Observe the sides of the open excavation and the surface area adjacent to the excavation.
- Crack-like openings such as tension cracks could indicate fissured material. If chunks of soil fall off a vertical side – this could indicate the soil is fissured.
- Look for signs the soil was previously disturbed, look for existing underground utilities or other underground facilities.

Manual Tests

EE Reed East Coast will assume that all soil is Type C soil unless a registered professional engineer familiar with soil typing and protective systems determines otherwise. Manual tests will not be conducted by EE Reed East Coast employees.

Hazardous Conditions, Hazardous Atmospheres

Competent Person will test the atmosphere in excavations over four (4) feet deep if a hazardous atmosphere exists or could reasonably be expected to exist. A hazardous atmosphere could be expected, for example, in excavations in landfill areas, areas where hazardous substances are stored nearby, or near areas containing gas pipelines.

Adequate precautions will be taken to prevent employee exposure to atmospheres containing less than 19.5 percent oxygen and other hazardous atmospheres. These precautions include providing proper respiratory protection or forced ventilation of the workspace.

Forced ventilation or other effective means will be used to prevent employee exposure to an atmosphere containing a flammable gas in excess of ten (10) percent of the lower flammability limit of the gas.

When controls are used that are intended to reduce the level of atmospheric contaminants to acceptable levels, continuous air monitoring will be performed by Competent Person.

Atmospheric testing will be performed using a properly calibrated direct reading gas monitor. Additional requirements are contained in EE Reed East Coast's safety policy for determining confined spaces and entry procedures.

Water Accumulation

Employees are not permitted to work in excavations that contain or are accumulating water unless precautions have been taken to protect them from the hazards posed by water accumulation. Precautions may include special support or shield systems to protect from cave-ins, water removal to control the level of accumulating water, or use of safety harnesses and lifelines.

Competent Person will inform affected workers of the precautions or procedures that are to be followed if water accumulates or is accumulating in an excavation.

Tension Crack or Fissures

Tension cracks or fissures often run along the trench, along the lip of the trench or even across benches. When this is found at an excavation, the sides of the trench have moved and could slide or topple.

Tension cracks can also cause sliding or sloughing of the soil, the soil will begin to start sagging from inside the trench walls.

Tension cracks can also cause toppling, which is when a trench's vertical face shears along the tension crack line and topples into the excavation.

Vibration

Vibration increases the chance of failure in an excavation. Vibration from equipment or traffic could cause the breakdown of an excavation and cause a collapse. A competent person will take this into consideration when determining soil type, which typically results in a lower soil classification.

Protective Systems Requirements

All employees in excavations **4** feet or more in depth must be protected from cave-ins by an adequate protection system. Employees exposed to potential cave-ins in excavation and trenches 4 feet or more in depth must be protected by sloping or benching the sides of a trench or excavation, shoring the sides of the trench or excavation, or placing a shield in the trench or excavation to protect workers.

Note that trenches less than 4 ft. can also be protected if the competent person determines that a cave-in is a possibility.

The Competent Person will make the determination of which method(s) of protective systems to utilize onsite.

Sloping

This method protects employees from cave-ins by shaping the sides of an excavation to form an incline away from the excavation.

1. In Type A Soil – less than 20 ft. in depth, the angle must be cut at a 53- degree angle or rate of $\frac{3}{4}$: 1 (horizontal to vertical).
2. In Type B Soil – less than 20 ft. in depth, the angle must be cut at a 45- degree angle or at a rate of 1:1 (horizontal to vertical).
3. In Type C Soil - less than 20 ft. in depth, the angle must be cut at a 34- degree angle or at a rate of 1 $\frac{1}{2}$:1 (horizontal to vertical).

Benching

This method protects employees from cave-ins by excavating the sides of an excavation to form one or a series of horizontal levels or steps, usually with vertical or near vertical surfaces between levels.

1. In Type A Soil – the benches will be cut with the vertical cut 4 ft. deep and then cutting back horizontally 4 ft. The second and subsequent vertical cuts can be made 4ft. high and cut 4 ft. back.
2. In Type B Soil – the benches will be cut with the vertical cut 4 ft. deep and then cutting back horizontally 4 ft. This can be done to a maximum of 20 ft. in depth.
3. In Type C Soil – benching of soil is prohibited.

Shielding

Trench boxes/shields are able to withstand the forces imposed by a cave-in and thereby protect employees. Trench boxes must be installed in a way to restrict lateral or other hazardous movement in the event a sudden lateral load is applied. Any equipment

found to have damaged or defective parts will be taken out of service until properly repaired or approved for use by a registered professional engineer.

Ladders must also be used along with trench boxes to allow entry and egress for workers.

Trench boxes must extend at least 18 inches above the surrounding area if it is sloped toward the excavation.

Shoring

Shoring is a temporary support system that supports the faces of a trench and is designed to prevent cave-ins. Shoring systems protect workers by preventing the movement of soil, underground utilities, and roadways.

Other Requirements

At least one copy of a tabulated data sheet must be maintained at the jobsite during the construction of a protective system.

Copies must be made available to OSHA, upon request.

Protective systems for excavations greater than 20 feet deep must be designed by a registered professional engineer.

Spoil piles must be placed no closer than 2 ft. from the edge of the excavation. Spoils can cause an extra load on the excavation wall causing it to fail. Equipment and materials can also cause extra loading to the walls and should be staged a safe distance from the edge of the excavation.

26. Crane Safety

Crane Operator Certification

All crane operators must be certified or qualified in accordance with OSHA requirements. The following provisions apply:

Employer Responsibilities

- Employers are responsible for ensuring crane operators are properly certified or qualified.
- Employers must pay all costs associated with certification or qualification for currently uncertified or unqualified operators.

Acceptable Certification / Qualification Options

Option 1: Certification by an Accredited Crane Operator Testing Organization

- The testing organization must be accredited by a nationally recognized accrediting agency.
- Certification must include both written and practical examinations.
- Certifications issued under this option are valid for five (5) years.

Option 2: Qualification Through an Audited Employer Program

- The employer's qualification program must be:
 - Developed by an accredited crane operator testing organization; or
 - Approved by an auditor certified to evaluate such programs by an accredited crane operator testing organization.
- The program must be audited:
 - Within three (3) months of implementation; and
 - At least every three (3) years thereafter.

Option 3: Qualification by the U.S. Military

- Crane operators qualified by the U.S. military are considered compliant, provided documentation of qualification is maintained.

Option 4: Licensing by a Government Entity

- Operators may be licensed by a federal, state, or local government entity.
- The licensing program must meet OSHA criteria equivalent to those required for accredited crane operator testing organizations.

All documentation of certification or qualification must be maintained and made available upon request.

Signal Person Qualification Requirements

Before any employee performs signaling duties, the employer must ensure the individual meets the qualification requirements outlined below.

Option 1: Third-Party Qualified Evaluator

A qualified third-party evaluator assesses the individual and provides written documentation confirming the person meets the required qualification criteria.

Option 2: Employer's Qualified Evaluator

An employer-designated qualified evaluator (meeting requirements similar to those for employer crane operator evaluators) assesses the individual and determines that they meet the qualification requirements. The employer shall provide written documentation of the qualification.

Signal Person Qualification Requirements

To be considered qualified, the signal person must:

1. Know and understand the types of signals used (e.g., hand, voice, radio, or other communication methods).
2. Be competent in the proper application of the signals used at the worksite.
3. Have a basic understanding of crane operation and limitations, including crane dynamics such as load swing, stopping distances, and boom deflection when hoisting loads.
4. Know and understand the applicable OSHA regulatory requirements.
5. Successfully demonstrate competency through both:
 - An oral or written test; and
 - A practical test.

Documentation of qualification must be maintained and available upon request.

Qualified Rigger

Employers must use a qualified rigger:

- During crane assembly and disassembly operations.
- When employees are engaged in hooking, unhooking, guiding loads, or making the initial connection of a load to a component or structure while within the fall zone.

All materials in these situations must be rigged by a qualified rigger.

Definition of a Qualified Rigger

A qualified rigger must meet the definition of a, meaning an individual who, by possession of a recognized degree, certificate, or professional standing, or by extensive knowledge, training, and experience, has successfully demonstrated the ability to solve or resolve problems relating to the subject matter, the work, or the project.

Procedures for Working in the Vicinity of Overhead Power Line

Before beginning equipment operations near overhead power lines rated up to 350 kV, the employer must complete the following steps:

Identify and Define the Work Zone

The employer shall establish the work zone using one of the following methods:

Option A: Demarcated Boundary

- Clearly mark boundaries using flags, barricades, range limit devices, or range control warning devices.
- Prohibit the operator from operating equipment beyond these established boundaries.

Option B: Maximum Working Radius

- Define the work zone as the area within the equipment's maximum working radius.

Determine Proximity to Power Lines

The employer must determine whether any part of the equipment, load line, or load—when operated to its maximum working radius—could come within 20 feet of an overhead power line.

If yes, one of the following options must be implemented:

Option 1: De-energize and Ground

- De-energize the power line.
- Visibly ground the line.
- Confirm de-energization and grounding with the utility owner/operator.

Option 2: Maintain 20-Foot Clearance

Ensure no part of the equipment, load line, or load comes within 20 feet of the power line by implementing the protective measures outlined in the Preventing Encroachment/Electrocution section below.

Option 3: Use OSHA Table A Clearance Distances

1. Determine the power line's voltage.
2. Identify the minimum approach distance (MAD) required under OSHA Table A.
3. Determine whether any part of the equipment, load line, or load could come within the MAD while operating at maximum radius.

If encroachment within the MAD is possible, implement the protective measures listed below.

Preventing Encroachment / Electrocutation

The employer must:

1. Conduct a Planning Meeting
Hold a pre-task meeting with the operator and affected workers to review:
 - The location of power lines
 - The required clearances
 - Steps to prevent encroachment and electrocutionUse Non-Conductive Tag Lines
If tag lines are used, they must be non-conductive.
2. Install Warning Systems
Erect and maintain an elevated warning line, barricade, or line of signs in clear view of the operator at:
 - 20 feet from the power line, or
 - The applicable minimum approach distance (Table A), whichever applies.
3. Implement Additional Protective Measures
Implement at least one of the additional safety measures listed in 29 CFR 1926.1408(b)(4), such as:
 - Dedicated spotter
 - Proximity alarm
 - Range control device
 - Insulating link/device

Required Training

The employer must train each operator and crew member on:

1. Procedures to follow in the event of electrical contact with a power line.
2. The presumption that power lines are energized unless confirmed de-energized and visibly grounded by the utility owner/operator.
3. The presumption that power lines are uninsulated unless confirmed otherwise by the utility owner/operator or a registered professional engineer.
4. The limitations of insulating links/devices, proximity alarms, and range control warning devices (if used).
5. Proper grounding procedures and the limitations of grounding as a protective measure.

No equipment shall be operated near overhead power lines until all required planning, evaluation, protective measures, and training have been completed.

Table A – Minimum Clearance Distances

Table A – Minimum Clearance Distances	
Voltage (nominal, kV, alternating current)	Minimum clearance distance (feet)
up to 50	10
over 50 to 200	15
over 200 to 350	20

over 350 to 500	25
over 500 to 750	35
over 750 to 1,000	45
over 1,000	As established by the utility owner/ operator or registered professional engineer who is a qualified person with respect to electrical power transmission and distribution.

Inspections

All cranes and wire hoisting rope are required to be inspected periodically including after any covered equipment has been modified or repaired, upon completion of being assembled (post-assembly), each shift/daily, monthly, and annually/comprehensive scheduled inspections.

Keep clear of the load: workers must be kept clear of the fall zone, which includes but is not limited to the area directly beneath the load where the hoisted materials could fall. Hoisting routes must also minimize exposures to workers of overhead loads. Additionally, the swing radius of the crane (i.e. area of the crane rotating superstructure which could strike a worker) must be protected with warning lines. Safety Devices and Operations Aids: Safety devices and operations aids on cranes, such as crane level indicator, boom and jib stops, horns, boom hoist limiting device, anti-two blocking device, boom angle or radius indicator, and load weighing device, are required on cranes and must be properly operating.

General Safety Rules

Operators shall comply with the following rules while operating the cranes and hoists:

- Do not engage in any practice that will divert your attention while operating the crane.
- Respond to signals only from the person who is directing the lift, or any appointed signal person.
- Obey a stop signal at all times, no matter who gives it.
- Do not move a load over people. People shall not be placed in jeopardy by being under a suspended load. Also, do not work under a suspended load unless the load is supported by blocks, jacks, or a solid footing that will safely support the entire weight.
- Have a crane or hoist operator remain at the controls or lock open and tag the main electrical disconnect switch.
- Ensure that the rated load capacity of a crane's bridge, individual hoist, or any sling or fitting is not exceeded. Know the weight of the object being lifted or use a dynamometer or load cell to determine the weight.

Check that all controls are in the OFF position before closing the main- line disconnect switch. If spring-loaded reels are provided to lift pendants clear off the work area, ease the pendant up into the stop to prevent damaging the wire.

Avoid side pulls. These can cause the hoist rope to slip out of the drum groove, damaging the rope or destabilizing the crane or hoist.

To prevent shock loading, avoid sudden stops or starts. Shock loading can occur when a suspended load is accelerated or decelerated and can overload the crane or hoist. When completing an upward or downward motion, ease the load slowly to a stop.

Operation Rules

At the start of each work shift, operators shall do the following steps before making lifts with any crane or hoist:

1. Test the upper-limit switch. Slowly raise the unloaded hook block until the limit switch trips.
2. Visually inspect the hook, load lines, trolley, and bridge as much as possible from the operator's station; in most instances, this will be the floor of the building.
3. If provided, test the lower-limit switch.
4. Test all direction and speed controls for both bridge and trolley travel.
5. Test all bridge and trolley limit switches, where provided, if operation will bring the equipment in close proximity to the limit switches.
6. Test the pendant emergency stop.
7. Test the hoist brake to verify there is no drift without a load.
8. If provided, test the bridge movement alarm.
9. Lock out and tag for repair any crane or hoist that fails any of the above tests.

Moving a Load

1. Center the hook over the load to keep the cables from slipping out of the drum grooves and overlapping, and to prevent the load from swinging when it is lifted. Inspect the drum to verify that the cable is in the grooves.
2. Use a tag line when loads must traverse long distances or must otherwise be controlled. Manila rope may be used for tag lines.
3. Plan and check the travel path to avoid personnel and obstructions.
4. Lift the load only high enough to clear the tallest obstruction in the travel path. Start and stop slowly.
5. Land the load when the move is finished. Choose a safe landing.

Never leave suspended loads unattended. In an emergency where the crane or hoist has become inoperative, if a load must be left suspended, barricade and post signs in the surrounding area, under the load, and on all four sides. Lock open and tag the crane or hoist's main electrical disconnect switch.

Parking a Crane or Hoist

1. Remove all slings and accessories from the hook. Return the rigging device to the designated storage racks.
2. Raise the hook at least 2.1 m (7 ft.) above the floor.
3. Store the pendant away from aisles and work areas or raise it at least 2.1 m (7 ft.) above the floor.
4. Place the emergency stop switch (or push button) in the OFF position.

Rigging

Do the following when rigging a load:

- Determine the weight of the load. Do not guess. Determine the proper size for slings and components. Do not use manila rope for rigging.
- Make sure that shackle pins and shouldered eye bolts are installed in accordance with the manufacturer's recommendations.
- Make sure that ordinary (shoulder-less) eye bolts are threaded in at least 1.5 times the bolt diameter.
- Use safety hoist rings (swivel eyes) as a preferred substitute for eye bolts wherever possible.
- Pad sharp edges to protect slings. Remember that machinery foundations or angle-iron edges may not feel sharp to the touch but could cut into rigging when under several tons of load. Wood, tire rubber, or other pliable materials may be suitable for padding.
- Do not use slings, eye bolts, shackles, or hooks that have been cut, welded, or brazed.
- Install wire-rope clips with the base only on the live end and the U-bolt only on the dead end. Follow the manufacturer's recommendations for the spacing for each specific wire size.
- Determine the center of gravity and balance the load before moving it. Initially lift the load only a few inches to test the rigging and balance.

27. Demolition Operations

Preparatory Operations:

75% of all OSHA demolition citations are for failure to comply with mandatory site preparation. Additionally, 50% of all site preparation citations are for failure to have an engineering survey completed prior to start of demolition. Therefore, and pursuant to OSHA regulations, prior to the start of demolition operations, an engineering survey will be completed by a competent person.

The engineering survey of the structure will determine the condition of:

- The Framing
- Floors and Walls
- Possibility of unplanned collapse of any portion of the structure
- Any adjacent structure where employees may be exposed shall also be similarly checked.

EE Reed East Coast will have evidence, in writing, verifying that such a survey has been performed.

When employees are required to work within a structure to be demolished which has been damaged by fire, flood, explosion, or other cause, the walls or floor will be shored or braced.

All electric, gas, water, steam, sewer, and other service lines shall be shut off, capped, or otherwise controlled, outside the building line before demolition work is started. In each case, any utility company which is involved shall be notified in advance.

If it is necessary to maintain any power, water or other utilities during demolition, such lines shall be temporarily relocated, as necessary, and protected.

EE Reed East Coast will determine if any type of hazardous chemicals, gases, explosives, flammable materials have been used in any pipes, tanks, or other equipment on the property. When the presence of any such substances is apparent or suspected, testing and purging must be performed, and the hazard eliminated before demolition is started. Where a hazard exists from fragmentation of glass, such hazards shall be removed.

Fall Protection

Where a hazard exists to employees falling through wall openings, the opening shall be protected to a height of approximately 42 inches. All floor openings, not used as material drops, shall be covered over with material substantial enough to support the weight of any load which may be imposed. Secure hole covers to prevent its accidental movement.

Controlled Access Zone (CAZ)

When debris is dropped through holes in the floor the drop area must be completely enclosed with barricades not less than 42 inches high and not less than 6 feet back from the projected edge of the opening above. Signs warning of the hazard of falling materials shall be posted at

each level. Removal shall not be permitted in this lower area until debris handling ceases above.

Employee entrances to multi-story structures being demolished shall be completely protected by sidewalk sheds providing protection from the face of the building for a minimum of 8 feet. All such canopies shall be at least 2 feet wider than the building entrances or openings.

Commencing Demolition

Demolition of exterior walls and floor construction shall begin at the top of the structure and proceed downward.

Exceptions: for the cutting of holes in floors for chutes, holes through which to drop materials, preparation of storage space, and similar necessary preparatory work.

Stairs, Passageways and Ladders

Only those stairways, passageways, and ladders, designated as means of access to the structure of a building, shall be used. Other access ways shall be entirely closed at all times. Means of access must be periodically inspected and maintained in a clean and safe condition.

Chutes

- No material shall be dropped to any point lying outside the exterior walls of the structure unless the area is effectively protected.
- All materials chutes at an angle of more than 45 deg. must be entirely enclosed. The openings shall not exceed 48 inches in height measured along the wall of the chute.
- At all stories below the top floor, such openings shall be kept closed when not in use.
- When operations are not in progress, the area surrounding the discharge end of a chute shall be securely closed off.
- Any chute opening, into which workmen dump debris, shall be protected by a guardrail.
- Any space between the chute and the edge of openings in the floors through which it passes shall be solidly covered over.
- Where the material is dumped from mechanical equipment or wheelbarrows, a securely attached toeboard or bumper, not less than 4 inches thick and 6 inches high, shall be provided at each chute opening.

Removal of Walls or Masonry Sections

No wall section more than one story in height, shall be permitted to stand alone without bracing. All walls shall be left in a stable condition at the end of each shift.

Structural or load-supporting members on any floor shall not be cut or removed until all stories above such a floor have been demolished and removed.

Floor openings within 10 feet of any wall being demolished shall be planked solid, except when employees are kept out of the area below.

Walkways or ladders shall be provided to enable employees to safely reach or leave any scaffold or wall.

Manual Removal of Floors

Openings cut in a floor shall extend the full span of the arch between supports. Stringers of ample strength shall be installed to support the flooring planks, and the ends of such stringers shall be supported by floor beams or girders, and not by floor arches alone. Planks shall be laid together over solid bearings with the ends overlapping at least 1 foot. When floor arches are being removed, employees shall not be allowed in the area directly underneath, and such an area shall be barricaded to prevent access to it. Demolition of floor arches shall not be started until they, and the surrounding floor area for a distance of 20 feet, have been cleared of debris and any other unnecessary materials.

Equipment Removal of Walls, Floors and Material

Mechanical equipment shall not be used on floors or working surfaces unless such floors or surfaces are of sufficient strength to support the imposed load. Floor openings shall have curbs or stop-logs to prevent equipment from running over the edge.

Storage

The storage of waste material and debris on any floor shall not exceed the allowable floor loads. In buildings having wooden floor construction, the flooring boards may be removed from not more than one floor above grade to provide storage space for debris, provided falling material is not permitted to endanger the stability of the structure. When wood floor beams serve to brace interior walls or free-standing exterior walls, such beams shall be left in place until other equivalent support can be installed to replace them. Storage space into which material is dumped shall be blocked off, except for openings necessary for the removal of material. Such openings shall be kept closed at all times when material is not being removed.

Removal of Steel Construction

- Steel construction shall be dismantled column length by column length, and tier by tier (columns may be in two-story lengths).
- Any structural member being dismembered shall not be overstressed.

Mechanical Demolition

- No workers shall be permitted in any area, which can be adversely affected by demolition operations, when balling or clamming is being performed.
- Only those workers necessary for the performance of the operations shall be permitted in this area at any other time.
- The weight of the demolition ball shall not exceed 50 percent of the crane's rated load.
- The crane boom and loadline shall be as short as possible.
- During demolition, continuing inspections by a competent person shall be made as the work progresses to detect ongoing hazards.
- No employee shall be permitted to work where such hazards exist until they are corrected by shoring, bracing, or other effective means.

28. Concrete Construction

EE Reed East Coast will work with the goal that all concrete construction and masonry work will meet the requirements of ANSI A10.9 "Safety Requirements for Concrete Construction and Masonry Work".

General Procedures

- Backup signal alarms will be provided on concrete trucks or signalmen will be used to guide trucks.
- Use of spotters for all trucks when backing up into unloading area
- Patent jacks and other shoring devices will be carefully selected to provide maximum support.
- Forms will be of sufficient strength to prevent collapse when placing concrete.
- Ramps used to carry Georgia buggies, wheelbarrows, etc. will be well secured and of sufficient strength.
- Incline ramps will not exceed 10%. Adequate guardrails will be installed.

Construction loads shall be placed on a concrete structure or portion of a concrete structure unless the EE Reed East Coast determines, based on information received from a person who is qualified in structural design, that the structure or portion of the structure is capable of supporting the loads. Qualified person must determine if concrete structure can support a load.

All protruding reinforcing steel, onto and into which employees could fall, shall be guarded to eliminate the hazard of impalement. The most common protective systems are called rebar caps. Only rebar caps designed to provide impalement protection, such as those containing steel reinforcement should be used. Additionally, a 2x4 with proper bracing can be used over exposed rebar.

Only employees essential to the operation are permitted behind the jack during tensioning operations. Signs and barriers will be installed to limit employee access to the post-tensioning operations.

When applying cement, sand, and water mixture through a pneumatic hose; employees must wear head and face protection meeting the requirements of this safety program manual.

Masonry saws:

Must be guarded with a semicircular enclosure over the blade. A method for containing broken blade fragments must be incorporated into the design of the semicircular guard.

- Consider using a wet-cutting method to reduce exposure to respirable dust particles.
- Ensure guards are in place before use. Inspect blades before use.
- Ensure proper grip on tool (if portable), and on piece being cut (clamp it down).
- Keep non-essential personnel away from cutting operations. Avoid kickback or lock-in situations.

PPE Requirements

- Wear approved eye protection – glasses or goggles.
- Wear a hard hat.
- Wear steel toe shoes meeting the requirements of ASTM F2413 for impact protection throughout the toe area.
- Wear hearing protection.
- Wear face shields when exposed to flying debris
- Wear respirators to protect against respirable silica particles.
- Eye wash stations must be in the work area

Bulk Storage Bins

Bulk storage bins, containers, and silos shall be equipped with the following:

1. Conical or tapered bottoms;
2. Mechanical or pneumatic means of starting the flow of material.

No employee shall be permitted to enter storage facilities unless the ejection system has been shut down, locked out, and tagged to indicate that the ejection system is not to be operated.

Concrete mixers

If equipped with one cubic or larger loading skips shall be equipped with the following:

1. A mechanical device to clear the skip of materials.
2. Guardrails installed on each side of the skip.

Powered Trowel

Powered and rotating type concrete troweling machines that are manually guided shall be equipped with a control switch that will automatically shut off the power whenever the hands of the operator are removed from the equipment handles.

Concrete buckets

If quipped with hydraulic or pneumatic gates must have positive safety latches or similar safety devices installed to prevent premature or accidental dumping.

Concrete buckets shall be designed to prevent concrete from hanging up on top and the sides.

- No employees will be permitted to ride concrete buckets.
- No employees are permitted to work under concrete buckets while buckets are elevated or lowered into position.

Concrete Washout

- Washout locations to be provided and labeled with signage
- Concrete truck drivers to safely wash out their trucks from the standing platform on all trucks
- Truck drivers must be wearing 100% PPE when outside of the truck

Portland Cement Safety:

Portland cement is a generic term used to describe a variety of building materials valued for their strong adhesive properties when mixed with water. Employees who work with portland cement are at risk of developing skin problems, ranging from mild and brief to severe and chronic. Wet portland cement can damage the skin because it is caustic, abrasive, and absorbs moisture. Portland cement also contains trace amounts of hexavalent chromium [Cr(VI)], a toxin harmful to the skin. Dry portland cement is less hazardous to the skin because it is not as caustic as wet cement.

Wet portland cement can cause caustic burns, sometimes referred to as *cement burns*. In severe cases, these burns may extend to the bone and cause disfiguring scars or disability.

- Skin contact with wet portland cement can also cause dermatitis.
- Signs and symptoms of dermatitis can include itching, redness, swelling, blisters, scaling, and other changes in the normal condition of the skin.

Employees working with the following, should take precautions to protect themselves from adverse health effects of working with portland cement:

- Concrete
- Mortar
- Plaster
- Stucco
- Grout
- Terazzo

PPE such as boots and gloves for jobs involving exposure to portland cement and ensure these items are maintained in a sanitary and reliable condition when not in use.

EE Reed East Coast will make washing facilities available for employees exposed to portland cement. Washing facilities must provide clean water, non-alkaline soap, and clean towels.

EE Reed East Coast will train employees exposed to portland cement on:

- The hazards associated with exposure to portland cement, including hazards associated with the cement's Cr(VI) content.
- Preventive measures, including proper use and care of PPE and the importance of proper hygiene practices.
- Employee access to hygiene facilities, PPE, and information (including safety data sheets SDSs).

Lockout/Tagout Procedures

No employee is permitted to perform maintenance or repair activity on equipment used for concrete and masonry construction where the inadvertent operation of the equipment could occur and cause injury, unless all potentially hazardous energy sources have been locked out and tagged.

Cast-In-Place Concrete:

Formwork will be designed, fabricated, erected, supported, braced and maintained so that it will be capable of supporting without failure all vertical and lateral loads that may be anticipated to be applied to the formwork.

Erected shoring equipment shall be inspected immediately prior to, during, and immediately after concrete placement. Shoring equipment that is found to be damaged or weakened after erection, such that its strength is reduced will be immediately reinforced. The sills for shoring shall be sound, rigid, and capable of carrying the maximum intended load. All base plates, shore heads, extension devices, and adjustment screws shall be in firm contact, and secured when necessary, with the foundation and the form.

Removal of Formwork

Forms and shores (except those used for slabs on grade and slip forms) shall not be removed until the employer or required engineer determines that the concrete has gained sufficient strength to support its weight and superimposed loads. Such determination shall be based on compliance with one of the following:

- The plans and specifications stipulate conditions for removal of forms and shores, and such conditions have been followed, or the concrete has been properly tested with an appropriate ASTM standard test method designed to indicate the concrete compressive strength, and the test results indicate that the concrete has gained sufficient strength to support its weight and superimposed loads.
- Reshoring must not be removed until the concrete being supported has attained adequate strength to support its weight and all loads in place upon it.

Precast Concrete

No employee shall be permitted under precast concrete members being lifted or tilted into position except those employees required for the erection of those members. Lifting inserts which are embedded or otherwise attached to precast concrete members, shall be capable of supporting at least four times the maximum intended load.

Limited Access Zones

The limited access zone shall be established prior to the start of construction of the wall.

- The limited access zone shall be equal to the height of the wall to be constructed plus four feet and shall run the entire length of the wall. masonry wall is being constructed.
- The limited access zone shall be established on the side of the wall which will be unscaffolded.
- The limited access zone shall be restricted to entry by employees actively engaged in constructing the wall.
- The limited access zone shall remain in place until the wall is adequately supported to prevent overturning and to prevent collapse unless the height of wall is over eight feet.
- Bracing installed on masonry walls over 8'.

29. Signs, Signals, and Barricades

Signs and symbols must be visible at all times when work is performed. Signs will be removed or covered when hazard no longer exists.

Danger Signs

- Must be used only where an immediate hazard exists and must be made in accordance with ANSI requirements.
- Danger signs shall have red as the predominating color for the upper panel; black outline on the borders; and a white lower panel for additional sign wording.

Caution Signs

- Caution signs must be used only to warn against potential hazards or to caution against unsafe practices.
- Caution signs shall have yellow as the predominating color; black upper panel and borders; yellow lettering of "caution" on the black panel; and the lower yellow panel for additional sign wording. Black lettering shall be used for additional wording.

Traffic Signs

Construction areas shall be posted with legible traffic signs at points of hazard. Must conform to the MUTCD (Manual on Uniform Traffic Control Devices) Standards

Accident Prevention Tags

Used as a temporary means of warning employees of an existing hazard, such as defective tools, equipment, etc. They shall not be used in place of, or as a substitute for, accident prevention signs.

Traffic Flagging

- Flaggers should wear high visibility clothing with a background of fluorescent orange-red or yellow-green and retro-reflective material of orange, yellow, white, silver, or yellow-green.
- Check the label or packaging to ensure that the garments are performance ANSI class 2 or 3.
- Drivers should be warned in advance with signs that there will be a flagger ahead.
- Flaggers should use STOP/SLOW paddles, paddles with lights, or flags (flags should be used only in emergencies.)
- The STOP sign should be octagonal with a red background and white letters and border.
- The SLOW sign is the same shape, with an orange background and black letters and a border.
- Flaggers should be trained and/or certified and use the signaling methods required by the authority in charge.
- Workers on foot, equipment operators, and drivers in internal work zones need to know the routes that construction vehicles will use.

- Equipment operators and signal persons need to know the hand signals used on the worksite.

To Stop Traffic

The flagger shall face traffic and extend the STOP sign paddle in a stationary position with the arm extended horizontally away from the body. The free arm should be raised with the palm toward approaching traffic.

To Direct Stopped Traffic to Proceed

The flagger shall face traffic with the SLOW paddle held in a stationary position with the arm extended horizontally away from the body. The flagger should motion with the free hand for traffic to proceed.

To Alert or Slow Traffic

The flagger shall face traffic with the SLOW sign paddle held in a stationary position with the arm extended horizontally away from the body.

- The flagger may motion up and down with the free hand, palm down, indicating that the vehicle should slow down.
- Must be used in accordance with MUTCD requirements.

Barricades may be used to mark any of the following conditions:

- A roadway ends
- A ramp or lane closed for operational purposes, or
- The permanent or semi-permanent closure or termination of a roadway.

30. Welding and Hot Work

Hot work operations and fire prevention precautions, including permits and fire watches, shall be in accordance with NFPA 51B, Standard for Fire Prevention During Welding, Cutting, and Other Hot Work.

Fire Safety Plan Management

Each individual company or contractor will be responsible for the accountability of its employees; establishing pre-designated muster points, and for training their employees.

Hot Work Procedure

The following is a comprehensive outline of EE Reed East Coast Hot Work Policy. The goal of our Hot Work Policy is to control our heat sources and ensure that they do not come in contact with combustible or flammable materials.

When objects are to be heated, other fire hazards in the nearby vicinity must be taken to a safe location.

Suitable fire extinguishing equipment must be immediately available in the work area and shall be maintained in a ready to use fashion.

Welding Quality and Safety Inspections

Before beginning any welding tasks, conduct thorough safety checks and carefully inspect all welding equipment. This includes examining machines, cables, torches, and personal protective equipment for any signs of damage, wear, or malfunction.

Welding

All gas welding equipment and connections should be kept free from grease and oil. (oxygen will explode upon contact with oil or grease). Oily and greasy gloves may bring about the same effect, besides making it difficult to handle the cylinders. Never roll tanks on the floor, nor attempt to carry them by hand or hoist unless properly slung. Use the skid provided when unloading cylinders from the truck. After unloading tank, the cylinder must be securely chained. Securely fasten with a chain the acetylene and oxygen tanks in an upright position where there is no danger of their falling or being bumped.

Use only standard green oxygen hose with right-hand couplings, together with red acetylene hose with left-hand thread.

Blow out the tank valve before attaching the regulator. Never use compressed air for blowing out equipment as air may contain some oil and moisture. Use oxygen to blow out the oxygen hose and acetylene to blow out the acetylene hose.

When changing empty tanks for full ones:

1. Shut off valve on empty tanks.
2. Release thumb screw on regulator.

3. Disconnect regulator, blow out tank valve and connect on full tank.
4. Stand on opposite side of tank, point the acetylene valve outlet away from the oxygen tank and face away from the gauge while opening the tank valve.
5. Adjust thumb screw on regulator to proper pressure, making sure that you do not have excess oxygen, which causes unnecessary sparks in operation.
6. Replace protective cap on empty tank.

Be sure that the end of your torch is cleaned before attempting to light. Use only friction lighters. Do not put the materials in such a position as to permit sparks, hot metal, or the severed section of metal to fall on the gas supply hose or the feet of any employee. At the completion of the work, the welder may make a careful inspection of the job site to ensure that hot articles have not been left smoldering which might later develop into a serious fire. Proper goggles and gloves shall be worn. Employee must wear steel-toe shoes.

Electric Arc Welding

Whenever possible, welding operations should be carried on inside a regular welding booth. If work must be performed outside a booth, the Arc shall be effectively screened to prevent injury to eyes and others.

Before entering the welding area, an effective warning, such as shouting, shall be given, so that the operator may be aware of your presence and help you to avoid a sudden flash or other injury. Like the welding operator, the person entering the welding area is to also wear required eye protection.

The welding of galvanized material requires the operator to protect himself with a specially designed airline respirator, which fits under his helmet.

- Deposit short ends of welding rods in the containers provided for that purpose, to prevent burning holes in your shoes or starting fires.
- Place the electric holder where it cannot cause an arc when not in use.
- Prevent injury to yourself and others from short circuits by only using welding cables that are in good condition.
- Only properly authorized operators shall use welding equipment. Never attempt to repair welding equipment yourself.
- Helmets and shields will be used with all electrical welding. Do not remove your helmet while bending over a hot weld, or while chipping slag. Safety shoes must be worn.

Compressed Gas Cylinders

Transportation, Moving and Storing:

1. Valve protection caps shall be in place and secured.
2. When cylinders are hoisted, they shall be secured on a cradle, slingboard, or pallet.
3. Cylinders shall be moved by tilting and rolling them on their bottom edges.
4. When cylinders are transported by powered vehicles, they shall be secured in a vertical position.
5. Unless cylinders are firmly secured on a special carrier intended for this purpose, regulators shall be removed, and valve protection caps put in place before cylinders are moved.
6. A suitable cylinder truck, chain, or other steadying device shall be used to keep cylinders from being knocked over while in use.

7. When work is finished, when cylinders are empty, or when cylinders are moved at any time, the cylinder valve shall be closed.
8. Compressed gas cylinders shall be secured in an upright position at all times except, if necessary, for short periods of time while cylinders are actually being hoisted or carried.
9. Oxygen cylinders in storage shall be separated from fuel-gas cylinders or combustible materials a minimum distance of 20 feet or by a noncombustible barrier at least 5 feet high having a fire-resistance rating of at least one-half hour.

Welding:

1. Keep cylinders far enough away from the welding or cutting operation so that sparks, hot slag, or flame will not reach them.
2. Cylinders shall be placed where they cannot become part of an electrical circuit.
3. Electrodes shall not be struck against a cylinder to strike an arc.
4. Cylinders containing oxygen or acetylene, or other fuel gas shall not be taken into confined spaces.
5. Do not use defective or damaged cylinders.
6. Before a regulator to a cylinder valve is connected, the valve shall be opened slightly and closed immediately.
7. The person cracking the valve shall stand to one side of the outlet, not in front of it.
8. The valve of a fuel gas cylinder shall not be cracked where the gas would reach welding work, sparks, flame, or other possible sources of ignition.
9. Fuel gas hose and oxygen hose shall be easily distinguishable from each other.
10. The contrast may be made by different colors or by surface characteristics readily distinguishable by the sense of touch.
11. Oxygen and fuel gas hoses shall not be interchangeable.
12. A single hose having more than one gas passage shall not be used.
13. All hose in use, carrying acetylene, oxygen, or any gas or substance which may ignite shall be inspected at the beginning of each working shift.

HOT WORK PERMIT

EE Reed East Coast Hot Work Permit will be required for cutting, welding, grinding and open flames

NOTE: Hot Work will be performed only after a careful and complete review of all safety precautions and site preparation actions have proven it safe to begin work.

Job name: _____

Supervisor in charge of hot work _____

Requested start date: _____ Time work started _____

Time inspection completed: _____ Time work completed: _____

Description and location of hot work being performed:

1.The location of the work to be done will be examined:

Were combustible materials removed from the area, covered or shielded? _____

Have all flammable dusts, vapors and liquids been cleared from the hot work area? _____

Have all unpurged tanks or equipment previously containing flammable material been removed? _____

Will the work be confined to the area specified in this permit? _____

Is ventilation adequate or is additional ventilation necessary? _____

Are there any flammable substances in the affected area or flame "drop zone?" _____

2.The following safeguards will be provided:

Have all floors and surroundings been swept, clean, and wet down if required? _____

Does Fire Watch have at least a 20# ABC Dry Chemical fire extinguisher? _____

Do smoke detectors or sensors have to be disabled? _____

Have affected individuals in the work area been notified? _____

3.If the work involves spark producing equipment the following will be done:

Are sparks directed away from people and combustibles?

Have all non-combustibles been protected with fire blankets, curtains, etc.?

Has a Fire Watch been designated?

Name of Fire Watch

Has flame- or spark- producing equipment been inspected and in good condition? _____

Have arrangements been made to monitor the areas around and below the hot work during breaks and for at least one-half hour after completion of work? _____

Have all affected personnel been made aware of all hazards? _____

List hazards:

Signature of responsible person requesting Hot Work Permit:

Printed name of responsible person:

31. Silica Exposure Control Plan

Applicability

This Written Exposure Control Plan (Plan) applies to EE Reed East Coast's personnel who are potentially exposed to airborne concentrations of respirable crystalline silica (silica) because of their work activities or proximity to the work locations where airborne silica is being emitted. This Plan also applies to EE Reed East Coast superintendents, foremen, or safety personnel who may be responsible for overseeing a subcontractor's operations that have the potential to expose personnel to airborne concentrations of silica at or above regulatory and industry action levels and exposure limits.

Scope

This Plan describes the hazards associated with projects involving potential exposure to airborne concentrations of silica and the issues to be addressed during these projects. These projects include, but are not limited to:

- Handheld power saws used to cut concrete, asphalt, concrete masonry block, sheet rock, gypsum fiber roof board, or any other product containing quartz.
- Rig-mounted or free-standing core saws or drills (including impact and rotary hammer drills) used to penetrate concrete, concrete masonry block, sheet rock, gypsum fiber roof board, or any other structural component or product containing quartz.
- Jackhammers and handheld powered chipping tools used to demolish or modify concrete, concrete masonry block, or any other structural component or product containing quartz.
- All housekeeping operations associated with the activities described above.

EE Reed East Coast employees who work in proximity to silica-related operations must be aware of safe work practices and take all necessary precautions associated with avoiding and minimizing airborne silica exposure.

Regulatory Review

Occupational Safety and Health Administration (OSHA) 29 CFR 1926.1153: Respirable Crystalline Silica (Construction Industry) and 29 CFR 1910.1053: Respirable Crystalline Silica (General Industry), contain regulatory requirements specific to respirable crystalline silica. This Written Exposure Control Plan is developed in accordance with the requirements in 29 CFR 1926.1153(g).

Project Planning & Training Requirements

EE Reed East Coast employees who anticipate working on projects where they could be exposed to airborne silica will be provided training in silica hazards in accordance the EE Reed East Coast program established to comply with the hazard communication standard (29 CFR 1910.1200). Each employee will have access to labels on containers of crystalline silica and safety data sheets, and be provided information on the health hazards of silica including cancer, lung effects, immune system effects, and kidney effects. In addition, EE Reed East Coast employees will be provided training and information regarding specific activities identified in this

Plan that could result in airborne silica exposure, and the specific engineering controls, work practices and respiratory protection requirements to mitigate the potential airborne silica exposures. This training will provide a discussion of silica hazards, initial exposure determination either by complying with 29 CFR 1926.1153 Table 1 requirements or air monitoring, specific engineering and work practice control measures, personal protective equipment (PPE), and medical surveillance requirements. The training will also identify the EE Reed East Coast competent person for silica exposure identification and determination of control requirements. All EE Reed East Coast employees will be provided with access to a copy of 29 CFR 1910.1153 and be trained on the contents of 29 CFR 1926.1153.

Medical Surveillance Requirements

EE Reed East Coast shall institute medical surveillance for any employees required by this Plan to wear a respirator 30 or more days per year.

Initial medical surveillance consists of medical and work history with emphasis on: past, present, and anticipated exposure to silica, dust and other agents affecting the respiratory system; any history of respiratory system dysfunction, including signs and symptoms of respiratory disease (e.g., shortness of breath, cough, wheezing); history of tuberculosis; and smoking status and history; a physical examination with emphasis on the respiratory system; chest X-ray (a single posterior-anterior radiographic projection or radiograph of the chest at full inspiration recorded on either film (no less than 14 x 17 inches and no more than 16 x 17 inches) or digital radiography systems), interpreted and classified according to the International Labour Office (ILO) International Classification of Radiographs of Pneumoconiosis by a NIOSH-certified B Reader; a pulmonary function test to include forced vital capacity (FVC) and forced expiratory volume in one second (FEV1) and FEV1/FVC ratio, administered by a spirometry technician with a current certificate from a NIOSH approved spirometry course; testing for latent tuberculosis infection; and any other tests deemed appropriate by the Occupational Medicine Provider. Subcontractors are responsible for implementing a medical surveillance program for their employees.

Competent Person Requirements

EE Reed East Coast shall identify a competent person to inspect and oversee all activities with potential airborne silica exposure. Subcontractors working on projects within the scope of this Program shall appoint a competent person capable of executing the duties described herein. The competent person must have training in the inspection of work areas and equipment and in the determination of safe working conditions. This person shall have a working knowledge of the 1926.1153 standards, shall be capable of identifying airborne silica hazards, shall determine the need for initial and additional exposure monitoring, shall recommend and implement engineering and work practice controls, shall establish levels of PPE, and shall have the authority to take action to eliminate hazards and correct incidences of noncompliance.

Planning Activities

Projects where anticipated activities involve concrete cutting, grinding, sandblasting, drilling, coring, or other abrasive operations are treated as potential sources for airborne silica exposure. Additionally, existing structures and materials such as sheetrock, any painted surfaces with low volatile organic compounds, tile, brick, or some insulation products may contain silica. Likewise, new material installation may involve silica-containing mortar, paints, or

insulation. Where process knowledge indicates the presence of silica, EE Reed East Coast will either implement all controls required by 1926.1153 Table 1- Exposure Control Methods for Selected Construction Operations or conduct an initial determination in accordance with 29 CFR 1926.1153(d)(2).

Safe Work Practices

The requirements of this section are to be followed by EE Reed East Coast employees, who may be exposed to airborne concentrations of silica at or above the regulatory limits.

Exposure Assessment

EE Reed East Coast will either comply with and implement all controls required by 1926.1153 Table 1- Exposure Control Methods for Selected Construction Operations or conduct an initial determination in accordance with 29 CFR 1926.1153(d)(2).

Communication of Hazards

- Each employee shall be provided training and demonstrate knowledge and understanding of the following:
 1. Health hazards associated with exposure to respirable crystalline silica.
 2. Specific tasks that could result in exposure to respirable crystalline silica
 3. Specific measures that are required to protect employees from exposure to respirable crystalline silica, including engineering controls, work practices, and required use of respiratory protection.
 4. The contents of the 29 CFR 1926.1153
 5. The identity of the competent person
 6. Purpose and description of the medical surveillance program
- A written compliance program shall be made available to all affected employees.
- In addition, notification to owners, contractors, and other personnel working in the area shall be made.

Control Methods

- Engineering and work practice controls, including administrative controls, shall be implemented to reduce and maintain employee exposure to silica at or below the PEL, to the extent that such controls are feasible.
- Where all feasible engineering and work practice controls that can be instituted are not sufficient to reduce employee exposure to or below the PEL, such controls shall be used, nonetheless, to reduce employee exposure to the lowest feasible level (and in conjunction with respiratory protection).
- Respiratory protection shall be selected based on guidance in 1926.1153 Table 1 or based on a Certified Industrial Hygienist's or competent person's assessment of the potential airborne exposure that may be created by the means and methods of work (high energy operations with high airborne dust generation or low energy operations with low dust generation).
- When using mechanical ventilation to control exposure, regularly evaluate the system's ability to effectively control exposure.

- If administrative controls are used to limit exposure, establish and implement a job rotation schedule that includes employee identification as well as the duration and exposure levels at each job or workstation where each affected employee is located.
- A written compliance program shall be established and implemented prior to the start of operations within the scope of this Written Compliance Plan. The written program shall outline the plans for maintaining employee exposure below the PEL.
- Maintain all surfaces as free as possible from accumulations of silica. Select methods for cleaning surfaces and floors that minimize the likelihood of silica becoming airborne (such as using a HEPA vacuum).
- If vacuuming is the method selected, specialized vacuums with HEPA filtration are required. Methods to use and empty vacuums in a manner that minimizes the reentry of silica into the workplace shall be described and used. Use of household vacuums with HEPA filters are not allowed at any time for the collection of dust or debris that contains silica.
- Never use compressed air to remove silica from any surface unless it is used in conjunction with a ventilation system designed to capture the airborne dust created while using the compressed air.
- Employees shall not eat, drink, smoke, chew tobacco or gum, or apply cosmetics in any areas where exposure to silica is above the PEL (in other words, regulated areas).
- Do not allow employees to leave the workplace wearing any protective clothing or equipment that is required to be worn during their work shift without HEPA vacuum removal of dust.
- Where feasible, install shower facilities and require employees who work in regulated areas to shower at the end of their work shift. Also provide an adequate supply of cleaning agents and clean towels.
- Provide hand washing facilities for use by employees working in regulated areas. Furthermore, require employees to wash their hands and face at the end of the work shift and prior to eating or entering eating facilities, drinking, smoking, or applying cosmetics.
- Eating facilities or areas shall be provided for employees working in regulated areas. These facilities shall be maintained free of silica contamination and shall be readily accessible to those employees.

Personal Protective Equipment (PPE)

Respiratory protection must be used for the following conditions:

- During periods when employee exposure to airborne silica exceeds the PEL.
- For work operations where engineering and work-practice controls are not sufficient to reduce employee exposure to or below the PEL.
- During periods when an employee requests a respirator.
- During periods when respirators are required to provide interim protection while conducting initial exposure assessments
- Powered air-purifying respirators (PAPR) shall be provided to employees who request such a respirator to use where it will provide adequate protection.

- Employees shall be provided, at no cost, protective work clothing and equipment including cotton coveralls or similar full-body clothing, gloves, hats, shoes or disposable shoe coverlets, face shields, vented goggles, or other appropriate PPE.

32. Fatigue Management

The purpose of this section is to establish general guidelines and criteria for a Fatigue Management Plan specific to the operational needs of EE Reed East Coast operating sites, acknowledging that there may be a wide range of variables that affect the operational activities.

Pursuant to this program, fatigue is defined as – the temporary loss of power to respond that is induced in a sensory receptor or motor end organ by continued stimulation. Signs of fatigue include tiredness even after sleep, psychological disturbances, loss of energy, and inability to concentrate.

As part of the fatigue management plan, EE Reed East Cost will:

1. Identify potential sources of risk associated with fatigue,
2. Assess the level of risk associated with these risk factors,
3. Identify appropriate risk treatments to address the identified risk factors including time frames and accountabilities for implementation, and
4. Evaluate the effectiveness of these risk treatments, once they have been implemented.

Each site will establish appropriate parameters for maximum working hours to comply with the appropriate Federal/State regulatory requirements pertaining to work hours if these requirements exceed the ANSI/API standard.

Investigations of accidents, property damage, and near-miss accidents will consider potential fatigue factors in the process of determining causal factors during the accident investigation process.

Fatigue management is a shared responsibility between employers and employees.

Employers	Employees
Ensure employees have plenty of time off between shifts, at least 12 hours, to get rest	Should report rested for work and be fit for duty
Allow employees to feel safe reporting fatigue-related issues within a non-punitive structure	Recognize their own personal limits (not the same for everyone)
Create systems to gather data, review data and apply findings to improve processes	Report issues through appropriate mechanisms
Educate employees on causes and consequences of fatigue, how to identify fatigue symptoms, and the importance of keeping each other safe	Look out for each other, note signs or symptoms in co-workers and encourage taking action; buddy system
Get input from employees on fatigue hazards and mitigation strategies	Recognize fatigue as a hazard to promote a culture of safety
"Walk the talk"	Managers and supervisors need to demonstrate the importance of these activities for themselves, helping create buy-in

33. Standard Work Procedures

High Risk Activity (HRA) Planning

Prior to the commencement of the work, including mobilization and site set-up activities, EE Reed will perform hazard identification and risk assessment for all high-risk work. EE Reed will be responsible for ensuring that effective procedures and assessment systems are in place to control hazards and mitigate risks to as low a level as possible, and to meet all the health and safety management requirements under this specification. The following activities are considered HRAs:

- Confined spaces;
- Driving and traffic management on- and off-site;
- electrical and mechanical energy storage systems;
- energy isolation (LOTO);
- ground disturbance including excavation and trenching;
- hazardous materials;
- fatigue management;
- lifting operations (crane safety, rigging, powered industrial equipment);
- material handling (powered industrial equipment & rigging);
- mobile equipment (powered industrial equipment);
- noise (excess of 85dBA)
- working at heights (fall protection, boom and scissor lifts and scaffolding); and
- temperature extremes (heat/cold stress).

For each of these high-risk activities, the Hierarchy of Hazard Controls will be followed in the prescribed order when determining suitable controls to mitigate potential SIFs.

- **Elimination:** physically remove or eliminate a potential hazard before it occurs. These are often identified during pre-planning and is the most effective form of hazard control.
Substitution: replace the hazard (i.e., substitution of a product that is less hazardous, or using the same product but in a different form)
- **Engineering Controls:** isolate workers from the hazard (i.e., establishing a controlled access zone (CAZ) when overhead work is taking place to prevent struck-by hazards)
- **Administrative Controls:** change the way work is performed as a matter of process (e.g., utilizing enclosures, shift rotation, signage, barriers, etc.)
- **Personal Protective Equipment (PPE):** individually worn equipment designed to protect a worker. This is the least effective form of hazard control.

The focus should be on identifying, eliminating, and substituting the risk associated during the preconstruction phase where possible. The early identification and plan of action will be communicated with the workforce.

Permits

Permits are required for the following items:

- Hotwork
- Confined space
- Excavation Work/Ground disturbances
- Critical lifts
- Energized Electrical Work/ Energy Isolation
- Ladder use

Specialized work such as ground disturbance, hot work, and confined space access require a permit authorized by an EE Reed superintendent.

34. Environmental Spill Response

Hazardous Substance Management

All hazardous substances, including chemical wastes, are to be managed in a way that prevents release. The following general requirements are to be followed. They include:

Container Management

- All hazardous substance containers must be in good condition and compatible with the materials stored within.
- All hazardous substance containers must be accessible and spacing between containers must provide sufficient access to perform periodic inspections and respond to releases.
- Empty hazardous substance containers (drums) must have all markers and labels removed and the container marked with the word 'empty'.
- Any spills on the exterior of the container must be cleaned immediately.
- Flammable materials stored or dispensed from drums or totes must be grounded to prevent static spark.
- Do not overfill waste drums. 4" of headspace must remain to allow for expansion.

Good Housekeeping

- All hazardous substances must be stored inside buildings or under cover;
- Store hazardous substances not used daily in cabinets, or in designated areas;
- All chemicals that are transferred from larger to smaller containers must be transferred by use of a funnel or spigot.
- All hazardous substance containers should be closed while not in use
- Use drip pans or other collection devices to contain drips or leaks from dispensing containers or equipment
- Implement preventative maintenance activities to reduce the potential for release from equipment
- Immediately clean up and properly manage all small spills or leaks
- Periodically inspect equipment and hazardous substance storage areas to ensure leaks or spills are not occurring
- Use signage to identify hazardous substance storage or waste collection areas
- Keep all work areas and hazardous substance storage areas clean and in good general condition.

Secondary containment

- Store all bulk chemicals (≥ 55 gallons) within appropriate secondary containment, or any sized chemical if there is a potential for release to the environment.
- Secondary containment should be checked periodically, and any spills identified in secondary containment must be immediately cleaned up and removed.

Marking/labeling

- Ensure all hazardous substances, including chemical wastes, are properly marked and labeled in accordance with all federal, state and local regulations.
- Ensure that hazardous substances transferred to small containers are marked with the chemicals name (example- "Isopropyl Alcohol") and hazard (example- "Flammable").

Reporting a Release:

When reporting a release prepare to provide the following information (use spill report form):

- Your name and telephone number from where you are calling;
- Exact address of the release or threatened release;
- Date, time, cause and type of incident (fire, air release, spill, etc.)
- Material and quantity of the release, to the extent known;
- Current condition of the facility;
- Extent of injuries, if any; and
- Possible hazards to the public health and/or environment outside of the facility.

Response Actions in Case of a Spill:

- If possible, shut off the source of the spill immediately.
- Notify spill contact person & other emergency contact(s)
- Use absorbent materials, such as absorbent pads, floor sweeping compound or kitty litter to contain spills that are relatively small in nature and where the spilled chemical and its hazardous properties have been properly identified and assessed.
- Use appropriate personal protective equipment depending on the spill material.
- Cover/block any drains/catch basins in the spill area to prevent material from entering into the stormwater system, sanitary sewer system or septic system.
- If possible, clean up the spill using absorbent materials. Collect these absorbent materials and treat them as hazardous waste.

35. Asbestos Awareness Statement

Purpose

This Asbestos Awareness Statement establishes the requirements and safe-work practices for all employees of the company who may encounter asbestos-containing materials (ACMs) or presumed asbestos-containing materials (PACMs) during construction, renovation, demolition, or maintenance activities.

The intent is to prevent exposure, ensure compliance with federal and state regulations, and protect employees, subcontractors, building occupants, and the public.

Policy Statement

EE Reed is committed to maintaining a safe and healthful work environment.

Asbestos-Containing Materials (ACMs) may be present in building products such as insulation, flooring, mastics, ceiling tiles, drywall joint compound, roofing materials, and various thermal system insulation products. Employees must not disturb ACMs or Presumed Asbestos-Containing Material (PACMs) unless they are properly trained, authorized, and supervised under regulated asbestos work practices.

No employee shall engage in tasks involving ACMs unless:

- They have received the required Asbestos Awareness Training (OSHA Class IV) or higher as applicable.
- The material has been properly identified, tested, or assumed to contain asbestos.
- Appropriate control measures, engineering controls, PPE, and regulatory requirements are in place.

Asbestos Awareness Requirements

All employees who may work near, but not directly disturb, ACMs or PACMs must receive Asbestos Awareness Training annually, including:

- Health effects of asbestos exposure
- Recognition of ACMs in the workplace
- Housekeeping and maintenance procedures
- Avoidance of activities that may disturb ACMs
- Company-specific reporting procedures

Training complies with OSHA 29 CFR 1926.1101.

Procedure: Employees Handling or Working Around ACMs

EE Reed will ensure that the following procedure is followed

Identification and Notification

1. Review building records, asbestos surveys, or testing results before beginning work.
2. If no documentation is available, materials must be treated as PACM until tested by an accredited laboratory.
3. Supervisors must notify employees of the presence and location of ACM or PACM before work begins.

Restricting Work to Authorized Personnel

1. Only employees meeting OSHA training requirements (Class I–IV, depending on task) may handle or disturb ACM.
2. Unauthorized employees must immediately stop work and report potential ACM discovery to a supervisor.

Establishing Safe Work Controls

For any activity involving intentional or incidental disturbance of ACM:

- A competent person must evaluate the site.
- Work area must be isolated using barriers, signage, or containment as required.
- Proper respiratory protection and PPE must be issued.
- Use wet methods, HEPA-filtered tools, and other engineering controls to minimize fiber release.
- Maintain exposure levels below OSHA PEL standards.

Handling, Removal, or Repair

- Only licensed asbestos abatement professionals may perform Class I or Class II work.
- Employees trained in Class III or Class IV work may perform minor repair or maintenance tasks only within the limits of training.
- Waste must be handled as asbestos waste, double-bagged, labeled, and disposed of in compliance with EPA, OSHA, and state regulations.

Emergency Situations

If suspected ACM is accidentally disturbed:

1. Stop work immediately.

2. Evacuate and isolate the immediate area.
3. Notify a supervisor or the safety department.
4. A qualified person will evaluate exposure potential and implement cleanup or response procedures.

Documentation

The following must be maintained:

- Training records
- Exposure assessments
- Air monitoring results (if applicable)
- Waste disposal manifests
- Worksite asbestos surveys

Employee Responsibilities

Employees must:

- Attend all required asbestos training.
- Follow all posted warnings and instructions.
- Never disturb or handle materials suspected to contain asbestos unless authorized.
- Immediately report damaged or deteriorated materials.

Management Responsibilities

Management will:

- Ensure employees receive proper training.
- Provide resources for testing, monitoring, PPE, and regulatory compliance.
- Maintain documentation and ensure communication with building owners and subcontractors.
- Enforce disciplinary action for non-compliance.

36. Signature and Acknowledgement



Receipt of Corporate Safety Program

I have received, reviewed, and understood the contents of EE Reed East Coast Safety Program.

EE Reed East Coast's Corporate Safety Program describes important information about the organization's safety policies and procedures. I understand that I should consult Jorge Castro regarding any questions not answered in the program. Additionally, I acknowledge and agree to observe the safe work practices as outlined as a condition of employment to protect my safety and health. I understand that the safe work practices in this program are not the only rules and procedures that I will be required to follow.

I also understand I am responsible for performing my duties in a safe manner so as not to bring harm to myself and others. I am expected to correct any unsafe act or condition. If I am unable to correct the unsafe act or condition myself, I will consult my supervisor. This manual and the policies and procedures contained herein supersede any and all prior practices, oral or written representations, or statements regarding the terms and conditions of your employment with EE Reed East Coast.

I understand and agree that nothing in the Corporate Safety Program creates or is intended to create a promise or representation of continued employment and that employment at EE Reed East Coast is employment at-will, which may be terminated at the will of either EE Reed East Coast or myself. Furthermore, I acknowledge that this manual is neither a contract of employment nor a legal document. I understand and agree that employment and compensation may be terminated with or without cause and with or without notice at any time by EE Reed East Coast or myself.

I have received the EE Reed East Coast Corporate Safety Program, and I understand that it is my responsibility to comply with the policies contained in this manual and any revisions made to it.

Employee's Printed Name: _____ Employee's Signature: _____
Position: _____ Date: - _____

The signed original copy of this receipt should be given to management - it will be filed in your personnel file. You will receive a copy for your records.