SW-BOOT C21 SW-ENTER SW-MODE SW-DEC SW-INC 100u 6v3 c27 R7 86 U130 (SA) DS3231N c22 LDR2 LDR3 LDR1 DAT_IN CLK_IN ди Б 2V2 AQ2 JJ2 SCF 3A3 R12 R2 R1 To avoid damaging tracks, do not snap off. Use hacksaw to separate boards if required. _ _ R13 ____c1 ____c2 C4 сз LDR4 LDR1 DAT_IN CLK_IN с5 се 83 C7 wyolum.com KlokTHREEjr github.com/wyolum/KlokTHREEjr C9 C10 C12 C11 C13 C14 C16 C15 R15 CONNECT MOAR
LEDS HERE
DATICLK
P2 _ _ R14

https://github.com/wyolum/KlokTHREEjr
www.wyolum.com

Sheet:
File: KlokTHREEjr.kicad_pcb

Title: KlokTHREEjr
Size: A3 Date: 2018-01-08 Rev: rev 1
KiCad E.D.A. kicad no-vcs-found-67ccf7661ubuntu16.04.1 Id: 1/1