open source open source hardware wyolum.com ULL R2 R1 To avoid damaging tracks, do not snap off. Use hacksaw to separate boards if required. R12 _ _ R13 LDR2 LDR3 5V GND LDR4 LDR1 DAT_IN CLK_IN R15 CONNECT MOAR
LEDS HERE
DAT|CLK . _ _ R14 David Pincus www.wyolum.com **WyoLum** Sheet:
File: chromogram.kicad_pcb

Title: ClockFOUR Size: A3 Date: KiCad E.D.A. kicad no-vcs-found-bf44d3961ubuntu16.04.1