PERSONAL PROTECTIVE AND SAFETY EQUIPMENT:

ବ୍ୟକ୍ତିଗତସ୍ୱରକ୍ଷାଏବଂନିରାପତ୍ତାଉପକରଣ:

Maintaining a safe laboratory environment is the responsibility of the P.I., but all employees play a role in observing safety guidelines. Personal protective devices and safety equipment must be provided to all employees under the appropriate circumstances and employees have the responsibility of properly using such equipment.

The SDS will provide some information on the personal protective equipment and safety procedures recommended for a given chemical, though the SDS may not provide sufficient information concerning the specific type of safety equipment required (for example, it may say "use gloves" but not list the best glove to use).

MIOSHA has adopted the American National Standards Institute (ANSI) consensus standards for eye protection and emergency shower and eyewash facilities.

ଏକନିରାପଦଲାବେ।ରଟେ।ରୀପରିବଶେବଜାୟରଖିବାହଉେଛି P. Iରଦାୟିତ୍।,କିନ୍ତୁସମସ୍ତକର୍ମଚାରୀସୁରକ୍ଷାନିର୍ଦ୍ଦଶୋବଳୀପାଳନକରି ବାରଏେକଭୂମିକାଗ୍ରହଣକରନ୍ତି|ସମସ୍ତକର୍ମଚାରୀଙ୍କୁଉପଯୁକ୍ତପରିସ୍ଥିତିରବ୍ୟେକ୍ତିଗତପ୍ରତିରକ୍ଷାଉପକରଣଏବଂସୁରକ୍ଷାଉପକରଣ ଯତାଗାଇଦିଆଯିବାଆବଶ୍ୟକଏବଂଏହିଉପକରଣଗୁଡ଼ିକୁସଠିକ୍ଭାବରବ୍ୟବହାରକରିବାରକର୍ମଚାରୀମାନଙ୍କରଦାୟିତ୍।ଅଛି|ବ୍ୟକ୍ତିଗତପ୍ର ତିରକ୍ଷାଉପକରଣଏବଂପ୍ରଦତ୍ତରାସାୟନିକପାଇଁସୁପାରିଶକରାଯାଇଥିବାସୁରକ୍ଷାପ୍ରଣାଳୀଉପରSDSକିଛିସୂଚନାପ୍ରଦାନକରିବ,ଯଦିଓS DSଆବଶ୍ୟକପ୍ରକାରରନିରାପତ୍ତାଉପକରଣବିଷୟରପେର୍ଯ୍ୟାପ୍ତସୂଚନାପ୍ରଦାନକରିପାରିବନାହିଁ (ଉଦାହରଣସ୍ରୂପ,ଏହାଗ୍ଲତୋଉସ୍ବ୍ୟ ବହାର" କହିପାରକୈନ୍ତୁତାଲିକାନୁହତ୍ଁ|ବ୍ୟବହାରକରିବାକୁସର୍ବତୋତ୍ତମଗ୍ଲତୋଭ୍)|MIOSHAକ୍ଷୁସୁରକ୍ଷାଏବଂଜରୁରୀକାଳୀନସା।ରଏ ବଂଚକ୍ଷୁସୁବିଧାପାଇଁଆମରେକୀୟନ୍ୟାସନାଲଷ୍ଟାଣ୍ଡାର୍ଡଇନଷ୍ଟିଚ୍ୟୁଟ୍ (ANSI) ସହମତିମାନଗ୍ରହଣକରିଛି|

5.3.1 Personal Protective Equipment

Eye and Face Protection. Eye protection must be made available to all employees or visitors to laboratories where chemicals are used and stored. Protective eye and face equipment must be used where there is a reasonable probability of injury from hazardous chemicals that can be prevented from such equipment. The minimum acceptable requirements are for hardened glass or plastic safety spectacles. The P.I. or laboratory supervisor should establish the level of eye protection needed per laboratory activity based on the guidelines below.

Eye and Face Protection: General Description

All eye protective devices must be stamped with "Z87" by the manufacturer if they meet ANSI standards. If the eye protection is not marked, it may not be the most effective protection available.

5.3.1ବ୍ୟକ୍ତିଗତପ୍ରତିରକ୍ଷାଉପକରଣ|

ଆଖିଏବଂଚହେରୋସୁରକ୍ଷା|

ଚକ୍ଷୁସୁରକ୍ଷାସମସ୍ତକର୍ମଚାରୀକିମ୍ବାପରିଦର୍ଶକମାନଙ୍କପାଇଁଉପଲବ୍ଧହବୋଆବଶ୍ୟକଯଉେଁଠାରରୋସାୟନିକପଦାର୍ଥବ୍ୟବହାରଏବ 'ସଂରକ୍ଷଣକରାଯାଇଥାଏ|ତିରକ୍ଷାଆଖିଏବଂମୁଖଉପକରଣବ୍ୟବହାରକରାଯିବାଆବଶ୍ୟକଯଉେଁଠାରବିପଜ୍ଜନକରାସାୟନିକପଦାର୍ଥରୁଆଘ ।ତହବୋରଯଥଷ୍ଟସମ୍ଭାବନାଥାଏଯାହାକୁଏହିପରିଉପକରଣରୁରୋକାଯାଇପାରିବ|କଠିନଗ୍ଲାସ୍କିମ୍ବାପ୍ଲାଷ୍ଟିକ୍ସୁରକ୍ଷାଦୃଶ୍ୟପାଇଁସର୍ବ ନିମ୍ନଗ୍ରହଣୀୟଆବଶ୍ୟକତା|P.I.କିମ୍ବାଲାବୋରଟୋରଟେୋରୀସୁପରଭାଇଜରନିମ୍ନରଦିଆଯାଇଥିବାନିର୍ଦ୍ଦଶୋବଳୀଉପରଆଧାରକରିଲା

ବେତାରଟେତାରୀକାର୍ଯ୍ୟକଳାପପାଇଁଆବଶ୍ୟକଚକ୍ଷୁସୁରକ୍ଷାସ୍ତରପ୍ରତିଷ୍ଠାକରିବାଉଚିତ୍|ଆଖିଏବଂଚହେରୋସୁରକ୍ଷା:ସାଧାରଣବର୍ଣ୍ଣ ନା|ସମସ୍ତଚକ୍ଷୁପ୍ରତିରକ୍ଷାଉପକରଣଯଦିANSI ମାନକପୂରଣକରତେବେନିର୍ମାତାଦ୍ାରା "Z87" ସହିତଷ୍ଟାମ୍ପ୍ହବୋଜରୁରୀ| ଯଦିଆଖିରସୁରକ୍ଷାଚିହ୍ନିତହତୋଇନଥାଏ, ଏହାଉପଲବ୍ଧସବୁଠାରୁପ୍ରଭାବଶାଳୀସୁରକ୍ଷାହତୋଇନପାରତ|

- 1. Safety glasses with side shields offer minimal protection against flying fragments, chips, particles, sand and dirt. When a splash hazard exists, other protective eye equipment should be worn.
 - ପାର୍ଶ୍ୱସୁରକ୍ଷାସହିତସୁରକ୍ଷାଚଷମାଉଡ଼ୁଥିବାଖଣ୍ଡ, ଚିପ୍ସ, କଣିକା, ବାଲିଏବଂମଇଳାଠାରୁସର୍ବନିମ୍ନସୁରକ୍ଷାପ୍ରଦାନକରେ| ଯେତେବେଳେଏକସ୍ଲାସ୍ଟିପଦଥାଏ, ଅନ୍ୟପ୍ରତିରକ୍ଷାଚକ୍ଷ୍ରଉପକରଣପିନ୍ଧିବାଉଚିତ୍।
- 2. Safety goggles (impact goggles) offer adequate protection against flying particles. These should be worn when working with glassware under reduced or elevated pressure or with drill presses or other similar conditions.
 - ସୁରକ୍ଷାଗଗଲ୍ସ(ପ୍ରଭାବଗଗଲ୍ସ)ଉଡ଼ୁଥିବାକଣିକାବିରୁଦ୍ଧରେପର୍ଯ୍ୟାପ୍ତସୁରକ୍ଷାପ୍ରଦାନକରେ|ହ୍ରାସକିମ୍ବାଉଚ୍ଚଚାପରେକିମ୍ବାଡ୍ରିଲ୍ଗ୍ରେୟିମ୍ବାଅନ୍ୟା ନ୍ୟସମାନଅବସ୍ଥାରେଗ୍ଲାସୱେୟାରସହିତକାମକରିବାବେଳେଏଗୁଡିକପିନ୍ଧିବାଉଚିତ|
- 3. Chemical splash goggles (acid goggles) have indirect venting for splash proof sides, which provide adequate protection against splashes. Chemical splash goggles offer the best eye protection from chemical splashes. Impact goggles should not be worn when danger of a splash exists. 31
 - ରାସାୟନିକୟ୍ଲାସ୍ସଗଲ୍ସ (ଏସିକ୍ଷଗଲ୍ସ) ୟ୍ଲାସ୍-ପ୍ରୁଫ୍ଧାର୍ଶ୍ୱପାଇଁପରୋକ୍ଷଭେଷ୍ଟିଙ୍ଅଛି, ଯାହାସ୍ଲାସ୍ଠାରୁପର୍ଯ୍ୟାପ୍ତସୁରକ୍ଷାଯୋଗାଇଥାଏ| ରାସାୟନିକସ୍ଲାସ୍ସଗଲ୍ସରାସାୟନିକସ୍ଲାସରୁସର୍ବୋଉମଚକ୍ଷୁସୁରକ୍ଷାପ୍ରଦାନକରେ| ଯେତେବେଳେସ୍ଲାସରବିପଦଥାଏସେତେବେଳେଇମ୍ପାକ୍ଟଗଗଲୁପିନ୍ଧିବାଉଚିଦ୍ସହେଁ| 31
- 4. Face shields protect the face and neck from flying particles and splashes. Always wear additional eye protection under face shields. Ultra-violet light face shields should be worn when working over UV light sources.

ତେହେରାକବଚଗୁଡ଼ିକମୁହଁଏବଂବେକକୁଉଡ଼ୁଥିବାକଶିକାଏବଂଷ୍ଲାସରୁରକ୍ଷାକରିଥାଏ| ସର୍ବଦାଚେହେରାକବଚତଳେଅତିରିକ୍ତଆଖିସୁରକ୍ଷାପିନ୍ଧନ୍ତୁ| UV ଆଲୋକଉସଉପରେକାମକରିବାସମୟରେଅଲ୍ଟ୍ରା-ବାଇଗଣୀହାଲ୍କାଚେହେରାକବଚପିନ୍ଧିବାଉଚିତ୍ର|

5.3.2 Selecting Appropriate Eye and Face Protection in Laboratories

Safety Glasses

Required when: An impact hazard exists or when working with low hazard chemicals, or when a low probability of splash exists.

Examples:

- Pipetting
- Handling closed bottle of injurious chemical
- · Mixing solutions
- Opening centrifuge tubes
- 5.3.2ଲାବୋରେଟୋରୀଗୁଡିକରେଉପଯୁକ୍ତଚକ୍ଷ୍ୟଏବଂଚେହେରାସୁରକ୍ଷାଚୟନକରିବା|

ସୁରକ୍ଷାଚଷମା

ଯେତେବେଳେଆବଶ୍ୟକହୁଏ: ଏକପ୍ରଭାବବିପଦବିଦ୍ୟମାନଥାଏକିମ୍ବାଯେତେବେଳେକନ୍ଦିପଜ୍ଜନକରାସାୟନିକପଦାର୍ଥସହିତକାମକରେ,

କିମ୍ବାଯେତେବେଳେସ୍କାସରକମୁୟାବନାଥାଏ|

ଉଦାହରଣଗୁଡିକ:

•ପାଇପେଟିଂ

କ୍ଷତିକାରକରାସାୟନିକରବନ୍ଦବୋତଲଗୁଡିକପରିଚାଳନାକରିବା|

ସମାଧାନସମାଧାନ|

ସେଷ୍ଟ୍ରିଫୁଗ୍ଲ୍ୟୁବ୍ଜୋଲିବା|

Chemical Splash Goggles

Required when: Working with smaller amounts of corrosive or injurious chemicals and a reasonable probability of splash exists

Examples:

- Pouring acid out of a 1-pint bottle
- Pouring methylene chloride from a 1-liter bottle
- Working with liquids under pressure

କେମିକାଲ୍ସ୍ଲାସ୍ଗୋଗଲ୍|

ଯେତେବେଳେଆବଶ୍ୟକହୁଏ:

ଅଳ୍ପପରିମାଣରକ୍ଷତିକାରକକିମ୍ବାକ୍ଷତିକାରକରାସାୟନିକପଦାର୍ଥସହିତକାର୍ଯ୍ୟକରିବାଏବଂସ୍କାସରଏକଯୁକ୍ତିଯୁକ୍ତସନ୍ତାବନାବିଦ୍ୟମାନ ଉଦାହରଣଗ୍ରତିକ:

- 1ପିୟବୋତଲରୁଏସିଡ୍ଢ଼ାଳିବା
- •ଏକଲିଟରବୋଡଲରୁମିଥାଇଲନ୍ଲ୍ଲୋରାଇଡ୍ଢ଼ାଳିବା|

ଚାପରେତରଳପଦାର୍ଥସହିତକାମକରିବା|

Face Shield and Chemical Splash Goggles

Required when: Working with larger quantities of corrosive chemicals and / or a high probability of eye and face injury exists.

Examples:

- Working with an acid bath
- Pouring 4 liters of acid into a container
- · Handling highly reactive chemicals that may spatter

Note: Ordinary prescription glasses do not provide adequate protection against eye injury. Eye protection equipment must be ANSI Z87 approved.

Protection of Skin and Body: Skin and body protection involves the use of protective clothing to protect individuals from chemical exposure. Determine clothing needed for the chemical being used, as protective garments are not equally effective for every hazardous chemical. Some chemicals will permeate a garment in a very short time, whereas others will not.

The basic and most effective forms of protection are gloves and lab coats. 32

ଫେସ୍ନିଲ୍ଲଏବଂକେମିକାଲ୍ଲ୍ଲାସ୍ସଗଲ୍ଲ।

ଯେତେବେଳେଆବଶ୍ୟକ: ଅଧିକପରିମାଣରକ୍ଷଡିକାରକରାସାୟନିକପଦାର୍ଥଏବଂ

କିମ୍ବାଆଖ୍ଏବଂମୂହଁରେଆଘାତହେବାରଏକଉଚ୍ଚସୟାବନାସହିତକାର୍ଯ୍ୟକରିବା|

ଉଦାହରଣଗୁଡିକ:

ଏକଏସିଜ୍ମାନସହିତକାମକରିବା|

ଏକପାତ୍ରରେ4ଲିଟରଏସିଡ୍our ାଳିବା|

ଅତ୍ୟଧ୍କପ୍ରତିକ୍ରିୟାଶୀଳରାସାୟନିକପଦାର୍ଥକୁନିୟନ୍ତ୍ରଶକରିବାଯାହାଛିଞ୍ଚିପାରେ|

ଟିପନ୍ତୁ: ସାଧାରଣପ୍ରେସକ୍ରିପସନ୍ଦୃଷମାଆଖ୍ରେଆଘାତରୁପର୍ଯ୍ୟାପ୍ତସୁରକ୍ଷାପ୍ରଦାନକରେନାହିଁ| ଚକ୍ଷୁସୁରକ୍ଷାଉପକରଣନିଷ୍ଟିତଭାବରେANSI Z87ଅନୁମୋଦିତହେବାଆବଶ୍ୟକ|

ଚର୍ମଏବଂଶରୀରରସୁରକ୍ଷା:ଚର୍ମଏବଂଶରୀରରସୁରକ୍ଷାବ୍ୟକ୍ତିବିଶେଷଙ୍କୁରାସାୟନିକଏକ୍ସପୋଜରରୁରକ୍ଷାକରିବାପାଇଁପ୍ରତିରକ୍ଷାପୋଷାକବ୍ୟବହାର କରିଥାଏ| ବ୍ୟବହୃତରାସାୟନିକପଦାର୍ଥପାଇଁଆବଶ୍ୟକପୋଷାକନିର୍ଣ୍ଣୟକର,

କାରଣପ୍ରତିରକ୍ଷାପୋଷାକପ୍ରତ୍ୟେକବିପଜ୍ଜନକରାସାୟନିକପଦାର୍ଥପାଇଁସମାନଭାବରେପ୍ରଭାବଶାଳୀନୁହେଁ । କେତେକରାସାୟନିକପଦାର୍ଥଖୁବ୍ଲମ୍ବମୟମଧ୍ୟରେଏକପୋଷାକରେପ୍ରବେଶକରିବ, ଅନ୍ୟମାନେତାହାକରିବେନାହିଁ । ସଂରକ୍ଷଣରମbasic ଳିକଏବଂସବଠାରପଭାବଶାଳୀଫର୍ମହେଉଛିଗ୍ଲୋଭସଏବଂଲ୍ୟାବକୋଟ୍ । 32 Employees working with hazardous chemicals in laboratories must wear closed-toe shoes, long pants or skirt which fully covers the legs, and a lab coat.

Even when there is minimal danger of skin contact with an extremely hazardous substance, lab coats, coveralls, aprons, or protective suits should be utilized. **These garments should not leave the work site.**

Exposures to strong acids and acid gases, organic chemicals and strong oxidizing agents, carcinogens, and mutagens require the use of specialized protective equipment that prevents skin contamination. Impervious protective equipment must be utilized. Examples include: rubber gloves, aprons, boots and protective suits.

ଲାବୋରେଟୋରୀରେବିପଜ୍ଜନକରାସାୟନିକପଦାର୍ଥସହିତକାର୍ଯ୍ୟକରୁଥିବାକର୍ମଚାରୀମାନେବନ୍ଦଆଙ୍ଗୁଠିଜୋତା, ଲମ୍ବାପ୍ୟାଞ୍ଜକିମ୍ବାଗୋଡକୁସମ୍ପୂର୍ଣ୍ଣଆଚ୍ଛାଦନକରୁଥିବାସ୍କର୍ଟଏବଂଲ୍ୟାବକୋଟ୍ସିନ୍ଧିବାଜରୁରୀ |

ଅତ୍ୟଧିକବିପଜନକପଦାର୍ଥସହିତଚର୍ମସଂୟର୍ଶରେଆସିବାରସର୍ବନିମ୍ନବିପଦଥିଲେମଧ୍ୟଲ୍ୟାବକୋଟ୍, କଭରେଲ୍, ଆପ୍ରୋନ୍, କିମ୍ବାପ୍ରତିରକ୍ଷାସୁଟ୍ୟୁବହାରକରାଯିବାଉଚିତ୍ । ଏହିପୋଷାକଗୁଡିକକାର୍ଯ୍ୟସ୍ଥାନଛାଡିବାଉଚିତ୍କୃହେଁ ।

ଶକ୍ତିଶାଳୀଏସିଡ୍ଏବଂଏସିଷ୍କ୍ୟାସ୍, ଜୈବିକରାସାୟନିକପଦାର୍ଥଏବଂଶକ୍ତିଶାଳୀଅକ୍ସିଡାଇଜେଷ୍ଟ୍ଏଜେଷ୍ଟ୍, କର୍କିନୋଜେନ୍, ଏବଂମ୍ୟୁଟେଜେନ୍ସଂସର୍ଶରେଆସିବାବିଶେଷଜ୍ଞପ୍ରତିରକ୍ଷାଉପକରଣରବ୍ୟବହାରଆବଶ୍ୟକହୁଏଯାହାଚର୍ମପ୍ରଦୂଷଣକୂରୋକିଥାଏ | ଦୁର୍ବଳପ୍ରତିରକ୍ଷାଉପକରଣବ୍ୟବହାରକରାଯିବାଜରୁରୀ | ଉଦାହରଣଗୁଡ଼ିକରେରବରଗ୍ଲୋଭସ୍, ଆପ୍ରନ୍, ବୁଟ୍, ଏବଂପ୍ରତିରକ୍ଷାସୁଟ୍ଅନ୍ତର୍ଭୁକ୍ତ |

SOURCE: MSU Chemical Hygiene Plan

ଉସ: MSU ରାସାୟନିକସ୍ପଚ୍ଛତାଯୋଜନା |

Link: https://ehs.msu.edu/_assets/docs/chem/msu-chem-hygiene-plan.pdf