

VANTARA PETROCHEM - UNIT 3

STANDARD OPERATING PROCEDURE

HOT WORK PERMIT PROCEDURE

Document Number:	SOP-HW-001
Revision:	Rev 4
Effective Date:	2023-09-01
Author:	Kavitha Reddy, HSE
Regulatory Reference:	OISD-GDN-206

PROCEDURE

1. Pre-Work Requirements:

- Gas testing by certified gas tester (LEL must be < 1%)
- Fire extinguisher positioned within 10 meters
- Fire blanket to cover drains and openings
- Fire watch designated and briefed

2. Permit Issuance:

- Area supervisor issues hot work permit
- Permit valid for single shift only
- Continuous gas monitoring required

3. During Hot Work:

- Fire watch maintains continuous observation
- Gas testing every 30 minutes
- Work stops immediately if LEL exceeds 10%

4. After Hot Work Completion:

- Fire watch must remain on station for minimum 30 minutes after completion of hot work per OISD-GDN-206 Section 3.4
- Final area inspection before fire watch release
- Permit closed out and returned to control room