# **EEE 216: Microprocessor Systems Lab**

# **Anthony Centeno**

# ( Anthony.Centeno@xjtlu.edu.cn)

In this seesion you will use the ARM assembly programming and the Keil µVision IDE.

## i. Getting started with Keil µVision

- Start Keil µVision 4 or 5 (Both are installed in the computer lab machines)
- Project → μVision project → select project directory and project file name → select target CPU
  (ARM → ARM7 little endian).
- Create new source file (File → new). Assembler file must have .s extension.
- Add the source file to a source group in the project (e.g. the default one).
- Write your program and save the source file.
- Build the project (Build Targets).
  - If you have edited the source file have previously built the project you should first clean targets before doing Build again
- Switch to the debugging/running mode.
- Control the program execution and observe the registers and memory.

#### Sample Program

1	AREA	ArmExample,	Code
2	ENTRY		
3		MOV r1, #10	
4		MOV r2, #&10	
5	SWI &	)	
6	END		

### TASK 1.

Run the sample program. Once it's running write comments into the program to explain what it is doing. [10 marks]

Note: Semicolons mark the beginning of comments

### Example:

AREA ArmExample, CODE ; code area declaration and name

ENTRY ;program entry point

NOTE: You will submit your programs for assessment. Every line of code should be commented.

#### A. 16 Bit Transfer

Consider the code below:

```
AREA ArmExample, CODE

ENTRY

Main

LDR R1, Value ;load the 16 bit value to be moved ldr R2, Res ;load the memory address to store the value

STR R1, [R2] ;save the value to the memory address Res SWI &0

Value DCW &C123 ;DCW enables you to write 16 bits to memory DCD &FFFFFFFO ;DCD enables you to write 32 bits to memory END
```

It transfers 16 bits from "Value" to "Res".

### Task 2.

- i. Modify the code to transfer 32 bits between "Value" and "Res". [20 marks]
- ii. Write some comments at the end of the program discussing how the code varies compared to writing it for the ViSUAL Arm Emulator. In particular consider where the DCD (and DCW) commands are placed. [Hint: Try putting them after END] [20 marks]

### **B.** Counting Iterations

Task 3.

Write an ARM assembly program which contains an infinite loop incrementing at each iteration the value of r1. [20 marks]

## C. Ordered pair

Write an ARM assembly language program which assigns a 16 bit value to r1 and a 16 bit value to r2, then checks of r1 = r2. If it is not the same an eight bit word 0xFF is sent to a memory address called fault.

[30 marks]

Note: You will need to put in two 16 bit values something like this:

Value1 DCW &1234

align

Value2 DCW &1235

[See what happens if you don't use align.]

### **Submission Requirements**

Programs will need to be submitted on ICE in Week 12. All programs must contain comments to clearly explain how the program works. Working programs with no or minimal comments will receive a lower grade.