

1.

Connect a USB webcam to your computer, install any required drivers, and verify that the webcam works by opening the default camera app and capturing a photo.

1.Plug in the USB Webcam:

Connect your webcam's USB cable directly into an available USB port on your computer (avoid unpowered USB hubs for better stability).

2.Install Drivers (Automated / Manual):

- **Windows 10/11 & macOS:** Most modern webcams are plug-and-play (UVC compliant). Your operating system will automatically detect and install the necessary drivers within a few seconds.
- **Manual Setup:** If your webcam came with dedicated software or requires specific drivers, download and run the installer from the manufacturer's official support page (e.g., Logitech, Razer, Anker).

3.Open the Built-in Camera App:

- **On Windows:** Open the **Start Menu**, search for **Camera**, and select the app.
- **On Mac:** Open **Finder > Applications**, and launch **Photo Booth** (or **FaceTime**).

4.Verify and Capture a Test Photo:

1. Ensure the camera preview displays your video feed. If you have multiple cameras connected, select the correct input device from the app settings.

2. Click the **Photo / Shutter** button to take a photo and confirm the camera is functioning properly.

2.

Set up a local printer (USB or network), install the correct driver, and print a test page to confirm successful installation.

Step 1: Connect the Printer

- **For USB Printers:** Plug the USB cable directly from the printer into an available USB port on your computer, then turn the printer on.
- **For Network/Wi-Fi Printers:** Turn on the printer and connect it to your Wi-Fi network using the printer's screen/buttons, or plug an Ethernet cable directly from the printer into your Wi-Fi router.

Step 2: Install the Printer & Driver

On Windows 10/11

1. Go to **Start > Settings > Bluetooth & devices > Printers & scanners**.
2. Click **Add device**. Windows will automatically detect your printer and download the correct drivers.
3. *If your printer isn't found automatically:* Download and run the software installer from your printer manufacturer's support site (e.g., HP, Canon, Epson, Brother).

On Mac

1. Go to **Apple Menu > System Settings** (or System Preferences) **> Printers & Scanners**.
2. Click **Add Printer, Scanner, or Fax...** (or the + button).
3. Select your printer from the list and click **Add**. macOS will automatically fetch the required drivers.

Step 3: Print a Test Page

On Windows

1. Go back to **Settings > Printers & scanners** and click your printer name.
2. Click **Printer properties**.
3. Under the **General** tab, click **Print Test Page**.

On Mac

1. In **Printers & Scanners**, click your printer and select **Options & Supplies...** (or *Open Print Queue*).
2. Go to the **Utility** tab and click **Print Test Page** (or **Print Self-Test Page**).

3.

Simulate a connectivity issue by unplugging the printer's USB cable, then use Windows Device Manager to identify and resolve the 'printer not detected' problem.

Step 1: Cause the Problem

1. Open **Device Manager** (right-click the **Start** button and click **Device Manager**).
2. Unplug the printer's USB cable from your computer.
3. You will see the printer disappear from the list, or show a yellow warning sign (!).

Step 2: Fix the Problem

1. **Plug the cable back in:** Firmly reconnect the USB cable and make sure the printer is turned on.
2. **Refresh the list:** At the top menu of Device Manager, click **Action** and then click **Scan for hardware changes** (or click the blue monitor icon on the toolbar).
3. **Check the result:** Windows will scan your computer and your printer will pop back up in the list with no warning signs.

4.

A user reports that their webcam video is not displaying in Zoom, but it works in the default camera app. Troubleshoot and resolve the issue so the webcam works in both applications.

Step 1: Close the Camera app

Webcams can only work in one app at a time. Close the **Camera** app (and any other video apps like Teams or Skype), then open Zoom again.

Step 2: Allow Zoom to use your camera

- **On Windows:** Go to **Settings > Privacy & security > Camera**. Turn ON **Camera access** and make sure Zoom is allowed to use it.
- **On Mac:** Go to **System Settings > Privacy & Security > Camera**, and turn ON the toggle switch next to **Zoom**.

Step 3: Pick the right camera in Zoom

1. Open **Zoom** and click your **profile picture** at the top right, then click **Settings**.
2. Click **Video** on the left menu.
3. In the **Camera** dropdown list, select your webcam's actual name.