

1.

List 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.

1. The Mouse or Keyboard Stops Working

- **How to fix:** Unplug it, plug it into a different USB hole, or restart your laptop.

2. Laggy or Slow Movement

- **How to fix:** If it is wireless, put in brand new batteries and move closer to the laptop.

3. Typing the Wrong Letters or Double Letters

- **How to fix:** Go to your laptop settings and make sure your keyboard language is set to **English**.

4. Mouse Pointer Skips or Freezes

- **How to fix:** Wipe the optical light on the bottom with a dry cloth and use a mouse pad.

5. Cable Keeps Disconnecting When Wiggled

- **How to fix:** Carefully clean out dust inside the USB port using a wooden toothpick.

2.

Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.

Step 1: Check the Headphones' Light and Battery

- Look at the small light on your headphones:
 - **No light or red light:** The battery is empty. Plug them in to charge.
 - **Blue or white light:** They have power.

Step 2: Turn Bluetooth Off and On

- On your phone, pull down the top menu screen.
- Tap the **Bluetooth icon** to turn it **OFF**, wait 5 seconds, and tap it back **ON**.

Step 3: Put Headphones into Pairing Mode

- Turn off your headphones.
- Hold down the **Power button for 5 seconds** until the light starts **blinking fast**. This tells the headphones to look for your phone.

Step 4: Forget and Re-Connect

- Go to your phone's **Settings → Bluetooth**.
- Find your headphones' name and tap **Forget** or **Unpair**.
- Look at the list of **Available Devices**, tap your headphones' name, and press **Pair**.

Step 5: Turn Off Bluetooth on Other Devices

- Make sure your headphones aren't accidentally connecting to a nearby laptop, TV, or tablet instead of your phone. Turn off Bluetooth on those other devices.

3.

A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem.

1. **Try a different USB hole:** Unplug your camera and plug it into another USB port on your computer.
2. **Check for a cover:** Make sure there is no plastic cap or slider covering the camera lens.
3. **Check Windows Settings:** Go to your computer's **Settings** → **Privacy** → **Camera**. Make sure the switch is turned **ON** so apps can use it.
4. **Pick the camera in Zoom:** In your Zoom meeting, click the small arrow next to the **Start Video** button. Make sure your plugged-in camera has a checkmark next to its name.
5. **Close other apps:** Completely close Skype, Teams, or the camera app. The camera can only look at one app at a time.
6. **Check Device Manager:** Right-click the Windows Start button at the bottom of your screen and click **Device Manager**. Click on **Cameras**. If your camera has a warning sign on it, right-click it and select **Update** or **Enable**.

4.

You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.

How to Run the Printer Fixer Tool (Troubleshooter)

1. **Open Settings:** Click the **Start button** on your screen and tap the **Gear icon** (Settings).
2. **Find the Troubleshooter:**
 - Go to **System** (or **Update & Security**), click **Troubleshoot**, and then click **Other trouble-shooters** (or **Additional troubleshooters**).
3. **Start the Tool:** Find **Printer** on the list and click the **Run** button next to it.
4. **Choose Your Printer:** Click on your printer's name when it pops up on the screen and press **Next**.

What Information the Tool Shows You

While it works, the tool gives you 3 simple updates:

- **What it is checking:** It shows a moving bar telling you what it is testing (like checking your printer cables, Wi-Fi connection, or computer software).
- **What the problem is:** It tells you exactly why the printer says 'offline'. For example:
 - *"The 'Use Printer Offline' setting was accidentally turned on."*
 - *"The computer lost connection to the printer."*
 - *"The printer background system stopped working."*

- **What it fixed:** It gives you a final report saying:
 - **"Fixed"** (e.g., *"We turned off 'Use Printer Offline' for you!"*), or
 - **"What to do next"** if it couldn't fix it automatically (e.g., *"Please turn your printer off and on again"*).