

# NovaTech Solutions — User Manual

Using your NovaTech devices and the NovaTech Home app

## Getting Started

After installation, all your NovaTech devices appear on the Home tab of the app, grouped by room. Tap any device to view its status, controls, and settings.

## Using the NovaTech Home App

- Home tab: quick controls for all devices, grouped by room
- Automations tab: create routines (e.g., 'Lock the door at 10 PM')
- Alerts tab: view motion, door, and system notifications
- Account tab: manage your profile, connected devices, and subscription add-ons

## Managing Device Sharing

Share access to your smart home with family members by going to Account > Household Members > Invite. Invited members can control devices but cannot change security PINs unless granted admin access.

## Firmware Updates

NovaTech devices update automatically overnight when connected to Wi-Fi and charging (for battery devices). You can also manually check for updates under Account > Device Settings > Check for Updates. We recommend keeping automatic updates enabled for security patches.

## Camera Features

Sentry Cam devices support live view, 2-way audio, motion zones, and activity history. Cloud storage recordings are retained for 30 days on Sentry Cam Pro; other models require a NovaTech Cloud subscription for recording storage beyond live view.

## Smart Lock Codes

LockGuard X1 supports up to 20 unique PIN codes and 10 fingerprints. Temporary guest codes can be set with automatic expiration under Lock Settings > Guest Access.

## Troubleshooting: Device Offline

- Check that your Wi-Fi router is powered on and connected to the internet
- Restart the device by unplugging for 10 seconds, or holding reset for battery devices
- Confirm the device hasn't been moved out of Wi-Fi range
- Check the app for any pending firmware updates that may need to complete first

## Battery Life & Charging

Battery-powered devices (cameras, locks, watches) show battery percentage in the app. Low battery notifications trigger at 20% and 5%. Most battery cameras last 3-6 months per charge depending on activity level.

## Safety Information

Do not expose non-weatherproof indoor devices to rain or direct water exposure. Smart locks should have a physical key backup stored safely in case of device failure or dead battery.

*NovaTech Solutions — fictional company knowledge base document, generated for RAG testing purposes.*