

SOP Pump P-101 - Safety Operating Procedure

Purpose: This document defines safe start-up, inspection, and shutdown steps for pump P-101.

1. Verify the suction and discharge valves are in the correct position.
2. Apply Lock-Out Tag-Out before opening the coupling guard or touching the seal housing.
3. Check for seal leakage, abnormal vibration, and bearing temperature above 85 C.
4. If seal leakage is detected, stop the pump immediately and notify maintenance.
5. Use PPE: gloves, goggles, face shield, and safety shoes.
6. Confirm the motor current is within nameplate limits before returning to service.

Hazards: rotating equipment, hot surfaces, pressure release, and entanglement.

Equipment Tags: P-101, M-101, V-201, FT-104.