Printing Settings

Prusa XL | PrusaSlicer configuration record

Object configuration. The print consists of a main (outer) object and a smaller, centrally positioned copy of the same object used as a PrusaSlicer modifier. The modifier changes the local printing parameters in the central region only: **99% Grid infill** and the additional layer/perimeter overrides listed below. The main object uses **100% Aligned Rectilinear infill**. All other print, filament, and printer settings below apply to the main object and the modified central region unless superseded by a modifier override.

1. Printer and overall setup

Parameter	Value / detail
Printer	Original Prusa XL - 0.4 mm nozzle (Prusa XL)
Filament profiles (two slots)	Generic FLEX (modified); Generic FLEX (modified)
Virtual extruders	Color Mixing
Supports	None
Overall infill displayed	100%
Brim	Enabled

2. Main object - layers and shells

Parameter	Value / detail
Layer height	0.10 mm
First-layer height	0.10 mm
Perimeters	1 (minimum)
Spiral vase	Disabled
Top solid layers	0
Bottom solid layers	0
Minimum shell thickness - top	0.7 mm (locked / inactive)
Minimum shell thickness - bottom	0.5 mm (locked / inactive)

3. Main object - infill and advanced

Parameter	Value / detail
Fill density	100%
Fill pattern	Aligned Rectilinear
Length of infill anchor	2 mm
Maximum length of infill anchor	0 (not anchored)
Top fill pattern	Monotonic Lines (locked / inactive)
Bottom fill pattern	Monotonic (locked / inactive)

Parameter	Value / detail
Solid infill every	0 layers
Fill angle	0 degrees
Solid infill threshold area	0 mm2 (locked / inactive)
Bridging angle	0 degrees (locked / inactive)
Only retract when crossing perimeters	Disabled
Infill before perimeters	Disabled

4. Central modifier - overrides only

Parameter	Value / detail
Geometry / placement	Smaller copy of the main object, centered within the main object
Fill density	99%
Fill pattern	Grid
Bottom solid layers	0
External perimeters first	Enabled
Extra perimeters if needed	Disabled
Extra perimeters on overhangs (experimental)	Disabled
Perimeters	1 (minimum)
Top solid layers	0

5. Speed for print moves

Parameter	Value / detail
Perimeters	80 mm/s
Small perimeters	45 mm/s
External perimeters	45 mm/s
Infill	110 mm/s
Solid infill	140 mm/s
Top solid infill	75 mm/s
Support material	120 mm/s
Support material interface	50 mm/s
Bridges	45 mm/s
Over bridges	50%
Gap fill	65 mm/s
Ironing	15 mm/s

6. Extrusion width

Parameter	Value / detail
Default extrusion width	0.40 mm
First layer	0.40 mm
Perimeters	0.40 mm
External perimeters	0.40 mm
Infill	0.40 mm
Solid infill	0.45 mm (locked / inactive)
Top solid infill	0.42 mm (locked / inactive)
Support material	0.40 mm (locked / inactive)
Automatic extrusion widths calculation	Disabled

7. Filament properties

Parameter	Value / detail
Filament profile	Generic FLEX (modified)
Filament diameter	1.75 mm
Extrusion multiplier	1.08
Density	1.22 g/cm3
Spool weight	0 g
Idle temperature	70 degrees C
Nozzle temperature - first layer	210 degrees C
Nozzle temperature - other layers	210 degrees C
Bed temperature - first layer	50 degrees C
Bed temperature - other layers	50 degrees C
Chamber temperature - nominal	0 degrees C
Chamber temperature - minimal	0 degrees C