Partnertech Victoria V5 Installation Guide

Contents

Contents

Document version: 1.0 June 2024

# How to connect your Partnertech Victoria hardware

Introduction

Follow these steps to connect your new Partnertech Victoria hardware together. Please use the pictures provided to find the correct cables.

Additional requirements

In addition to the box contents, you will need:

- Somewhere to setup the hardware
- Access to power sockets
- A network cable and port
- Keyboard and Mouse (optional)

Step 1 - Prepare till computer for set up

a) Unpack the box containing the till screen
b) Flip the screen over so that it is face down on a soft surface
c) Fold the stand up and remove the cover from the back of the screen.

*Please note this is an all in one unit so doesn't need to be plugged into another PC.*

Step 2 – Connect till PC power

a) Find the 2 parts that make up the power cable. Connect them together so the black box is in the middle

b) Plug the power cable into the till screen

Plug it into the DC-IN port on the back of the till, and the other end into a mains plug socket.

Step 3 - Connect the till PC to the network

a) Plug the ethernet cable into the back of the till into the port marked LAN.

b) Connect the other end to a network port or a router.

Step 4 - Connect the receipt printer

c) Unbox the receipt printer and cables
d) Plug the power cable into the back of the receipt printer and the other end into a power socket
e) Plug the other end of the cable into the USB printer port in the back of the receipt printer
f) Connect the USB cable into a USB port on the back of the till

Step 5 - Connect the Till Drawer

Connect the cable coming from the cash drawer into the port labelled "DK" on the back of the receipt printer.

Step 6- Connect the Barcode Scanner (optional)

a) Plug the barcode scanner into a USB port on the back of till

Step 7- Connect the Barcode printer (optional)

a) Unpack the barcode printer, power cable and USB cable from the box
b) Plug the barcode printer into a USB port on the back of the till
c) Plug the power cable into the back of the barcode printer and the other end into a power socket

Step 8 - Keyboard and Mouse (optional)

If you wish to attach a keyboard and mouse to the till, plug the mouse and keyboard each into one of the available USB ports.

Step 9- Replace cover on the back of the till

Replace the cover on the back of the till. When re-attaching the cover, please ensure no wires are trapped to prevent any damage to the wires or till unit.