

Workflow using P/T/RH Monitor

1. Upload `delete_sd.ino` to make sure `data.csv` is empty.
2. Upload and run `P_T_RH_Sensor_Initail.ino` to log data for the desired duration.
3. Upload `extract_data_from_csv.ino`, you should see the data in Monitor.
4. close the Monitor in the Arduino IDE.
5. open a native terminal (e.g. PowerShell if you are on Windows) and install the dependency:

```
pyserial
```

6. run `save_serial_data.py` from that terminal, make sure you have the same port as in Arduino IDE (example has COM3).
7. you should have now `data.csv` locally with the same contents as what was printed in the Monitor.
8. run `plotting_code_P_T_RH.py` to make the plots.