

Workflow using CO2 monitor

September 23, 2026

1. upload *delete_sd.ino* to make sure data.csv is empty
2. upload and run *CO2_Sensor_Init.ino* to log data for the desired duration
3. upload *extract_data_from_csv.ino*, you should see the data in Monitor
4. close the Monitor in Arduino IDE
5. open a Windows terminal (e.g. PowerShell) and install the dependency: pyserial
6. run *save_serial_data.py* from that terminal, make sure you have the same port as in arduino IDE (example has COM3)
7. you should now have data.csv locally with the same contents as what was printed in Monitor
8. run *plotting_code_CO2.py* to make the plot