Requesting replacement peripherals

Article KB0010042 | Owner: Desktop Support | Subcategory: Keyboard / mouse / headset | Applies to: Windows 11 23H2/24H2 laptops (Dell Latitude 5440/7440, Lenovo ThinkPad T14/X1 Carbon, HP EliteBook 840), MacBook Pro/Air running macOS 14/15, Any Acme Global employee using company-issued peripherals

Summary

This article guides users through troubleshooting common peripheral issues (mouse, keyboard, headset) and explains how to request a replacement when basic fixes fail. It outlines self-help checks, a step-by-self-help procedure for re-pairing Bluetooth devices and selecting the correct audio device, and the Desktop Support process for issuing stock replacements. Follow the verification steps to confirm the new peripheral works before closing the ticket.

Symptoms

- Mouse cursor does not move or clicks are unresponsive
- Keyboard keys produce no input or repeat erratically
- Headset microphone is silent in Teams or other apps; others cannot hear you
- Bluetooth headset fails to pair or disconnects repeatedly
- Error message: "Device not found" or "No audio input device detected" in Windows Sound settings or macOS Audio MIDI Setup

Common causes

- Battery depleted or low power in wireless peripherals
- Bluetooth pairing lost due to interference, outdated driver, or device removed from trusted list
- Incorrect default audio device selected in application settings (e.g., Teams)
- Physical damage or wear (stuck keys, broken mic boom, faulty sensor)

Initial Checks

Before requesting a replacement, perform quick sanity checks that often resolve the issue. Verify the peripheral has sufficient charge or fresh batteries. For wired devices, ensure the cable is firmly plugged into the correct port and try a different USB-A/USB-C socket. For Bluetooth devices, toggle the laptop's Bluetooth radio off and on, then attempt to reconnect. These steps take less than two minutes and eliminate the most common power-or-connection problems.

Self-Help Procedure - Re-pair Bluetooth Device & Select Correct Audio

Follow this numbered procedure if your mouse, keyboard, or headset uses Bluetooth and appears unresponsive. It works on both Windows 11 and macOS. After completing the steps, test the peripheral for at least 30 seconds to confirm functionality.

1. 1. Open Bluetooth settings: Windows - Settings -> Devices -> Bluetooth & other devices; macOS - Apple menu -> System Settings -> Bluetooth.
2. 2. Turn Bluetooth off, wait 5 seconds, then turn it back on.
3. 3. Locate the problematic device in the list. If it appears as "Paired" but not connected, select it and choose "Remove device".
4. 4. Put the peripheral into pairing mode (usually holding the power/button for 5-7 seconds until LED flashes). Refer to the manufacturer's quick-start guide if unsure.
5. 5. In the Bluetooth window, click "Add device" (Windows) or the "+" button (macOS) and select the peripheral when it appears.
6. 6. Complete any on-screen prompts (e.g., confirm a passkey). Windows will install drivers automatically; macOS will acknowledge the device.
7. 7. For headsets: after pairing, open the audio source application. In Windows, right-click the speaker icon -> Sounds -> Recording tab, select the headset microphone, and click "Set Default". In macOS, open System Settings -> Sound -> Input and choose the headset.
8. 8. Test the device: move the mouse, type a few keys, or speak into the mic while monitoring the input level bar.

Verification & Closure

After receiving a replacement peripheral, the user should perform a quick functional test to ensure the device operates correctly before the ticket is closed. This step prevents unnecessary repeat contacts and confirms that the issue was hardware-related rather than a misconfiguration.

1. 1. Connect the new peripheral (or ensure Bluetooth is paired).
2. 2. For mice/keyboards: move the cursor, click, and type a sentence in Notepad or any text editor.
3. 3. For headsets: join a test Teams call or use the Windows Voice Recorder; verify that you can hear playback and that your voice is captured clearly.
4. 4. If any abnormality persists, note the details and reopen the ticket for further investigation - do not close until the device works as expected.

When to escalate

If the replacement peripheral still fails after verification, or if the user reports multiple peripheral failures suggesting a broader system issue (e.g., Bluetooth adapter failure, USB controller problem), the L1 agent should escalate to the Desktop Support - Hardware Engineering sub-team. Include in the escalation: the ticket number, asset tags of the original and replacement devices, a summary of troubleshooting steps taken, and any error logs collected from Intune or Event Viewer. Escalation is appropriate when the issue persists beyond a second replacement or when diagnostic tests indicate a motherboard or port fault.

Keywords: mouse not working, keyboard keys not responding, headset microphone silent, Bluetooth headset not pairing, replace peripheral, request replacement, hardware issue, peripheral troubleshooting, desktop support, stock replacement