Camera, audio and Bluetooth driver fixes

Article KB0010051 | Owner: Desktop Support | Subcategory: Drivers (audio/camera/Bluetooth) | Applies to: Dell Latitude 5440/7440, Lenovo ThinkPad T14/X1 Carbon, HP EliteBook 840, Windows 11 23H2/24H2, macOS 14/15 on MacBook Pro/Air

Summary

This article provides guidance for resolving common camera, audio, and Bluetooth issues on Acme Global managed laptops. It outlines quick checks, a self-help troubleshooting procedure that end-users can run, and the detailed steps Desktop Support agents should follow when the problem persists. Follow the verification steps to confirm the fix before closing the ticket.

Symptoms

- Camera not detected in Teams or the Camera app - error?0xA00F4244 or "No camera found"
- No sound from speakers or headphones - audio icon shows mute or "No audio output device installed"
- Bluetooth toggle missing in Settings or device shows "Bluetooth not available"
- External webcam works but built-in camera does not

Common causes

- Outdated or corrupted device drivers after a Windows update
- Device disabled in Device Manager (camera, audio adapter, Bluetooth radio)
- Third-party software (VPN clients, security tools) disabling hardware
- Power-management settings turning off USB/audio controllers to save battery
- Rare hardware failure requiring replacement

Initial Checks

Before reinstalling drivers, verify basic conditions that often resolve the issue quickly. Ensure the laptop is connected to AC power or has sufficient battery, as aggressive power-saving policies may disable peripherals. Confirm that no physical privacy shutter or mute switch is engaged on the camera or audio jack. For Bluetooth, make sure airplane mode is off and that the Bluetooth tile in Action Center is enabled.

Self-Help Troubleshooting Procedure

Follow these steps to reset the camera, audio, and Bluetooth drivers yourself. The procedure takes about 5-10 minutes and does not require admin rights beyond the standard user account.

1. Right-click each listed device and choose Uninstall device. If prompted, check the box "Delete the driver software for this device" and confirm.
2. After uninstalling all three categories, click Action -> Scan for hardware changes. Windows will reinstall the default drivers.
3. If a device still shows a warning, repeat the uninstall step but this time select Update driver -> Browse my computer for drivers -> Let me pick from a list of available drivers -> Choose the manufacturer-provided version (e.g., Realtek, Intel).
4. Restart the laptop when prompted.
5. After reboot, test each function:
- Camera: launch the Camera app or start a Teams meeting and verify video.
- Audio: play a sound or join a Teams call and check speaker/headphone output.
- Bluetooth: open Settings -> Devices -> Bluetooth & other devices, toggle Bluetooth on, and attempt to pair a known device.

Service Desk Procedure

When the self-help steps do not restore functionality, the Desktop Support agent should perform a deeper investigation. This includes checking driver versions, reviewing Intune compliance, and determining whether a hardware fault exists.

1. Verify the user's device is compliant in Intune (Company Portal) and that the latest driver packages have been deployed via the 'Driver Updates' script.
2. Open an elevated Command Prompt and run `pnputil /enum-drivers | findstr /i "camera audio bluetooth"` to list

installed driver versions; compare against the approved baseline in the Driver Repository.
3. If drivers are outdated or missing, redeploy the approved driver package using the Intune Win32 app or the local driver store (`pnputil /add-driver <inf> /install`).
4. Check the Windows Event Viewer under System > DriverFramework-UserMode for error codes 0xC0000001 (device failed to start) or 0x80070005 (access denied).
5. Temporarily disable any third-party camera/audio utilities (e.g., OBS, Zoom virtual cam, VPN split-tunnel) and retest.
6. If the device continues to show a yellow triangle after driver reinstall, run the built-in hardware diagnostic: Dell BIOS Diagnostics, Lenovo Vantage Hardware Test, or HP PC Hardware Diagnostics UEFI.
7. Should diagnostics report a hardware failure, create a hardware replacement ticket and escalate to the Desktop Support senior team.

Verification and Closure

After completing either the self-help or service-desk steps, confirm that the issue is resolved before closing the ticket. Document the final driver version and any configuration changes made. Ask the user to test camera, audio, and Bluetooth in a Teams call to ensure full functionality.

When to escalate

If hardware diagnostics indicate a failure of the camera, audio subsystem, or Bluetooth radio, escalate to the Desktop Support senior team (or the appropriate hardware vendor) with the following details: device model, service tag, BIOS version, driver versions attempted, Event Viewer error codes, and results of the built-in hardware test. Include a copy of the Intune compliance report and any screenshots showing the yellow triangle in Device Manager.

Keywords: camera, audio, bluetooth, driver, Teams, no sound, webcam not detected, Device Manager, driver reinstall, Intune, hardware diagnostic