

Ord. of soldering: Solder with heat gun: L1, USBC, STM32 X1, JST GH for CAN By soldering iron: Top ICs Top R&C Bottom ICs Bottom R&C SS24 after pwr ok & no short circuit **ECAP** D7 if pwr from USB needed Low temp: Push btn, TLP291 Connectors