Pin Name	Pin#	I/O Usage
PA0 (output)	Pin 57	Col_0 of keypad
PA1 (output)	Pin 58	Col_1 of keypad
PA2 (output)	Pin 59	Col_2 of keypad
PA3 (output)	Pin 60	Col_3 of keypad
PA4 (input)	Pin 61	Row_0 of keypad
PA5 (input)	Pin 62	Row_1 of keypad
PA6 (input)	Pin 63	Row_2 of keypad
PA7 (input)	Pin 64	Row_3 of keypad
PB0 (output)	Pin 24	LED0 or H-bridge
PB1 (output)	Pin 25	LED1 or H-bridge
PB2 (output)	Pin 26	LED2 or H-bridge
PB3 (output)	Pin 27	LED3 or H-bridge
PB4 (output)	Pin 28	LED4
PB5 (output)	Pin 29	LED5
PB6 (output)	Pin 30	LED6
PB7 (output)	Pin 31	LED7
PE0 (input)	Pin 56	Abort switch SW8
PE1	Pin 55	not used
PE2	Pin 54	not used
PE3	Pin 53	not used
PE4	Pin 39	not used
PE5	Pin 38	not used
PE6	Pin 37	not used
PE7	Pin 36	not used
PH0 (input)	Pin 52	DIP switch 1 or pushbutton switch SW5
PH1 (input)	Pin 51	DIP switch 2 or pushbutton switch SW4 (input)
PH2 (input)	Pin 50	DIP switch 3 or pushbutton switch SW3 (input)
PH3 (input)	Pin 49	DIP switch 4 or pushbutton switch SW2 (input)
PH4 (input)	Pin 35	DIP switch 5 (input)
PH5 (input)	Pin 34	DIP switch 6 (input)
PH6 (input)	Pin 33	DIP switch 7 (input)
PH7 (input)	Pin 32	DIP switch 8 (input)
PJ0	Pin 22	not used
PJ1	Pin 21	not used
PJ6	Pin 99	SDA for DS1307(U11) or external I2C (J2)
PJ7	Pin 98	SCL for DS1307(U11) or external I2C (J2)
PK0 (output)	Pin 8	RS of LCD module
PK1 (output)	Pin 7	EN of LCD module
PK2	Pin 6	DB4 of LCD module (bi-directional)
PK3	Pin 5	DB5 of LCD module (bi-directional)
PK4	Pin 20	DB6 of LCD module (bi-directional)
PK5	Pin 19	DB7 of LCD module (bi-directional)
PK7	Pin 108	not used

Table 1-1: I/O pin usage list 1

Pin Name	Pin#	I/O Usage
PM0 PM1 PM2 PM3 PM4 PM5 PM6 PM7	Pin 105 Pin 104 Pin 103 Pin 102 Pin 101 Pin 100 Pin 88 Pin 87	CAN0 CAN0 not used not used not used not used CS of LTC1661 (DAC) Not used
PP0 (output) PP1 (output) PP2 (output) PP3 (output) PP4 (output) PP5 (output) PP6 (output) PP7 (output)	Pin 4 Pin 3 Pin 2 Pin 1 Pin 112 Pin 111 Pin 110 Pin 109	Digit 3 of 7-segment display or EN12 of H-bridge Digit 2 of 7-segment display or EN34 of H-bridge Digit 1 of 7-segment display Digit 0 of 7-segment display Servo motor 1 or RGB LED Servo motor 2 or RGB LED Servo motor 3 or RGB LED Servo motor 4
PS0 PS1 PS2 PS3 PS4 PS5 PS6 PS7	Pin 89 Pin 90 Pin 91 Pin 92 Pin 93 Pin 94 Pin 95 Pin 96	SCI0 for PC communication, RECV SCI0 for PC communication, XMIT SCI1 for user applications, RECV SCI1 for user applications, XMIT MISO for LTC1661, and external SPI (J10) MOSI for LTC1661, and external SPI (J10) SCLK for LTC1661, and external SPI (J10) /SS for external SPI (J10)
PT0 PT1 PT2 PT3 (input) PT4 (output) PT5 (output) PT6 (output) PT7	Pin 9 Pin 10 Pin 11 Pin 12 Pin 15 Pin 16 Pin 17 Pin 18	not used not used not used not used not used not used Speaker (output) BDMout reset (used in POD mode only) BDMout data line (bi-directional, used in POD mode only)
PAD0 PAD1 PAD2 PAD3 PAD4 PAD5 PAD6 PAD7 PAD8 PAD9 PAD10 PAD11 PAD11 PAD12 PAD13 PAD14 PAD15	Pin 67 Pin 69 Pin 71 Pin 73 Pin 75 Pin 77 Pin 79 Pin 81 Pin 68 Pin 70 Pin 72 Pin 74 Pin 76 Pin 78 Pin 80 Pin 82	D-bug12 mode select, SW7 D-bug12 mode select, SW7 not used not used Light sensor (phototransistor Q1) Temperature sensor (U14, LM45) not used Trimmer pot VR2 X axis input for Wytec accelerometer or ADC input for GP12D2 Y axis input for Wytec accelerometer or ADC input for GP12D2 Z axis input for Wytec accelerometer or ADC input for GP12D2 not used not used not used not used not used

Table 1-2: I/O pin usage list 2