Step No.	Procedure for Firmware Uploading.
1	Copy the hex file to desktop from X:\Firmware\1P\Renesas Alpha\SR00000
2	Open V307
3	Connect the USB Cable of Programmer keeping the START Key pressed.
4	Select the Com Port from the List Box.
5	Click on 'Connect to OP'
6	Select the device RL78.
7	Select the hex file.
8	Disable Encryption.
9	Enter Bin File ID as 'SR00000' for example.
10	Click on Generate Bin File
11	Select 'Enc Binary' and map the Binary File generated on Desktop.
12	Click on Download Bin
13	Give the Device ID as R5F10MME
14	Select Set Product count
15	Give the Encryption Key as 1111 1111 1111.
16	Set Product count as 9999999
17	Disconnect the Programmer.