



#### **AUGMENTED TRANSFORMATIONS PVT. LTD.**

(A Orbit Techsol Company)





9001:2015 & 27001:2013







**User Manual: AJAX Smart Fleet** 

**Role: OEM** 

#### **Features**



- > Track your vehicle on Map. Track each point traversed by your vehicle.
- > Track and monitor all your vehicles at single place.
- > Vehicle summary report at a glance.
- > Geofence your area and receive mobile alerts when vehicle goes out of area.
- > Critical parameter violation notifications on web / your mobile phone.
- > Batch processing and consumption data: Live and History view.
- > Complete tracking with parameters when vehicle on rent.
- > Define Point of Interest and track locations.
- ➤ Graphical dashboard and analytical reports.
- > Track day wise distance travelled, speed and speed violations.
- > Service reminders
- ➤ Service updates
- ➤ Mobile app to track your vehicle on mobile.

## Login

DRIVING INNOVATIONS

- Open Chrome Browser.
- > Type the url : https://ajax-smartfleet.com:8045/
- > Enter Userid / Password.



## Login



Jsername		

Password			

LOGIN

Forgot Password?




# TRACK YOUR VEHICLE

#### Track Vehicles




➤ When logged in, Click on Track Vehicles page. All vehicles will be visible.



#### Track Vehicles



- In Track Vehicles page, all vehicles details are displayed based on authorization.
- ➤ 1. Click on Pin No to view vehicle detailed working.
  - 2. Click on Map to view details of vehicle path on map.
- 3. Click on Gauge panel link to view last engine ON display of gauge readings.



#### Track Vehicles: Details

DRIVING INNOVATION:

➤ 1. Click on PinNo Link.


☐Show Alert values

Particular vehicle details are available for viewing.

Engine On

➤ It will show vehicle summary statistics, Engine ON/OFF parameter data, Alert parameter data.

Refresh




#	Date & Time	Fuel Level	Engine	RPM	Coolant °C	Battery Level (volt)	Travel Speed (Km/h)	Parking Switch	Hydraulic Oil Filter Choke	Oil Pressure (Bar)	Fuel (L)	Distance (kms)
1	03-05-2021 4:36:43 PM	Full Tank	ON	2,094	70	13.8	1.0	RELEASE	CHOKE	6	105	0.00913
2	03-05-2021 4:36:13 PM	Full Tank	ON	838	60	14.1	0.0	APPLIED	CHOKE	4	105	0.00546
3	03-05-2021 4:35:43 PM	Full Tank	ON	890	60	14.1	0.0	APPLIED	CHOKE	4	105	0.00664
	02.05.0004.4.05.40.014		201	200	70	440		4.001.150	CHOKE	_	405	0.00500

Parameter alert values: warning in orange colour, critical in red colour.

eQ

~~~

> Select drop down value as Engine Hours to view engine hours data for selected days.



| # | Engine OnTime          | Engine OffTime         | Duration |
|---|------------------------|------------------------|----------|
| 1 | 03-05-2021 3:25:03 PM  | 03-05-2021 3:25:33 PM  | 00:00:30 |
| 2 | 03-05-2021 3:10:55 PM  | 03-05-2021 3:13:26 PM  | 00:02:31 |
| 3 | 03-05-2021 10:36:18 AM | 03-05-2021 11:30:49 AM | 00:54:31 |

## Track Vehicles : Live Gauge Meter



#### Live Gauge Meter:

Panel will display data for Last Engine ON time.

Engine Hours: 439:02:33

Distance(kms): 250.44

Live Data

Oil Pressure:

Fuel Level: Empty

Fuel Litres:

Coolant Temperature: 120

> Battery Level: 13.9

> > RPM: 742

Hydraulic Oil Filter: CHOKE


> Parking Brake: APPLIED

> > ₩ ON Engine Date Time: 03-05-2021


> > > 4:49:58 PM

000 

2



About Us





mations



## Track Vehicles : Batch Data

000

60


£


000a


ക്

DRIVING

Click on drop down Batch to view machine batch data..









## Track Vehicles: Map path display









### **Dashboard view**






888




₩₩
























## **Master Data: Machine Master Data and mapping**




For Master data entry and machine data mapping Refer to manuals for Master Data Mapping

#### **Master Data: Location**

DRIVING


- Select pointer or polygon for defining a location.
- Mark your location in the Map. It can be a point location or a polygon.
- Enter details on right panel: Location Name, Radius (for pointers only), duration stay time (mnts).








> Click on button Add Location. Location will get added and displayed in bottom of the report.



#### **Master Data: Location**







DRIVING

➤ Go to Menu Masters → Vehicle Geofence

## **Vehicle Geofence**


| Q | Search Vehicle |
|---|----------------|
|   |                |

| #                    | Model    | Variant       | Pin No.            | Location | Map Location |
|----------------------|----------|---------------|--------------------|----------|--------------|
| 1<br>Model           | ARGO2500 | ACURA         | AF1ARG25CCM001213  |          |              |
| Variant              | RGO4000  | CLOSED BUCKET | AF1ARG40KBM009728  |          |              |
| Machine<br>Device    | RGO2500  | CLOSED BUCKET | AF1ARG25LCM001152  |          |              |
| Customer<br>Location | RGO4000  | CLOSED BUCKET | AF01ARG40TBL008713 |          |              |
| Geofence<br>Shipment | .RGO2500 | ACURA         | AF1ARG25JAM000994  |          |              |
| Service              | .RGO2500 | ACURA         | AF1ARG25VBM001079  |          |              |

## Geofencing

DRIVING

- > Select the desired machine.
- Click on the Map location icon,
- > Pop up screen will open. Select the desired location for which you want to create geofencing.
- Click on Map Location.



## **Geofencing**



- > Machine is geofenced with selected location.
- > Whenever this machine will enter or exit this geofence location, user will get sms notification.
- > You can map multiple locations which will work as geofence for defined machine.

| # | Model    | Variant       | Pin No            | Engine No       | Locations | Map Location |  |  |
|---|----------|---------------|-------------------|-----------------|-----------|--------------|--|--|
| 1 | ARG02000 |               | AF1ARGO2L00005469 | T4.2407/1721139 |           | Q            |  |  |
| 2 | ARG02000 |               | AF1ARG20VLJ007455 | T4.2407/1821500 |           | Q            |  |  |
| 3 | ARG02000 |               | AF1ARG20CJJ007248 | T4.2407/1821436 |           | Q            |  |  |
| 4 | ARGO2000 |               | AF1ARG20AJJ007244 | T4.2407/1821416 |           | Q            |  |  |
| 5 | ARGO2000 | CLOSED BUCKET | AF1ARG20HMJ007638 | T4.2407/1821777 |           | Q            |  |  |
| 6 | ARGO2000 |               | AF1ARG20CLJ007423 | T4.2407/1821609 |           | P            |  |  |
| 7 | ARGO2000 | CLOSED BUCKET | AF1ARG20TMJ007613 | T4.2407/1821803 | Bangaluru | Ŷ            |  |  |
| 8 | ARG02000 | CLOSED BUCKET | AF1ARG20ABK007918 | T4.2407/1920091 |           | V            |  |  |
| 9 | ARGO2000 | CLOSED BUCKET | A1ARG20PBK007930  | T4.2407/1920210 |           | •            |  |  |



Powered by

