This Revit add-in not only batch exports multiple views from Revit into 'nwc' format but also includes linked model elements in the export and provides the user with a fine-grained control over important export settings.

Please go through the following you tube video for detailed information:

https://youtu.be/m6qXziVUhTU

For any queries or help required, kindly send an email to along with the snapshots of errors and contextual information:

Sanjiv.kapila@outlook.com

Just click on the 'Export NWC' button at 'Navis' panel on Add-ins tab of the Revit ribbon.

The app reminds you about the prerequisite that NWC export utility for the current Revit version must be installed on your system.

If it is installed, click 'Yes' to proceed.

If it is not installed, click 'No' to cancel.

The dialog box also displays the link to the url from where you can download and install this utility.

Once you click 'Yes', a list of all the 3D views in the project is presented for you to be able to select the required coordination views to be exported.

Please check the boxes against the views that need to be exported and click the 'ok' button.

The next dialog box is where this tool makes all the difference, few crucial settings can be controlled by the user such as whether you want to export linked model elements visible in the view or not, whether you want to use shared coordinates or project base point for export.

Or if you want to export room geometry and element properties or not.

The last two options are unchecked by default, the default settings work fine if you are exporting for clash coordination and review purposes.

After confirming these few crucial settings, click on the 'ok' button.

And that's it, all the selected views are exported in a folder named 'nwc' at your current project saved location.

At the end a dialog box shows the path of the exported nwc files and the number of views that are exported.