

Verify Isolations / LOTO Walkthrough (Job Aid)

Before an ESWC can be declared, every isolation must be checked against the HEC plan. **This sheet lists the four isolation points and what 'correct' looks like at each.**

Isolation point	What to confirm
1. Medium Voltage Switch (front)	Covers closed · switch in the OPEN position · blue lock and danger tag attached to the LOTO point.
2. 52-1 Breaker	Control power cabinet cover closed · breaker 52-1 OPEN and racked to the DISCONNECT position · LOTO applied.
3. Control Power Cabinet	Door closed · LOTO on the Control Power DISCONNECT (blue lock) — NOT on the control power fuse and NOT on the VT primary fuses.
4. Grounding (rear of MVS)	Cover closed · temporary protective grounds in place, in the correct location per the HEC plan · the spider connection carries the key linked to the red lock on the lockbox.

LOTO Walkthrough: Locks, Keys, & Common Errors

A. Review the LOTO & apply your lock

1. Review the established LOTO and grounding. The Job Lead's red lock and danger tag are already on the lockbox.
2. Spot what's missing: the MVS grounds need their OWN red lock and danger tag — add the second lockout device.
3. The lockbox holds two keys — one for the 52-1 breaker, one for the MVS grounds.
4. After all four isolations pass, place YOUR personal lock and tag on the lockbox.
5. Drop the key into the lockbox. **Do not skip this — it is a critical step.**

Remember

Opening the Control Power Cabinet or the rear MVS door exposes you to BOTH shock and arc flash. Wear the required PPE: safety glasses/goggles, ear plugs, hard hat with face shield + arc-rated balaclava (or arc-flash hood), Class 0/2 rubber gloves with matching leather protectors, leather boots, and the Compass Pro voltage detector.

B. Common errors to catch

Each isolation must match the HEC plan. Watch for:

- **LOTO in the wrong place** — move it to the correct location per the HEC plan (it IS needed for control of hazardous energy; don't remove it).
- **52-1 not in disconnect** — shift the breaker isolation so 52-1 is in the disconnect position.
- **Control Power Cabinet LOTO on the fuse** — move it to cover the Control Power Disconnect (blue lock); do not lock the VT primary fuses instead.
- **MVS grounds missing a lock/tag** — add the second red lock and danger tag.