MATLAB

matlab.mathworks.com

HOME PLOTS APPS EDITOR PUBLISH FILE VERSIONS VIEW Pratik

New Open Save FILE | Go To Find Bookmark NAVIGATE | Refactor CODE | Code Issues Debugger ANALYZE | Run Section Section Break Run and Advance Run to End SECTION | Run Step Stop RUN

/ > MATLAB Drive >

mcpractical1.m

Command Window

```
ans =

    'Vector of codes used for transmission:'


C =

    -1    -1    -1    -1
    -1     1    -1     1
    -1    -1     1     1
    -1     1     1    -1


ans =

    'Resulting traffic on the channel:'
```

Zoom: 110% UTF-8 CRLF script Ln 7 Col 5

MATLAB

matlab.mathworks.com

HOME PLOTS APPS EDITOR PUBLISH FILE VERSIONS VIEW Pratik

New Open Save FILE | Go To Find Bookmark NAVIGATE | Refactor CODE | Code Issues Debugger ANALYZE | Run Section Section Break Run and Advance Run to End SECTION | Run Step Stop RUN

/ > MATLAB Drive >

mcpractical1.m

Command Window

```
T =

    -2    -2     2    -2


ans =

    'Reconstructed data at the receiver:'


RECON =

     1
    -1
     1
     1
```

Zoom: 110% UTF-8 CRLF script Ln 7 Col 5


MATLAB
matlab.mathworks.com
HOME
PLOTS
APPS
EDITOR
PUBLISH
FILE VERSIONS
VIEW
Pratik
New
Open
Save
FILE
Go To
Find
Bookmark
NAVIGATE
Refactor
CODE
Code Issues
Debugger
ANALYZE
Run Section
Section Break
Run and Advance
Run to End
SECTION
Run
Step
Stop
RUN
/ › MATLAB Drive ›
mcpractical1.m
Command Window
>> mcpractical1
BETC04 Pratik Kothari
ans =
'Vector of data bits to be transmitted:'
D =
1
-1
1
1
ans =
Zoom: 110%
UTF-8
CRLF
script
Ln 7 Col 5