

Лабораторная работа. Настройка Rapid PVST+, PortFast и BPDU Guard (вариант для инструктора)

Примечание для инструктора. Красным шрифтом или серым фоном выделен текст, который отображается только в копии инструктора.

Топология




Таблица адресации

Устройство	Интерфейс	ІР-адрес	Маска подсети
S1	VLAN 99	192.168.1.11	255.255.255.0
S2	VLAN 99	192.168.1.12	255.255.255.0
S3	VLAN 99	192.168.1.13	255.255.255.0
PC-A	NIC	192.168.0.2	255.255.255.0
PC-C	NIC	192.168.0.3	255.255.255.0

Назначения сети VLAN

VLAN	РМИ			
10	User			
99	Management			

Задачи

Часть 1. Создание сети и настройка основных параметров устройства

Часть 2. Настройка сетей VLAN, native VLAN и транковых каналов

Часть 3. Настройка корневого моста и проверка сходимости PVST+

Часть 4. Настройка Rapid PVST+, PortFast, BPDU guard и проверка сходимости

Общие сведения/сценарий

Протокол spanning-tree для VLAN (PVST) является проприетарным протоколом Cisco. По умолчанию коммутаторы Cisco используют протокол PVST. Rapid PVST+ (IEEE 802.1w) является усовершенствованной версией PVST+ и обеспечивает более быстрые вычисления протокола spanning-tree и более быструю сходимость после изменений топологии 2-го уровня. Rapid PVST+ определяет три состояния порта: отбрасывание, обучение и пересылка, а также представляет ряд нововведений в целях оптимизации производительности сети.

В этой лабораторной работе вам предстоит настроить основной и вспомогательный корневые мосты, изучить сходимость PVST+, настроить Rapid PVST+ и сравнить его сходимость с PVST+. Кроме того, необходимо будет настроить пограничные порты для немедленного перехода в состояние пересылки с помощью PortFast, а также блокировать пересылку BDPU из пограничных портов, используя BDPU guard.

Примечание. В данной лабораторной работе содержится минимальный набор команд, необходимых для настройки. Список требуемых команд приведен в Приложении А. Проверьте свои знания: настройте устройства, не пользуясь приложениями.

Примечание. В практических лабораторных работах CCNA используются коммутаторы Cisco Catalyst 2960s с операционной системой Cisco IOS 15.0(2) (образ lanbasek9). Допускается использование других моделей коммутаторов и других версий Cisco IOS. В зависимости от модели устройства и версии Cisco IOS доступные команды и результаты их выполнения могут отличаться от тех, которые показаны в лабораторных работах.

Примечание. Убедитесь, что все настройки коммутатора удалены и загрузочная конфигурация отсутствует. Если вы не уверены, обратитесь к инструктору.

Примечание для инструктора. Порядок инициализации и перезагрузки устройств см. в руководстве по лабораторным работам для инструктора.

Необходимые ресурсы

- 3 коммутатора (Cisco 2960 с операционной системой Cisco IOS 15.0(2) (образ lanbasek9) или аналогичная модель)
- 2 ПК (Windows 7, Vista или XP с программой эмуляции терминала, например Tera Term)
- Консольные кабели для настройки устройств Cisco IOS через консольные порты
- Кабели Ethernet, расположенные в соответствии с топологией.

Часть 1: Создание сети и настройка основных параметров устройства

В части 1 вы настроите топологию сети и такие базовые параметры, как IP-адреса интерфейсов, доступ к устройствам и пароли.

Шаг 1: Создайте сеть согласно топологии.

Шаг 2: Настройте узлы ПК.

Шаг 3: Выполните инициализацию и перезагрузку коммутаторов.

Шаг 4: Настройте базовые параметры каждого коммутатора.

- а. Отключите поиск DNS.
- Присвойте имена устройствам в соответствии с топологией.
- с. Назначьте **cisco** в качестве пароля консоли и виртуального терминала VTY и включите запрос пароля при подключении.
- d. Назначьте class в качестве зашифрованного пароля доступа к привилегированному режиму.
- e. Hactpoйte logging synchronous, чтобы сообщения от консоли не могли прерывать ввод команд.
- f. Отключите все порты коммутатора.
- д. Сохраните текущую конфигурацию в загрузочную конфигурацию.

Часть 2: Настройка сетей VLAN, native VLAN и транковых каналов

В части 2 рассматриваются создание сетей VLAN, назначения сетям VLAN портов коммутатора, настройка транковых портов и изменение native VLAN для всех коммутаторов.

Примечание. Команды, необходимые для работы по части 2, указаны в Приложении А. Проверьте свои знания и попытайтесь настроить сети VLAN, сеть VLAN с нетегированным трафиком и магистрали, не заглядывая в это приложение.

Шаг 1: Создайте сети VLAN.

Используйте соответствующие команды, чтобы создать сети VLAN 10 и 99 на всех коммутаторах. Присвойте сети VLAN 10 имя **User**, а сети VLAN 99 — имя **Management**.

```
S1(config) # vlan 10
S1(config-vlan) # name User
S1(config-vlan) # vlan 99
S1(config-vlan) # name Management

S2(config) # vlan 10
S2(config-vlan) # name User
S2(config-vlan) # vlan 99
S2(config-vlan) # name Management

S3(config) # vlan 10
S3(config-vlan) # name User
S3(config-vlan) # name User
S3(config-vlan) # name User
S3(config-vlan) # name Management
```

Шаг 2: Переведите пользовательские порты в режим доступа и назначьте сети VLAN.

Для интерфейса F0/6 S1 и интерфейса F0/18 S3 включите порты, настройте их в качестве портов доступа и назначьте их сети VLAN 10.

```
S1(config) # interface f0/6
S1(config-if) # no shutdown
S1(config-if) # switchport mode access
S1(config-if) # switchport access vlan 10
```

```
S3(config) # interface f0/18
S3(config-if) # no shutdown
S3(config-if) # switchport mode access
S3(config-if) # switchport access vlan 10
```

Шаг 3: Настройте транковые порты и назначьте их сети native VLAN 99.

Для портов F0/1 и F0/3 на всех коммутаторах включите порты, настройте их в качестве транковых и назначьте их сети native VLAN 99.

```
S1(config)# interface range f0/1,f0/3
S1(config-if)# no shutdown
S1(config-if)# switchport mode trunk
S1(config-if)# switchport trunk native vlan 99
S2(config)# interface range f0/1,f0/3
S2(config-if)# no shutdown
S2(config-if)# switchport mode trunk
S2(config-if)# switchport trunk native vlan 99
S3(config-if)# interface range f0/1,f0/3
S3(config-if)# no shutdown
S3(config-if)# switchport mode trunk
S3(config-if)# switchport mode trunk
S3(config-if)# switchport trunk native vlan 99
```

Шаг 4: Настройте административный интерфейс на всех коммутаторах.

Используя таблицу адресации, настройте на всех коммутаторах административный интерфейс с соответствующим IP-адресом.

```
S1(config)# interface vlan 99
S1(config-if)# ip address 192.168.1.11 255.255.255.0

S2(config)# interface vlan 99
S2(config-if)# ip address 192.168.1.12 255.255.255.0

S3(config)# interface vlan 99
S3(config-if)# ip address 192.168.1.13 255.255.255.0
```

Шаг 5: Проверка конфигураций и возможности подключения.

S1# show vlan brief

Используйте команду **show vlan brief** на всех коммутаторах, чтобы убедиться в том, что все сети VLAN внесены в таблицу VLAN и назначены правильные порты.

```
VLAN Name Status Ports

1 default active Fa0/2, Fa0/4, Fa0/5, Fa0/7
Fa0/8, Fa0/9, Fa0/10, Fa0/11
```

```
Fa0/12, Fa0/13, Fa0/14, Fa0/15
                                         Fa0/16, Fa0/17, Fa0/18, Fa0/19
                                         Fa0/20, Fa0/21, Fa0/22, Fa0/23
                                         Fa0/24, Gi0/1, Gi0/2
                                        Fa0/6
10 User
                                active
99 Management
                                active
1002 fddi-default
                                act/unsup
1003 token-ring-default
                                act/unsup
1004 fddinet-default
                                act/unsup
1005 trnet-default
                                act/unsup
S2# show vlan brief
VLAN Name
                                Status Ports
____ ______
1 default
                                active Fa0/2, Fa0/4, Fa0/5, Fa0/6
                                        Fa0/7, Fa0/8, Fa0/9, Fa0/10
                                        Fa0/11, Fa0/12, Fa0/13, Fa0/14
                                         Fa0/15, Fa0/16, Fa0/17, Fa0/18
                                         Fa0/19, Fa0/20, Fa0/21, Fa0/22
                                         Fa0/23, Fa0/24, Gi0/1, Gi0/2
10 User
                                active
99 Management
                                active
1002 fddi-default
                                act/unsup
1003 token-ring-default
                                act/unsup
1004 fddinet-default
                                act/unsup
1005 trnet-default
                                act/unsup
S3# show vlan brief
VLAN Name
                                Status Ports
____ _______
1 default
                                active Fa0/2, Fa0/4, Fa0/5, Fa0/6
                                        Fa0/7, Fa0/8, Fa0/9, Fa0/10
                                         Fa0/11, Fa0/12, Fa0/13, Fa0/14
                                        Fa0/15, Fa0/16, Fa0/17, Fa0/19
                                         Fa0/20, Fa0/21, Fa0/22, Fa0/23
                                        Fa0/24, Gi0/1, Gi0/2
10 User
                                active
                                        Fa0/18
99 Management
                                active
1002 fddi-default
                                act/unsup
1003 token-ring-default
                                act/unsup
1004 fddinet-default
                                act/unsup
1005 trnet-default
                                act/unsup
```

Используйте команду **show interfaces trunk** на всех коммутаторах для проверки магистральных интерфейсов.

S1# show interfaces trunk

Лабораторная работа. Настройка Rapid PVST+, PortFast и BPDU Guard

Port	Mode	Encapsulation		Native vlan	
Fa0/1	on	802.1q	trunking	99	
Fa0/3	on	802.1q	trunking	99	
Port	Vlans allowed on	trunk			
Fa0/1	1-4094				
Fa0/3	1-4094				
Port	Vlans allowed an	d active in man	agement domain		
Fa0/1	1,10,99				
Fa0/3	1,10,99				
Port	Vlans in spannin	g tree forwardi	ng state and n	ot pruned	
Fa0/1	none				
Fa0/3	1,10,99				
S2# show i	nterfaces trunk				
Port	Mode	Encapsulation		Native vlan	
Fa0/1	on		trunking	99	
Fa0/3	on	802.1q	trunking	99	

Port	Vlans allowed on	trunk			
Fa0/1	1-4094				
Fa0/3	1-4094				
Dowt	Wlane allowed an	d action in man	agamant damain		
Port Fa0/1	Vlans allowed an	d active in man	agement domain		
Fa0/1	1,10,99				
FaU/3	1,10,99				
Port	Vlans in spannin	a troo forwardi	ng etato and n	ot prunod	
Fa0/1	1,10,99	g tiee loiwaldi	ing state and in	ot pruned	
Fa0/1	1,10,99				
Fa0/3	1,10,99				
93# show i	nterfaces trunk				
SSW SHOW I	interraces crank				
Port	Mode	Encapsulation	Status	Native vlan	
Fa0/1	on		trunking	99	
Fa0/3	on	802.1q	trunking	99	
Port	Vlans allowed on	trunk			
Fa0/1	1-4094				
Fa0/3	1-4094				
•					
Port	Vlans allowed an	d active in man	agement domain		
Fa0/1	1,10,99				
Fa0/3	1,10,99				
Port	Vlans in spannin	g tree forwardi	ng state and n	ot pruned	

```
Fa0/1 1,10,99
Fa0/3 1,10,99
```

Используйте команду **show running-config** на всех коммутаторах, чтобы проверить все остальные конфигурации.

```
S1# show running-config
Building configuration...
Current configuration: 1857 bytes
version 15.0
no service pad
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
hostname S1
boot-start-marker
boot-end-marker
enable secret 4 06YFDUHH61wAE/kLkDq9BGho1QM5EnRtoyr8cHAUg.2
no aaa new-model
system mtu routing 1500
no ip domain-lookup
spanning-tree mode pvst
spanning-tree extend system-id
vlan internal allocation policy ascending
interface FastEthernet0/1
 switchport trunk native vlan 99
 switchport mode trunk
interface FastEthernet0/2
 shutdown
interface FastEthernet0/3
 switchport trunk native vlan 99
 switchport mode trunk
interface FastEthernet0/4
```

```
shutdown
interface FastEthernet0/5
shutdown
interface FastEthernet0/6
 switchport access vlan 10
switchport mode access
interface FastEthernet0/7
shutdown
interface FastEthernet0/8
shutdown
interface FastEthernet0/9
shutdown
interface FastEthernet0/10
shutdown
interface FastEthernet0/11
shutdown
interface FastEthernet0/12
shutdown
interface FastEthernet0/13
shutdown
1
interface FastEthernet0/14
shutdown
interface FastEthernet0/15
 shutdown
interface FastEthernet0/16
shutdown
interface FastEthernet0/17
 shutdown
interface FastEthernet0/18
 shutdown
```

```
interface FastEthernet0/19
shutdown
interface FastEthernet0/20
shutdown
interface FastEthernet0/21
shutdown
interface FastEthernet0/22
shutdown
interface FastEthernet0/23
shutdown
interface FastEthernet0/24
shutdown
interface GigabitEthernet0/1
shutdown
interface GigabitEthernet0/2
shutdown
interface Vlan1
no ip address
interface Vlan99
ip address 192.168.1.11 255.255.255.0
1
ip http server
ip http secure-server
line con 0
password cisco
logging synchronous
login
line vty 0 4
password cisco
login
line vty 5 15
password cisco
login
!
end
```

Какие настрой	ки используются	я для режима протокола spa	nning-tree ι	на коммутаторах С	isco?
По умолчанию	используется р	ежим протокола spanning-tre	ee PVST+.		
Проверьте под		у компьютерами РС-А и РС	-С. Удалос	ь ли получить отве	т на ping-запрос?
Если эхо-запр будет решена.		удалось, следует выполня	гь отладку	до тех пор, пока пр	облема не
Примечание.	Для успешной п	ередачи эхо-запросов може	т потребов	аться отключение	брандмауэра.
Часть 3: На	астройка ко	рневого моста и п	роверка	а сходимост	и PVST+
		делить корневой мост по ум мосты и использовать коман			
		одимые для работы по част строить корневой мост, не з			
Шаг 1: Опреде	элите текущий	і корневой мост.			
С помощью ка	кой команды пол	пьзователи определяют сос /LAN? Запишите команду в			е коммутатора
show spannin	g-tree				
Выполните ког	ианду на всех тр	ех коммутаторах, чтобы оты	ветить на с	педующие вопрось	4:
умолчанию на создавать отд	коммутаторах С ельный экземпл	нутаторе доступно три экзем Cisco используется конфигур яр протокола spanning-tree д вователем сети VLAN).	ация STP I	PVST+, которая по	зволяет
Каков приорит	ет моста коммут	татора S1 для сети VLAN 1?		32769	
Каков приорит	ет моста коммут	татора S2 для сети VLAN 1?		32769	
Каков приорит	ет моста коммут	татора S3 для сети VLAN 1?		32769	
	тор является ко эигурации это ко	рневым мостом? ммутатор S3.	_ Возможн	ы различные вари	анты ответов.
	, , ,	ан в качестве корневого мос	ста?		
адреса.	протокол spann	ning-tree выбирает корневой	мост с уче	том наименьшего з	начения МАС-
VLAN0001					
	=	protocol ieee			
Root ID		32769 0cd9.96d2.5100			
	Address Cost				

Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

3 (FastEthernet0/3)

Bridge ID	Address)	sys-id-ext 1) Forward Delay 15 sec
Interface		Sts Cost		
Fa0/1		FWD 19		
Fa0/3	Root	FWD 19	128.3	P2p
VLAN0010				
Spanning to	ree enabled p	protocol ieee		
Root ID	Priority	32778		
	Address	0cd9.96d2.5100)	
	Cost	19		
	Port	3 (FastEtherne	et0/3)	
	Hello Time	2 sec Max A	ge 20 sec	Forward Delay 15 sec
Bridge ID	Priority	32778 (prior:	ity 32768	sys-id-ext 10)
	Address	0cd9.96e2.3d80)	
	Hello Time	2 sec Max A	ge 20 sec	Forward Delay 15 sec
	Aging Time	300 sec		
Interface		Sts Cost		Type
Fa0/1		FWD 19		P2p
Fa0/3	Root	FWD 19	128.3	P2p
Fa0/6	Desg	FWD 19	128.6	P2p
VLAN0099				
Spanning tree enabled protocol ieee				
Root ID	Priority	32867		
Address		0cd9.96d2.5100		
	Cost	19		
	Port	3 (FastEtherne	et0/3)	
	Hello Time	2 sec Max A	ge 20 sec	Forward Delay 15 sec
Bridge ID	Priority	32867 (prior:	ity 32768	sys-id-ext 99)
	Address	0cd9.96e2.3d80)	
		2 soc May N	ge 20 sec	Forward Delay 15 sec
	Hello Time	2 Sec Max A		
	Hello Time Aging Time			-
	Aging Time Role	300 sec Sts Cost	Prio.Nbr	
	Aging Time Role	300 sec Sts Cost	Prio.Nbr	Туре
	Aging Time Role Desg	300 sec Sts Cost	Prio.Nbr 128.1	Type P2p

S2# show spanning-tree

```
VLAN0001
 Spanning tree enabled protocol ieee
 Root ID Priority 32769
          Address 0cd9.96d2.5100
                    19
          Cost
                   3 (FastEthernet0/3)
          Port
          Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
 Bridge ID Priority 32769 (priority 32768 sys-id-ext 1)
                   0cd9.96e8.6f80
          Address
          Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
          Aging Time 300 sec
Interface
               Role Sts Cost
                               Prio.Nbr Type
Altn BLK 19 128.1 P2p
Root FWD 19 128.3 P2p
               Altn BLK 19
Fa0/3
VLAN0010
 Spanning tree enabled protocol ieee
 Root ID Priority 32778
          Address 0cd9.96d2.5100
                   19
          Cost
          Port 3 (FastEthernet0/3)
          Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
 Bridge ID Priority 32778 (priority 32768 sys-id-ext 10)
          Address 0cd9.96e8.6f80
          Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
          Aging Time 300 sec
               Role Sts Cost Prio.Nbr Type
               Altn BLK 19
Fa0/1
                             128.1 P2p
                Root FWD 19 128.3 P2p
Fa0/3
VLAN0099
 Spanning tree enabled protocol ieee
 Root ID Priority 32867
          Address 0cd9.96d2.5100
                    19
          Cost
                   3 (FastEthernet0/3)
          Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
 Bridge ID Priority 32867 (priority 32768 sys-id-ext 99)
                   0cd9.96e8.6f80
          Address
           Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
          Aging Time 300 sec
```

Interface	Role	Sts Cost	Prio.Nbr	Туре
Fa0/1	Altn	BLK 19	128 1	P2n
	Root			
				•
S3# show spa	nning-tree			
VLAN0001				
Spanning t	ree enabled p	protocol iee	е	
Root ID	Priority	32769		
	Address	0cd9.96d2.5100		
		is the root		
	Hello Time	2 sec Max	Age 20 sec	Forward Delay 15 sec
Bridge ID	Priority	32769 (pri	ority 32768	sys-id-ext 1)
	Address	0cd9.96d2.5	100	
	Hello Time	2 sec Max	Age 20 sec	Forward Delay 15 sec
	Aging Time	300 sec		
Interface	Role	Sts Cost	Prio.Nbr	Туре
				P2-
Fa0/1		FWD 19		
Fa0/3	Desg	FWD 19	128.3	P2p
VLAN0010				
Spanning t	ree enabled p	protocol iee	е	
Root ID	Priority	32778		
	Address	0cd9.96d2.5		
	This bridge	is the root		
	Hello Time	2 sec Max	Age 20 sec	Forward Delay 15 sec
Bridge ID	Priority	32778 (pri	ority 32768	sys-id-ext 10)
3	Address		_	
				Forward Delay 15 sec
	Aging Time			-
Interface	Role	Sts Cost	Prio.Nbr	Type
Fa0/1	Desg	FWD 19	128.1	P2p
Fa0/3	Desg	FWD 19	128.3	P2p
Fa0/18	Desg	FWD 19	128.18	P2p
VLAN0099				
Spanning tree enabled protocol ieee				
Root ID	Priority	32867		
	Address	0cd9.96d2.5100		
		is the root		
	Hello Time	2 sec Max	Age 20 sec	Forward Delay 15 sec

```
Bridge ID Priority 32867 (priority 32768 sys-id-ext 99)

Address 0cd9.96d2.5100

Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
Aging Time 300 sec

Interface Role Sts Cost Prio.Nbr Type

Fa0/1 Desg FWD 19 128.1 P2p
Fa0/3 Desg FWD 19 128.3 P2p
```

Шаг 2: Настройте основной и вспомогательный корневые мосты для всех существующих сетей VLAN.

При выборе корневого моста (коммутатора) по MAC-адресу может образоваться условно оптимальная конфигурация. В этой лабораторной работе вам необходимо настроить коммутатор S2 в качестве корневого моста и коммутатор S1 — в качестве вспомогательного корневого моста.

а. Настройте коммутатор S2 в качестве основного корневого моста для всех существующих сетей VLAN. Запишите команду в строке ниже.

```
S2(config) # spanning-tree vlan 1,10,99 root primary
```

b. Настройте коммутатор S1 в качестве вспомогательного корневого моста для всех существующих сетей VLAN. Запишите команду в строке ниже.

S1# show spanning-tree vlan 1

VLAN0001

```
Spanning tree enabled protocol ieee

Root ID Priority 24577
Address 0cd9.96d2.4000
Cost 19
Port 1 (FastEthernet0/1)
Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Bridge ID Priority 28673 (priority 28672 sys-id-ext 1)
Address 0cd9.96e8.8a00
Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
Aging Time 15 sec

Role Sts Cost Prio.Nbr Type
```

```
Fa0/1
              Root FWD 19
                            128.1 P2p
              Desg FWD 19 128.3 P2p
Fa0/3
S2# show spanning-tree vlan 1
VLAN0001
 Spanning tree enabled protocol ieee
 Root ID Priority 24577
         Address 0cd9.96d2.4000
         This bridge is the root
         Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
 Bridge ID Priority 24577 (priority 24576 sys-id-ext 1)
         Address 0cd9.96d2.4000
         Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
         Aging Time 15 sec
Interface
             Role Sts Cost Prio.Nbr Type
Desg FWD 19
                            128.1 P2p
              Desg FWD 19 128.3 P2p
Fa0/3
S3# show spanning-tree vlan 1
VLAN0001
 Spanning tree enabled protocol ieee
 Root ID Priority 24577
         Address 0cd9.96d2.4000
         Cost
                  19
                 1 (FastEthernet0/1)
         Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
 Bridge ID Priority 32769 (priority 32768 sys-id-ext 1)
                 0cd9.96e8.7400
         Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
         Aging Time 300 sec
              Role Sts Cost Prio.Nbr Type
Fa0/1
             Root FWD 19
                            128.1 P2p
              Altn BLK 19 128.3 P2p
Fa0/3
```

Шаг 3: Измените топологию 2-го уровня и проверьте сходимость.

Чтобы проверить сходимость PVST+, необходимо создать изменение топологии 2-го уровня, используя команду **debug** для отслеживания событий протокола spanning-tree.

выполните команду debug spanning-tree events в привилегированном режиме на коммутаторе S3.

```
S3# debug spanning-tree events
Spanning Tree event debugging is on
```

b. Измените топологию, отключив интерфейс F0/1 на коммутаторе S3.

```
S3(config) # interface f0/1
S3(config-if) # shutdown
*Mar 1 00:58:56.225: STP: VLAN0001 new root port Fa0/3, cost 38
*Mar 1 00:58:56.225: STP: VLAN0001 Fa0/3 -> listening
*Mar 1 00:58:56.225: STP[1]: Generating TC trap for port FastEthernet0/1
*Mar 1 00:58:56.225: STP: VLAN0010 new root port Fa0/3, cost 38
*Mar 1 00:58:56.225: STP: VLAN0010 Fa0/3 -> listening
*Mar 1 00:58:56.225: STP[10]: Generating TC trap for port FastEthernet0/1
*Mar 1 00:58:56.225: STP: VLAN0099 new root port Fa0/3, cost 38
*Mar 1 00:58:56.225: STP: VLAN0099 Fa0/3 -> listening
*Mar 1 00:58:56.225: STP[99]: Generating TC trap for port FastEthernet0/1
*Mar 1 0:58:56.242: %LINEPROTO-5-UPDOWN: Line protocol on Interface Vlan1, changed
*Mar 1 00:58:56.242: %LINEPROTO-5-UPDOWN: Line protocol on Interface Vlan99, changed
state to down
*Mar 1 00:58:58.214: %LINK-5-CHANGED: Interface FastEthernet0/1, changed state to
administratively down
*Mar 1 00:58:58.230: STP: VLAN0001 sent Topology Change Notice on Fa0/3
*Mar 1 00:58:58.230: STP: VLAN0010 sent Topology Change Notice on Fa0/3
*Mar 1 00:58:58.230: STP: VLAN0099 sent Topology Change Notice on Fa0/3
*Mar 1 0:58:59.220: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/1,
changed state to down
*Mar 1 00:59:11.233: STP: VLAN0001 Fa0/3 -> learning
*Mar 1 00:59:11.233: STP: VLAN0010 Fa0/3 -> learning
*Mar 1 00:59:11.233: STP: VLAN0099 Fa0/3 -> learning
*Mar 1 0:59:26.240: STP[1]: Generating TC trap for port FastEthernet0/3
*Mar 1 00:59:26.240: STP: VLAN0001 Fa0/3 -> forwarding
*Mar 1 0:59:26.240: STP[10]: Generating TC trap for port FastEthernet0/3
*Mar 1 0:59:26.240: STP: VLAN0010 sent Topology Change Notice on Fa0/3
*Mar 1 00:59:26.240: STP: VLAN0010 Fa0/3 -> forwarding
*Mar 1 0:59:26.240: STP[99]: Generating TC trap for port FastEthernet0/3
*Mar 1 00:59:26.240: STP: VLAN0099 Fa0/3 -> forwarding
*Mar 1 0:59:26.248: %LINEPROTO-5-UPDOWN: Line protocol on Interface Vlan1, changed
state to up
*Mar 1 0:59:26.248: %LINEPROTO-5-UPDOWN: Line protocol on Interface Vlan99, changed
state to up
```

Примечание. Прежде чем продолжить, исходя из выходных данных команды **debug** убедитесь, что все сети VLAN на интерфейсе F0/3 перешли в состояние пересылки, после чего используйте команду **no debug spanning-tree events**, чтобы остановить вывод данных командой **debug**.

Через какие состояния портов проходит каждая сеть VLAN на интерфейсе F0/3 в процессе схождения сети?

Прослушивание, получение данных и пересылка

Используя временную метку из первого и последнего сообщений отладки STP, рассчитайте время (округляя до секунды), которое потребовалось для схождения сети. **Рекомендация**. Формат временной метки сообщений отладки: чч.мм.сс.мс

Возможны различные варианты ответов, однако время сходимости должно составлять примерно 30 секунд.

Часть 4: Настройка Rapid PVST+, PortFast, BPDU Guard и проверка сходимости

В части 4 вам предстоит настроить Rapid PVST+ на всех коммутаторах. Вам необходимо будет настроить функции PortFast и BPDU guard на всех портах доступа, а затем использовать команду **debug** для проверки сходимости Rapid PVST+.

Примечание. Команды, необходимые для работы по части 4, указаны в Приложении А. Проверьте свои знания и попытайтесь настроить Rapid PVST+, PortFast и BPDU Guard, не заглядывая в это приложение.

Шаг 1: Настройте Rapid PVST+.

а. Настройте S1 для использования Rapid PVST+. Запишите команду в строке ниже.

```
S1(config) # spanning-tree mode rapid-pvst
```

b. Настройте коммутаторы S2 и S3 для Rapid PVST+.

```
S2(config) # spanning-tree mode rapid-pvst
S3(config) # spanning-tree mode rapid-pvst
```

с. Проверьте конфигурации с помощью команды show running-config | include spanning-tree mode.

```
S1# show running-config | include spanning-tree mode spanning-tree mode rapid-pvst

S2# show running-config | include spanning-tree mode spanning-tree mode rapid-pvst

S3# show running-config | include spanning-tree mode spanning-tree mode rapid-pvst
```

Шаг 2: Настройте PortFast и BPDU Guard на портах доступа.

PortFast является функцией протокола spanning-tree, которая переводит порт в состояние пересылки сразу после его включения. Эту функцию рекомендуется использовать при подключении узлов, чтобы они могли начать обмен данными по сети VLAN немедленно, не дожидаясь протокола spanning-tree. Чтобы запретить портам, настроенным с использованием PortFast, пересылать кадры BPDU, которые могут изменить топологию протокола spanning-tree, можно включить функцию BPDU guard. После получения BPDU функция BPDU Guard отключает порт, настроенный с помощью функции PortFast.

а. Настройте F0/6 на S1 с помощью функции PortFast. Запишите команду в строке ниже.

```
S1(config)# interface f0/6
S1(config-if)# spanning-tree portfast
```

b. Настройте F0/6 на S1 с помощью функции BPDU Guard. Запишите команду в строке ниже.

```
S1(config)# interface f0/6
S1(config-if)# spanning-tree bpduguard enable
```

с. Глобально настройте все нетранковые порты на коммутаторе S3 с помощью функции PortFast. Запишите команду в строке ниже.

```
S3(config) # spanning-tree portfast default
```

d. Глобально настройте все нетранковые порты на коммутаторе S3 с помощью функции BPDU. Запишите команду в строке ниже.

```
S3(config) # spanning-tree portfast bpduguard default
```

Шаг 3: Проверьте сходимость Rapid PVST+.

- а. Выполните команду debug spanning-tree events в привилегированном режиме на коммутаторе S3.
- b. Измените топологию, отключив интерфейс F0/1 на коммутаторе S3.

```
S3(config) # interface f0/1
S3(config-if) # no shutdown
*Mar 1 01:28:34.946: %LINK-3-UPDOWN: Interface FastEthernet0/1, changed state to up
*Mar 1 01:28:37.588: RSTP(1): initializing port Fa0/1
*Mar 1 01:28:37.588: RSTP(1): Fa0/1 is now designated
*Mar 1 01:28:37.588: RSTP(10): initializing port Fa0/1
*Mar 1 01:28:37.588: RSTP(10): Fa0/1 is now designated
*Mar 1 01:28:37.588: RSTP(99): initializing port Fa0/1
*Mar 1 01:28:37.588: RSTP(99): Fa0/1 is now designated
*Mar 1 01:28:37.597: RSTP(1): transmitting a proposal on Fa0/1
*Mar 1 01:28:37.597: RSTP(10): transmitting a proposal on Fa0/1
*Mar 1 01:28:37.597: RSTP(99): transmitting a proposal on Fa0/1
*Mar 1 01:28:37.597: RSTP(1): updt roles, received superior bpdu on Fa0/1
*Mar 1 01:28:37.597: RSTP(1): Fa0/1 is now root port
*Mar 1 01:28:37.597: RSTP(1): Fa0/3 blocked by re-root
*Mar 1 01:28:37.597: RSTP(1): synced Fa0/1
*Mar 1 01:28:37.597: RSTP(1): Fa0/3 is now alternate
*Mar 1 01:28:37.597: RSTP(10): updt roles, received superior bpdu on Fa0/1
*Mar 1 01:28:37.597: RSTP(10): Fa0/1 is now root port
*Mar 1 01:28:37.597: RSTP(10): Fa0/3 blocked by re-root
*Mar 1 01:28:37.597: RSTP(10): synced Fa0/1
*Mar 1 01:28:37.597: RSTP(10): Fa0/3 is now alternate
*Mar 1 01:28:37.597: RSTP(99): updt roles, received superior bpdu on Fa0/1
*Mar 1 01:28:37.605: RSTP(99): Fa0/1 is now root port
*Mar 1 01:28:37.605: RSTP(99): Fa0/3 blocked by re-root
*Mar 1 01:28:37.605: RSTP(99): synced Fa0/1
*Mar 1 01:28:37.605: RSTP(99): Fa0/3 is now alternate
*Mar 1 1:28:37.605: STP[1]: Generating TC trap for port FastEthernet0/1
*Mar 1 1:28:37.605: STP[10]: Generating TC trap for port FastEthernet0/1
*Mar 1 1:28:37.605: STP[99]: Generating TC trap for port FastEthernet0/1
*Mar 1 01:28:37.622: RSTP(1): transmitting an agreement on Fa0/1 as a response to
a proposal
*Mar 1 01:28:37.622: RSTP(10): transmitting an agreement on Fa0/1 as a response to
<mark>a proposal</mark>
```

```
*Mar 1 01:28:37.622: RSTP(99): transmitting an agreement on Fa0/1 as a response to a proposal
```

```
*Mar 1 1:28:38.595: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/1, changed state to up
```

Используя временную метку из первого и последнего сообщений отладки RSTP, рассчитайте время, которое потребовалось для схождения сети.

Возможны различные варианты ответов, однако время схождения не должно превышать одну секунду.

Вопросы для повторения

1. В чем заключается главное преимущество Rapid PVST+?

Rapid PVST+ существенно уменьшает время схождения на 2-м уровне по протоколу PVST+.

2. Каким образом настройка порта с помощью функции PortFast обеспечивает более быстрое схождение?

PortFast позволяет немедленно перевести порт доступа в состояние пересылки, что существенно сокращает время схождения 2-го уровня.

3. Какую защиту обеспечивает функция BPDU Guard?

BPDU guard обеспечивает защиту домена STP путем отключения портов доступа, которые получают кадр BPDU. Кадры BPDU можно использовать в случае атаки типа «отказ в обслуживании», которая изменяет корневой мост домена и инициирует повторное вычисление STP.

Приложение А. Команды настройки коммутатора

```
S1(config) # vlan 10
S1(config-vlan) # name User
S1(config-vlan) # vlan 99
S1(config-vlan) # name Management
S1(config-vlan)# exit
S1(config)# interface f0/6
S1(config-if) # no shutdown
S1(config-if)# switchport mode access
S1(config-if)# switchport access vlan 10
S1(config-if)# interface f0/1
S1(config-if) # no shutdown
S1(config-if)# switchport mode trunk
S1(config-if) # switchport trunk native vlan 99
S1(config-if) # interface f0/3
S1(config-if) # no shutdown
S1(config-if)# switchport mode trunk
S1(config-if) # switchport trunk native vlan 99
```

```
S1(config-if)# interface vlan 99
S1(config-if)# ip address 192.168.1.11 255.255.255.0
S1(config-if)# exit
S1(config)# spanning-tree vlan 1,10,99 root secondary
S1(config)# spanning-tree mode rapid-pvst
S1(config)# interface f0/6
S1(config-if)# spanning-tree portfast
S1(config-if)# spanning-tree bpduguard enable
```

Коммутатор S2

```
S2(config) # vlan 10
S2(config-vlan) # name User
S2(config-vlan) # vlan 99
S2(config-vlan) # name Management
S2(config-vlan)# exit
S2(config)# interface f0/1
S2(config-if) # no shutdown
S2(config-if)# switchport mode trunk
S2(config-if) # switchport trunk native vlan 99
S2(config-if)# interface f0/3
S2(config-if) # no shutdown
S2(config-if) # switchport mode trunk
S2(config-if) # switchport trunk native vlan 99
S2(config-if)# interface vlan 99
S2(config-if) # ip address 192.168.1.12 255.255.255.0
S2(config-if)# exit
S2(config) # spanning-tree vlan 1,10,99 root primary
S2(config)# spanning-tree mode rapid-pvst
```

```
S3(config) # vlan 10
S3(config-vlan) # name User
S3(config-vlan) # vlan 99
S3(config-vlan) # name Management
S3(config-vlan) # exit
S3(config) # interface f0/18
S3(config-if) # no shutdown
S3(config-if) # switchport mode access
S3(config-if) # switchport access vlan 10
S3(config-if) # spanning-tree portfast
S3(config-if) # spanning-tree bpduguard enable
S3(config-if) # interface f0/1
S3(config-if) # interface f0/1
S3(config-if) # switchport mode trunk
S3(config-if) # switchport trunk native vlan 99
```

```
S3(config-if)# interface f0/3
S3(config-if)# no shutdown
S3(config-if)# switchport mode trunk
S3(config-if)# switchport trunk native vlan 99
S3(config-if)# interface vlan 99
S3(config-if)# ip address 192.168.1.13 255.255.255.0
S3(config-if)# exit
S3(config)# spanning-tree mode rapid-pvst
```

Конфигурации устройств — итоговые

```
S1#show run
Building configuration...
Current configuration: 1963 bytes
version 15.0
no service pad
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
hostname S1
boot-start-marker
boot-end-marker
enable secret 4 06YFDUHH61wAE/kLkDq9BGho1QM5EnRtoyr8cHAUg.2
no aaa new-model
system mtu routing 1500
no ip domain-lookup
spanning-tree mode rapid-pvst
spanning-tree extend system-id
spanning-tree vlan 1,10,99 priority 28672
vlan internal allocation policy ascending
interface FastEthernet0/1
 switchport trunk native vlan 99
 switchport mode trunk
interface FastEthernet0/2
 shutdown
interface FastEthernet0/3
 switchport trunk native vlan 99
 switchport mode trunk
interface FastEthernet0/4
shutdown
```

```
interface FastEthernet0/5
shutdown
interface FastEthernet0/6
switchport access vlan 10
switchport mode access
spanning-tree portfast
spanning-tree bpduguard enable
interface FastEthernet0/7
shutdown
interface FastEthernet0/8
shutdown
interface FastEthernet0/9
shutdown
interface FastEthernet0/10
shutdown
interface FastEthernet0/11
shutdown
interface FastEthernet0/12
shutdown
interface FastEthernet0/13
shutdown
interface FastEthernet0/14
shutdown
interface FastEthernet0/15
shutdown
interface FastEthernet0/16
shutdown
interface FastEthernet0/17
shutdown
interface FastEthernet0/18
shutdown
interface FastEthernet0/19
shutdown
interface FastEthernet0/20
shutdown
interface FastEthernet0/21
shutdown
interface FastEthernet0/22
shutdown
```

```
interface FastEthernet0/23
shutdown
interface FastEthernet0/24
shutdown
interface GigabitEthernet0/1
shutdown
interface GigabitEthernet0/2
shutdown
interface Vlan1
no ip address
interface Vlan99
ip address 192.168.1.11 255.255.255.0
ip http server
ip http secure-server
line con 0
password cisco
logging synchronous
login
line vty 0 4
password cisco
login
line vty 5 15
password cisco
login
end
```

```
S2#show run
Building configuration...

Current configuration: 1864 bytes
!
version 15.0
no service pad
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
!
hostname S2
!
boot-start-marker
boot-end-marker
!
enable secret 4 06YFDUHH61wAE/kLkDq9BGho1QM5EnRtoyr8cHAUg.2
```

```
no aaa new-model
system mtu routing 1500
no ip domain-lookup
spanning-tree mode rapid-pvst
spanning-tree extend system-id
spanning-tree vlan 1,10,99 priority 24576
vlan internal allocation policy ascending
interface FastEthernet0/1
switchport trunk native vlan 99
switchport mode trunk
interface FastEthernet0/2
shutdown
interface FastEthernet0/3
switchport trunk native vlan 99
switchport mode trunk
interface FastEthernet0/4
shutdown
interface FastEthernet0/5
shutdown
interface FastEthernet0/6
shutdown
interface FastEthernet0/7
shutdown
interface FastEthernet0/8
shutdown
interface FastEthernet0/9
shutdown
interface FastEthernet0/10
shutdown
interface FastEthernet0/11
shutdown
interface FastEthernet0/12
shutdown
```

```
interface FastEthernet0/13
shutdown
interface FastEthernet0/14
shutdown
interface FastEthernet0/15
shutdown
interface FastEthernet0/16
shutdown
interface FastEthernet0/17
shutdown
interface FastEthernet0/18
shutdown
interface FastEthernet0/19
shutdown
interface FastEthernet0/20
shutdown
interface FastEthernet0/21
shutdown
interface FastEthernet0/22
shutdown
interface FastEthernet0/23
shutdown
interface FastEthernet0/24
shutdown
interface GigabitEthernet0/1
shutdown
interface GigabitEthernet0/2
shutdown
interface Vlan1
no ip address
interface Vlan99
ip address 192.168.1.12 255.255.255.0
!
```

```
ip http server
ip http secure-server
!
line con 0
password cisco
logging synchronous
login
line vty 0 4
password cisco
login
line vty 5 15
password cisco
login
!
end
```

```
S3#show run
Building configuration...
Current configuration: 1935 bytes
version 15.0
no service pad
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
hostname S3
boot-start-marker
boot-end-marker
enable secret 4 06YFDUHH61wAE/kLkDq9BGho1QM5EnRtoyr8cHAUg.2
no aaa new-model
system mtu routing 1500
no ip domain-lookup
spanning-tree mode rapid-pvst
spanning-tree portfast default
spanning-tree portfast bpduguard default
spanning-tree extend system-id
vlan internal allocation policy ascending
interface FastEthernet0/1
switchport trunk native vlan 99
```

```
switchport mode trunk
!
interface FastEthernet0/2
shutdown
interface FastEthernet0/3
 switchport trunk native vlan 99
switchport mode trunk
interface FastEthernet0/4
 shutdown
!
interface FastEthernet0/5
shutdown
interface FastEthernet0/6
 shutdown
interface FastEthernet0/7
shutdown
interface FastEthernet0/8
shutdown
interface FastEthernet0/9
shutdown
interface FastEthernet0/10
shutdown
interface FastEthernet0/11
 shutdown
interface FastEthernet0/12
shutdown
interface FastEthernet0/13
shutdown
interface FastEthernet0/14
shutdown
interface FastEthernet0/15
shutdown
interface FastEthernet0/16
shutdown
interface FastEthernet0/17
 shutdown
```

```
interface FastEthernet0/18
switchport access vlan 10
switchport mode access
interface FastEthernet0/19
shutdown
!
interface FastEthernet0/20
shutdown
interface FastEthernet0/21
shutdown
interface FastEthernet0/22
shutdown
interface FastEthernet0/23
shutdown
interface FastEthernet0/24
 shutdown
interface GigabitEthernet0/1
shutdown
interface GigabitEthernet0/2
shutdown
interface Vlan1
no ip address
interface Vlan99
ip address 192.168.1.13 255.255.255.0
ip http server
ip http secure-server
line con 0
password cisco
logging synchronous
login
line vty 0 4
password cisco
login
line vty 5 15
password cisco
login
!
end
```