

Demo Air Maintenance Task Card - ATA 32 Landing Gear

Task 32-41-00-210-801: Main landing gear brake wear inspection

Aircraft type: DA-350 (fictional). Revision: Rev 7.

WARNING: Make sure the parking brake is set and wheel chocks are installed before this task.

1. Apply brake pressure of 3000 psi using the parking brake.
2. Measure the wear pin protrusion on each brake assembly P/N 2315-0045-001.
3. If the wear pin is flush with the housing or below it, the brake has reached its wear limit.  
Replace the brake assembly P/N 2315-0045-001 before the next flight.

4. If the wear pin protrudes 1 mm or more, the brake is serviceable. Record the value in the tech log.
5. Wheel nut torque after brake replacement: 150 ft-lb, then back off and re-torque to 90 ft-lb.

Related task: 32-42-00-710-802 (brake operational test after replacement).

Tooling: wear pin gauge T-3241-06.

Maintenance planning contact: j.murphy@demoair.example, phone +353 1 555 0147.