SULZER

CHIEFTAIN 1860 - PERIODIC MAINTENANCE LOG

Frequency	Maintenance activity	Acceptance / action
Weekly	Thoroughly clean machine, bedways, slides and chip/coolant areas.	Clean and serviceable; no accumulated swarf or obstruction.
Weekly	Inspect chuck/guards, leadscrew guard, toolpost guard and rear splash guard where fitted.	Secure, undamaged and functional.
Weekly	Check coolant quantity, pump operation and leakage.	Adequate coolant; pump operates; no abnormal leaks.
Weekly	At no load, observe headstock/spindle for abnormal noise and vibration.	No abnormal noise or vibration.
3 Monthly	Replace headstock, gearbox and apron oil after initial 3 months (commissioning service).	Initial oil change completed and recorded.
3 Monthly	Clean dust, chips and foreign matter from moving parts.	Moving areas clean and unobstructed.
3 Monthly	Inspect electrical wires, terminals and switches.	Inspection by qualified/authorised personnel; repair any damage.
6 Monthly	Replace headstock, gearbox and apron oil after initial 3-month change.	Routine oil change completed and recorded.
6 Monthly	Inspect drive, feed, slide and lubrication condition.	Smooth operation; no abnormal wear, looseness or leakage.
Annually	Comprehensive mechanical inspection: spindle, chuck, bearings, carriage, cross/compound slide and tailstock.	Record condition, clearance/run-out concerns and corrective actions.
Annually	Inspect safety devices and machine electrical condition.	Function verified by qualified personnel; defects corrected before release.
Annually	Inspect coolant system and clean tank/pump/lines as required.	Coolant system clean, leak-free and operating correctly.

Lubrication reminder: Keep the lead screw clean and lightly oiled; verify apron oil level at the sight gauge. Use only the lubricant grade approved for your exact machine/manual and site standard.

Safety note: Switch the electrical disconnect OFF before maintenance and follow your site lockout/tagout procedure. Maintenance should be carried out by qualified personnel.

Document basis: Machine identification follows the previously prepared Chieftain 1860 Centre Lathe SOP. The maintenance structure uses available 1860-class engine-lathe maintenance guidance for daily, weekly, 3-month, 6-month and annual service. Verify exact lubricant grades, quantities and intervals against the installed Chieftain 1860 operation manual before workplace approval.