
SQD Tree Rack (10 Hook) - Build Sheet

Visuals

Tree Rack Assembly



Materials & Cuts

• Carbin: 47" length

• Copper Hook: 4ft length, bent @ 2 1/2" with a twist

• **Tips:** 3/8" rod, 8 1/2" long

Instructions

- Form Hook: Take the 4ft copper piece, make the J-bend at 2 1/2", and add the twist.
- Assemble: Bolt the copper hook to the top of the 47" carbin spine.
- Weld Tips: Cut and bend the 3/8" rod for the 10 tips. Weld them onto the spine according to the spacing measurements.

Tip Spacing (From Top)

2", 5 3/4", 11 3/4", 15 1/4", 21 1/4", 25 1/4", 31 1/4", 34 3/4", 40 1/4", 44 1/2"